

Performance

When used, these tubes are to be connected.

Measuring range	0.2 to 20 ppm	20 to 66 ppm
Number of pump strokes	3(300 ml)	1(100 ml)
Correction factor	1	3.3
Sampling time	6 min	2 min

Detecting limit: 0.1 ppm (3 pump strokes)

Colour change : White → Brown Corrections for temperature & humidity : Unnecessary

Relative standard deviation: 10 % (for 0.2 to 5 ppm), 5 % (for 5 to 20 ppm)

Shelf life: 2 years

Reaction principle

Pretreatment tube: Interference gas removing

Detector tube : $2C_6H_6 + HCHO \rightarrow C_6H_5CH_2C_6H_5 + H_2O$

C₆H₅CH₂C₆H₅ + H₂S₂O₇ → Condensation polymer

Possible coexisting substances and their interferences

Substance	Concentration	Interference	Changes colour by itself to
Hexane	≤ 500 ppm	No)
Toluene	≤ 300 ppm	No	} No
Xylene	≤ 350 ppm	No	J

Aromatic hydrocarbons other than benzene are trapped in the white layer in the pretreatment tube. If the pretreatment reagent is entirely consumed (whole white layer turns to brown), a higher reading will be given.

Calibration gas generation

Diffusion tube method