



From the house of
inbase
Copyright © 2019 inbase, India.

www.gourban.in
Helpline
support@inbasetech.in

Sleeping Monitor

User wearing the watch while sleeping can detect the length of sleep, as well as deep sleep and light sleep state. Adjust your sleeping time according to the data's reference, improve your body's health index. The defaulted sleep monitoring time is from 21:00 pm to 7:30 am. The sleeping data result of last night will be displayed after 10:00 am. Data can be synchronized to the App with detailed information analysis and data record can be viewed from the App.



Alarm & Stop Watch

With in-built alarm feature, it's not necessary to keep your eye on the clock for our important schedules. The stopwatch feature helps to keep your activity under timely check.



Calendar

Urban lyf keeps you in touch with complete access of calendar. The in-built calculator feature acts as your mathematical guide at fingertip.



DEVICE DIMENSIONS



URBAN LYF

COLORS OPTION



Jet Black Case With Midnight Black Band



Silver Case With Frost White Band



Rose Gold Case With Pink Salmon Band



USER MANUAL

App DOWNLOAD FUNDO



Fun Do



Scan the QR code on the right side to download and install the App to the phone. (Supports IOS 9.0 & above, Android 4.4 & above. It does not support all mobile device models).

SMART WATCH CHARGING AND ACTIVATED

First time users, please make sure the battery is fully charged. It takes 2 hours to be fully charged. Use the magnetic charger to attract the metal contacts on the back of watch (as shown on the right), and connect the other end of charger to USB charging head or computer USB interface (please use 5V / 500 mA) charging head. The two charging thimbles on the magnetic charger end cannot be attached to metal objects, in case of short-circuit & fire, do not charge with fast charging device.



CONNECT SMART WATCH

1. Switch Smart Watch: long press the touch area of screen for 3-5 seconds.
2. Please turn on the phone's Bluetooth and location service and make sure the watch is not binded to other devices.

Install & Open FunDo app in your mobile phone → Set your personal information → Enter the device interface → Click on "My Device" → Go to settings in your smartwatch → Click "About" to view MAC address, you can use the MAC address from the device list to determine your device → The device name and the corresponding MAC address are paired → Device successfully connected.

Each time you open the App, the watch will automatically connect to the phone. After right-slide of the main interface of watch to enter the MAC address interface, the Bluetooth icon will appear, indicating that Bluetooth is connected. If there is no Bluetooth icon, Bluetooth is not connected.

NOTE:

1. When using GPS under sports mode, please turn on location services for phone and device. The watch does not have GPS function, you can open the GPS function in the App.
2. The Relevant data can be Synchronized by pulling Down the corresponding page. More detailed information analysis and data recording can be viewed from the app

URBAN LYF FEATURES

Main Interface/Dial

Long press the main dial interface, slide it and select your preferred interface. Flaunt yourself by switching the watch interface according to your convenience.



How to sync exercise data via Bluetooth?

- Step 1: Go to FUNDO APP
- Step 2: Add device
- Step 3: Pair your device with "Urban LYF"

Now you can sync exercise data via the Bluetooth function in your smartwatch

How to pair calling function via Bluetooth?

- Step 1: Go to Bluetooth Setting
- Step 2: Pair your device with "UrbanLYF_LE"
- Step 3: Allow access to sync contacts
- Step 4: Once the access is given, kindly do one time synchronization from smartwatch

Now you can make and receive calls via bluetooth function in your smartwatch

Bluetooth Calling Function

Receive and make calls directly from the smart watch. When there is an incoming call, the watch will vibrate, then you can answer the call via the watch without pulling out your mobile phone. Even phonebook can be accessed at ease



Caller Display

Urban Lyf is designed to showcase the caller name only if the respective connected device have contacts list of 200 contacts or less. If the device have more than the mentioned limit, it will not display the caller name. However, it can be easily accessed from the call logs or contact function



Music Control

Connect the App client state, manually open the mobile phone music player, and control the music to last song, next song, pause/play on the watch side.



Camera Control

When the App is connected, the Android mobile phone can directly click the remote camera function on the App to automatically turn on the camera. The IOS system phone needs to manually turn on the camera, then click the camera button on the watch to shoot or shake it (shake the arm) to take photo.



Disclaimer:

It is forbidden to throw this product into the fire to avoid an explosion. The battery life varies according to the environment and usage mode.

Warning: This product is not a medical device. The watch and its application should not be used for diagnosis, treatment, or prevention of diseases. If you want to change your habits such as exercise and sleep, please consult qualified medical personnel first, in case if you are suffering from serious casualties. Our company reserves the right to modify and improve any of the functions described in this manual without prior notice. At the same time, the company reserves the right to continuously update the contents of the products. All contents are subject to the actual product.

FAQ:

1. Warranty: 12 months from the date of purchase.

2. Why can't you wear watch for hot water baths, hot springs, saunas, etc.

The bath water temperature is relatively high, it will produce a lot of water vapor, and the water vapor is gas phase. Its molecular radius is small, it is easy to infiltrate from the shell gap of the watch, and when the temperature drops, it will re-condense into a liquid phase. Water droplets can easily cause short circuit inside the watch, damage the circuit board and damage watch.

Special Attention: For other issues of watch usage, you can get detailed answers in the App suggestion feedback.

Blood Oxygen

Stay ahead by intelligently monitoring your (spO2) blood oxygen levels and be aware of changes to your body. Monitoring your blood oxygen levels is essential to help you avoid possible health problems in the long run



Heart Rate

Slide to the heart rate function interface, the heart rate will start automatically after 2 seconds (you can also click the heart rate icon to stop/start during the measurement). The test data will be displayed when the measurement is completed> The heart rate monitoring data can be synchronized to the App, and the detailed HR information analysis and the data record can be viewed from the App (Please utilize the correct posture while measuring, the measurement results are for reference only and cannot be used as medical data).



Blood Pressure

Track the real-time blood pressure rate while you exercise to keep record of your performance and overall improvement.



ECG Monitor

With Urban Lyf, you can record your cardiogram at any time to analyze the efficiency of your heart function. Designed to provide continuous medical grade data while fitting your lifestyle



All Day Activity Tracker

The inbuilt step pedometer provides accurate step-count and calorie burnt information



Sedentary Reminder

You'll get a friendly reminder after a long sitting to keep your rolling. This feature will help you to get rid of an inactive lifestyle also maintains you to keep fit and stay healthy.

