

EdenPURE

**OxiLeaf® Refrigerator
Air Purifier**



**Model No.: A6007
Owner's Manual**

PLEASE READ AND SAVE
THESE INSTRUCTIONS



WARNINGS

Please read this Owner's Manual before using this product

- Do not get the unit wet.
- Do not expose the unit to high temperatures.
- Do not disassemble, repair or modify the product yourself.
- Power unit off when you store it.
- Do not get the unit close to a magnetic or electrical field.
- Do not use the unit to deodorize while it's charging. Wait until it has a full charge (around 6 hours) before use.

TIPS

Do not use the EdenPURE® OxiLeaf® Refrigerator Air Purifier in freezers.

Use the unit to deodorize your closet, cupboards, older storage boxes and your pantry.





Designed with low concentration ozone and negative ion technology, this unit can actively and automatically deodorize and sterilize refrigerators, wardrobes, shoe closets, cabinets, storage boxes, etc. Meanwhile, it helps keep food fresh for longer while accelerating the clearance of pesticide residues.

Touch Power Key



**Ozone
Outlet**

**Indicator
Light**

**microUSB
Charging Port**

TURNING THE UNIT ON

Press and hold the Power Button for 2 seconds to turn the unit on. Press the power button again to shift between the modes.

**Stand-By
(Red)**



**Slow Sterilization
(Green)**



**Fast Sterilization
(Blue)**



**Prolonged Slow Sterilization
(green light on every 3 sec)**



**Prolonged Fast Sterilization
(blue light on every 3 sec)**



TURNING THE UNIT OFF

When the unit is on stand-by, hold the Power Button to turn the unit off.

SLEEP MODE

If the unit is on stand-by and not running (with the red light on), it will shift to sleep mode to save power consumption.



STERILIZATION MODES

Slow Sterilization: The unit will run for 5 minutes in the Slow Sterilization Mode (green light on). Then it will shift into the stand-by mode for 25 minutes before it returns to the Slow Sterilization Mode. The green light will flash every 3 seconds. Press the Power Button to end the stand-by mode.



Fast Sterilization: The unit will run for 10 minutes in the Fast Sterilization Mode (blue light on). Then it will shift into the stand-by mode for 20 minutes before it returns to the Fast Sterilization Mode. The blue light will flash every 3 seconds. Press the Power Button to end the stand-by mode.

CHARGING THE UNIT

When the battery is low, the red light will flash for 30 seconds with a buzzer at the end. The unit will then shut off.



Connect the USB cord to the back of the unit. While charging the red light will continue to flash until it's fully charged. Then the light will turn green. You will not be able to use the unit while it is charging.



Charging
(red light flashes)



Fully charged
(green light on)

**microUSB
Charging Port**



RUN TIME

- The battery run time on Slow Sterilization (Green Light) is around 10 days.
- The battery run time on Fast Sterilization (Blue Light) is around 7 days.

FAQ

Question: Why won't the unit turn on?

Answer: Check and make sure the unit doesn't need charged.

TECHNICAL SPECIFICATIONS

EdenPURE® OxiLeaf® Refrigerator Air Purifier

Model Number: A6007

Coverage: Up to 350 Cubic Ft.

Charging Port: MicroUSB 5V1A

Battery Capacity: 4400mA

Power: 0.5W

Ozone Release: 1 mg/h

Weight: 7.7 oz.

Working Temperatures: 14°F to 122°F

WARRANTY

The EdenPURE® OxiLeaf® Refrigerator Air Purifier comes with a 1 year limited warranty. If your unit does not appear to be working properly, please contact our service department by calling 1-800-225-6595. Prior to your call, we encourage you to visit our service related website www.edenpuresupport.com for troubleshooting tips and service instructions if needed.

EdenPURE®

7800 Whipple Avenue NW
North Canton, OH 44720

custserv@edenpure.com

Follow us/Like us



facebook.com/Edenpure



Instagram.com/edenpureproducts



twitter.com/edenpure_



pinterest.com/Edenpure

