



07-13 14-15

WATCH OVERVIEW

Noise Buzz

Workouts

• Clock

Music

Breathe

Reminders

Calculator

• Flashlight

Settings

· Watch faces

User Manual for ColorFit Pulse Grand 2

Weather

· Noise Health

• Sports Record

PACKAGE CONTAINS ColorFit Pulse Grand 2 Smartwatch >

CHARGING COLOREIT PULSE GRAND 2 SMARTWATCH

battery to its full capacity. Use the charging cable provided with the watch to charge. On a single charge, ColorFit Pulse Grand 2 can last up to 7 days. Note: The battery life and time to fully charge your device may vary as per usage and other factors.

CHARGE COLORFIT PULSE GRAND 2

• Plug the USB cable into a power adaptor. Plug the power adaptor into an electrical socket. (Power adaptor not included).

 Place the charger on the magnetic charging points of the watch. • While your watch is charging, the screen will show its progress. Once the battery is fully charged, remove the charger.



• Press and hold the side button for a few seconds to turn on the watch.

POWER OFF

• Select 'Power off' and confirm to power off.

Press and hold the side button for a few seconds.

To preserve battery, the watch screen turns off when not in use. Turn the screen back on by:

• Pressing the side button. · Turning on the wirist sense.

WAKING UP THE WATCH

POWER ON



02 User Manual for ColorFit Pulse Grand 2

WATCH NAVIGATION

The ColorFit Pulse Grand 2 smartwatch has a TFT touch screen. Navigate the watch by tapping on the screen, swiping side to side,

BUTTON NAVIGATION

• Press the side button to turn on the display. • Press the side button to go to the main menu.

HOME SCREEN NAVIGATION The home screen is the watch face.

up and down and pressing the side button.

From the home screen: Swipe right to access music. Swipe left to access activity.

· Swipe up to check your message notifications Swipe down to access quick settings.



Select 'Pair with device' and wait for it to pair.

APP SET-UP

Before pairing, make sure that your smartphone

The app will ask for personal information such as height

weight and sex to calculate your stride length, distance

Create an account or log in using an existing account.

watch name and MAC address to link the watch.

Or you can follow the steps below:

• Turn on Bluetooth and the location on your mobile device.

• On your smartphone, download the NoiseFit Prime app from the Play

Note: Ensure that your smartphone is running on Android 9.0 & +

Open the NoiseFit Prime app and allow the BT and GPS positioning

Feed in your personal information and health goals in the app.

and smartwatch are next to each other.

store or the App store and install it.

PAIRING THE WATCH

04 User Manual for ColorFit Pulse Grand 2

Scan the QR code on your watch using the NoiseFit Prime app on your phone.

Select 'Add Device'. Choose your device from the range of devices. On iOS: Choose BT pairing when you receive a pairing prompt. On Android: Connect it directly.

How does the watch estimate how many calories have been burned

ColorFit Pulse Grand 2 estimates how many calories you've burned based

Go to the 'Device' page in the app, Tap on 'select device' Select the

05 User Manual for ColorFit Pulse Grand 2

For automatic connection

After pairing the watch with the NoiseEit Prime and the watch's calling BT would be activated. Now connect it with your

To establish BT calling connectivity, follow these steps.

phone's BT to use the calling feature conveniently.

Manual connection

BT CALL CONNECTIVITY

In case the BT calling connectivity has not been established earlier, you'll have to do the steps manually. Go to Settings. Search for device and pair your smartphone to attend calls from the watch.

BT CALL CONNECTIVITY REMOVAL

• In Android devices, to remove the BT connection, you can unpair the watch from the phone's BT settings. Go to the phone's BT settings and disconnect Pulse Grand 2 - xxx (xxxx last 4 digits of watch's mac address).

• In iOS devices, to remove the BT connection, you can unpair the watch from the phone's BT settings. Go to the phone's BT settings (xxxx last 4 digits of watch's mac address).

NOISE BUZZ

WATCH FEATURES

You can use this feature to manage calls from the watch. via BT. Go to Noise Buzz to access recent logs, make calls using the dial pad and access contacts Note: If the watch is connected to your smartphone via tan the switch icon on your watch to switch to your pho and take the call there.

NOISE HEALTH

06 User Manual for ColorFit Pulse Grand 2

Noise Health Suite has a collection of wellness features that take a holistic route.

You can check your daily activity progress in terms of the calories burned, distance covered, active time and steps take You can view your most recent sleep record and sleep quality

in various sleep stages, in the NoiseFit Prime app. The feature will measure the device records of the user's sleep cycle, sleep states (light and deep sleep), wake time and REM.

Blood Oxygen

ColorFit Pulse Grand 2 supports the viewing of the highest and lowest Blood Oxygen levels of the day. To measure you blood Oxygen level in real-time, go to the 'SpO2' monitor Note: Make sure your arms and wrists are still and there

is no space between your watch and the wrist.

ColorFit Pulse Grand 2 supports 24/7 heart rate tracking. You can select the measurement frequency in the app settings. To measure your heart rate in real-time, go to the 'Heart Rate' monitor and tap on 'Tap to Measure,' You can view the all-day data on the watch and app. Note: Make sure your arms and wrists are still and there is no space between your watch and the wrist.

ColorFit Pulse Grand 2 supports 24-hour stress level measurement and viewing of all-day measurement data. To measure the stress level in real-time, go to the 'Stress' feature and wait for it to measure. Note: Make sure your arms and wrists are still and there is no space between your watch and the wrist.

WORKOUTS

You can choose from 59 workout modes. You can take your pick and add more workouts from the app. This feature also lets you control music while working out User Manual for ColorFit Pulse Grand 2









SPORTS RECORD

before using the product

You can check the progress report of your workouts in

CLOCK Alarm

You can set alarms in the NoiseFit Prime app and they will sync with the watch. You can add, delete, and enable/disable alarms. You can also label alarms to

Stopwatch A stopwatch can be set on the watch. You can also set

lap times on the stopwatch.

You can set a timer with a pre-set duration on the watch and the timer will remind you when the time is up.

ColorFit Pulse Grand 2 supports 7-day weather viewing in a location of your choice as long as it is synced with weather and for the next 7 days as well. Open the Weather app on your watch and change the location to see the weather of your current location

User Manual for ColorFit Pulse Grand 2



User Manual for ColorFit Pulse Grand 2

play from your phone, right on your wrist as long as the watch is connected to the NoiseFit Prime app on your track and increase/decrease the volume.

This feature helps you adjust your breathing rhythm as r your convenience. You can choose from 3 speeds fast, moderate and slow) to adjust your breathing duration to the 'Breathe' feature, choose the time duration and speed and tap on start to enter the cycles of breathing and

REMINDERS

CALCULATOR

your smartwatch.

09 User Manual for ColorFit Pulse Grand 2

FLASHLIGHT You can use this feature to turn on the screen brightness and see your surroundings better. Go to the Flashlight, Tap

You can control your favourite songs and podcasts that

You can add or edit reminders on the app.

You can use this feature to do basic calculations through

adjust the ringtone volume. You can set the watch's brightness.

10 User Manual for ColorFit Pulse Grand 2

You can switch between different watch faces in the watch

also create your own watch faces in the NoiseFit Prime app.

Changing the watch face Give your screen a personalised style by changing or ustomising the watch face from the NoiseFit Prime app or

Touch and hold the home screen. Swipe and choose from

Tap on call settings to change incoming call settings

(only ring, only vibration, ring & vibration or mute) and

the watch faces.

WATCH FACES

Go to watch faces, select the watch face of your choice and tap 'save' to change the watch face.



You can set the vibration level to get an alert of any

Turn on the wrist awake and set the 'Auto Screen Off' duration as per your preference.

Wrist Awake

01 User Manual for ColorFit Pulse Grand 2

You will find all the information related to the device here, including the device name, BT name and version.

You can set the DND duration on the watch. Feed in

Scan the QR code to connect with the app.

You can choose to reboot to restart the watch.

You can choose to power off to turn off the watch.

QUICK SETTINGS

to gain quick settings access.

Power Off

DND

reset, all your data and settings will be erased. 11 User Manual for ColorFit Pulse Grand 2

You can swipe up from the watch's home screen

12 User Manual for ColorFit Pulse Grand 2

BT CALLING

POWER SAVING MODE FIND PHONE BRIGHTNESS

DEVICE INFORMATION

contains the following: • 1.85" TFT Display

Stress monitor • IP68 waterproof • 50+ sports modes

03 User Manual for ColorFit Pulse Grand 2

How do I update my ColorFit Pulse Grand 2?

13 User Manual for ColorFit Pulse Grand 2

You can update your ColorFit Pulse Grand 2 via the NoiseFit Prime app. Go to 'My

'Device info' to find the latest firmware version. How do I save battery?

Follow these simple steps to save ColorFit Pulse Grand 2 battery.

DEVICE INFORMATION AND TIPS

The ColorFit Pulse Grand 2 smartwatch

Blood Oxygen measurement

Device' and select 'Firmware upgrade.' How do I find my watch's current firmware version? You can find the watch's current firmware on the watch. Go to Settings, tap on

Minimise the screen brightness. Limit the notifications you receive from the NoiseFit Prime app.

How do I change my activity goals? You can do it through the NoiseFit Prime app. Go to 'Me' and select 'My goal' Change your goals and confirm.

How do I log my weight?

14 User Manual for ColorFit Pulse Grand 2

You can log in your weight the first time you set up your NoiseFit Prime app However, you can update the weight later via the NoiseFit Prime app. Go to can update your age and height as well.

• The device includes an in-built rechargeable battery. The battery life may degrade near the end-of-life of the battery. Do not attempt to change the battery yourself in any event as you may end up damaging the device and/or the batteries posing a

15 User Manual for ColorFit Pulse Grand 2

SAFETY AND HANDLING INSTRUCTIONS:

safety hazard on subsequent usage. • Please do not tamper with the battery terminals as it may result in battery leakage, overheating, explosion or a fire hazard.

• Please do not pierce or disassemble the device as it may damage the battery causing the battery liquid to leak causing irritation to your skin if exposed to the • Damaged battery may also be prone to overheating or causing a fire hazard.

- Do not place the device near fire or expose it to excessive heating as it may cause the battery to explode posing a safety hazard. Only use Noise approved chargers and cables that are specifically designed for use with the device. Unapproved charges and cables may damage the device and also
- pose a safety hazard for the user. • If the device emits a foul smell or burning odour, please stop using the device immediately and contact the Noise approved service centres. • The device can be used in ambient temperature ranges of -20°C to 55°C. Using the
- device outside of the prescribed temperature range may damage the device. Do not use the device in a sauna or steam room.

• Do not use household cleaners to clean the device. Use soap-free cleaners instead.

HEARING LOSS:

While using the device, ensure that the sound levels are maintained at optimum level.

• The device is dust and water resistant (rated at IP68). Following tips are to be

-Please make sure that the device is not exposed to sea water or used in deep waters o not expose the device to high pressure water flow.

-Wipe the device clean of water with soft and clean cloth if exposed to water. Leave the device to dry up naturally. Do not open the device if it stops functioning upon exposure to water and despit

following the above steps. Visit an authorized service centre for getting the device

MEDICAL DEVICE INTERFERENCE:

he device includes components that may cause interference when worn with DISPOSAL INFORMATION: you intend to use a medical device, please consult your physician before using the device. Also, in case the device is allowed to be worn with the medical device

device during all times.

16 User Manual for ColorFit Pulse Grand 2

Unless otherwise specified, the device and any associated app-based or Noise provided services are not suitable to be used as medical devices. In particular, the rice and associated app-based or Noise provided services are not intended to diagnose, treat, cure or prevent any disease/health condition. We develop products nd services to track daily activity and wellness information as accurately as possible. accuracy of devices is not intended to be equivalent to medical devices or scientific measurement devices.

ur physician, ensure sufficientseparation between the device and the medical

Prolonged exposure to high volumes may result in permanent damage to hearing

hazard. Accordingly, the device is not intended for use by or left unattended around small children or pets. SKIN IRRITATION HAZARD:

part of your skin while or after using the watch, please immediately discontinue use

17 User Manual for ColorFit Pulse Grand 2

CHOKING HAZARD:

O/WM-III Division dated 04.03.2021) by the Central Pollution Control

If you experience any problem with the watch, it may be fixed by restarting

CUSTOMER SUPPORT

lamage to the same by way of irresponsible disposal of e-waste generated from electronic devices. In our endeavour to collaboratively protect the environment, we irge our customers to help Noise to reduce the impact of e-waste on the environment. The following symbol is indicative that the device and/or any of the sociated accessories (like USB cable, chargerand the like) thereof should not b lisposed with household/domestic waste. In accordance with the regulation of the stry of Environment, Forest and Climate Change, Noise has been granted stended Producer Responsibility Authorisation (EPR Authorisation number: B-290) Board, Accordingly, Noise is committed to contribute its bit owards protecting the environment by providing customers with the option of lepositing their Noise devices, which have reached their end-of-life, at authorised e-waste collection centres. The details of our e-waste collection centres and our er-management. By recycling, reusing materials or other forms of utilising old ogether we could make a difference!

In some cases, prolonged use of or exposure to the device may cause skin irritation or allergies in some users. To reduce the possibility of irritation, keep the device

18 User Manual for ColorFit Pulse Grand 2