

SmartWatch User Guide	Quick use instructions for watches Charging introduction Charging correct Touch display Heart rate sensor Note: Press and hold the button to turn on the watch. Instruction for Charging Charging the device to activate before the first time using. To charge your device, plug the charging cable into the adapter or USB port on your computer. Install DuetPro APP Scan the following QR codes or go to the major APP Stores to download and install the APP "DuetPro Pro"	Device requirements: iOS 9.0.0 and above, Android 5.0 and above, Bluetooth 4.0 is supported. Open the mobile client to set up personal information Click on the "Device" page and click on the binding device Click on your device and click on the binding device Binding completed Main function introduction Main interface - dial Press and hold the touch screen on the main interface to enter. Swipe left and right to switch and click OK. The dial has 30 dials. Step 1: distance/ calorie View the number of steps taken at any time of the day, walking distance and calories burned. Can be synchronized to the app in time to view the sports data.	Heart rate interface Switch to the heart rate test interface to enter the heart rate real time Monitoring, measurement data can be synchronized to the APP in time. And have a test report. Blood oxygen interface Switch to the blood oxygen test interface to enter the real-time detection of blood oxygen, test results are displayed directly on the bracelet interface Weather interface The weather interface will display the current weather. Weather information needs to be connected to the app. Can get data, if it is connected for a long time, weather later. The information will not be updated. Stopwatch Click the stopwatch icon to enter the stopwatch function. Swipe right	Message interface On the main interface, slide into the message interface and click the message icon to view the message. Click to turn the page, view the message to exit or right to exit. Sports interface Press the button on the main interface to enter the motion interface, right slide back to the main interface. Click on the motion map. The target can enter the motion mode detection, running, cycling, swimming, skipping, table tennis, badminton tennis. Press the button on the main interface to enter. Slide up and down to switch, click to start calculation, right slide to exit the current Sports mode. Setting function interface In the main interface, slide down to enter the setting function interface, you can choose "Find phone", "Brightness adjustment", "Alarm", "Settings" then. Click the icon to enter the corresponding function settings.	Find the phone interface In the connected state, click the "Find" icon to enter, click, the phone will Give a vibrate or ringtone reminder. Brightness adjustment interface You can freely choose the screen brightness by clicking the brightness adjustment icon. About the interface Click on the icon to display the model number of the machine and the last four digits of the Bluetooth address. Restore interface Click the restore icon to enter, you can restore the bracelet. Shutdown interface Click on the shutdown page to enter, you can shut down. Other feature reminders The reminder function needs to set the open reminder switch on the APP side, and keep the mobile phone and the bracelet in the Bluetooth connection in the successful state, the message is a vibration reminder.	Sleep monitoring function When you fall asleep, the bracelet will automatically judge to enter the deep detector mode, automatically entering your sleep deep / shallow. All right Sleep wake up time, calculate your sleep quality, also data only supports APP side view. Note: Sleep data will only be available when you wear the bracelet to sleep. Precautions 1. It is forbidden to use an adapter with a charging voltage greater than 5V and a charging current greater than 2A. The charging time is 2-3 hours. 2. Do not charge in case of water state. 3. This product is an electronic product, not for medical reference, measurement data is for reference only. common problem 1. Why can't I push caller information or content? 1.1 Android QQ WeChat reminder service permission to obtain When the user opens the QQ WeChat reminder switch for the first time, the app will get the corresponding permission and check the APP Program to get the corresponding permissions. 1.2 iOS (incoming call, SMS, QQ, WeChat) reminder switch, the system will automatically pop up the pairing request, users only need to choose to pair.	FCC Statement Change or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -- Consult the dealer or an experienced radio/TV technician for help. This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation of the device.	IC Statement This device contains Radio-waiver transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's Bureau of Standards (BIS). Operation is subject to the following two conditions: (1) This device may not cause interference and (2) This device must accept any interference, including interference that may cause undesired operation of the device. The term "IC" before the certification/registration number only signifies that the Industry Canada technical specifications were met. This product meets the applicable Industry Canada technical specifications. Cet appareil conforme aux normes techniques de l'industrie du Canada. L'exploitation est soumise aux deux conditions suivantes: (1) L'appareil ne doit pas produire de brouillage et (2) l'appareil de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.
--------------------------------------	---	---	---	--	--	--	---	--