

Language Translator Wireless Earbuds 6 Mics Hybrid ANC + AI Resists Wind Noise



Product user manual



01/Product Parameters

| Product Name | Language Translator Wireless Earbuds |
|---------------------|---|
| Product Model | P200 |
| Bluetooth Version | V5.4+EDR |
| Work Range | 10-15 Meters |
| Wireless Frequency | 2.402-2.480GHz |
| Charging Voltage | 5V/1A |
| Charging Time | About 2 hours |
| Noise Reduction(DB) | 42dB |
| Working Time | About 6-7H per session and 35H in total |
| Battery Capacity | 40mAh/400mAh |
| Charging Case Size | 2.48×1.85×1.02 inch |

① 02/Warnings

1.Al chat mode

- Do not disassemble the earphones.
 Please use standard cable and adapter for charging.
- This machine supports wearing on both the left and right ears.

oglicity of the state of the s

② 03/Charging Case Pairing Connection

Earphones automatically turn on when opening the charging case. 2. Power Off
Put the earphones back into the charging case and the power will
automatically but molf. Earphones will turn off in 3 minutes without the
need to connect any devices.
3. Bustooth Pauling
Alter power on, par the left and right earphones immediately.
4. How to Connect
into earphones from the charging case, they will automatically
build.

2. The connection of the charging case, they will automatically
build.

2. The device of the charging case, they will automatically
build.

2. The charging case, they will automatically
build.

2. The device of the charging case, they will automatically
build.

3. The device of the charging case, they will automatically
build.

the unx.

If the connection fails, please put the earphones back into the case and try again. After connection, the earphones will automatically reconnect to the last paired device when power on.

5. Bluetooth Disconnected

Turn off the Bluetooth of the device and put the earphones into pairing mode. When the headphone are disconnected from the device and within a valid distance range within 3 minutes, they will automatically



2. Free talk mode

1. Power On

This feature does not require clicking on the phone or headphone The headphones automatically recognize language, and translate, allowing users to work while translating.







3. Translation machine mode

04/Indicator Chart



© 05/Key Function

Hang up/Reject 2+Tap on either MFB

4. Headphones+phone mode



3 06/Charging Diagram



07/Packing List

Switch language

User Manual"1 pcs

Supports a total of 134 languages. You can freely switch between your language and the other party's language in the language button at the top of the App.

(APP) 08/Translation "Ear Dance" APP

10/Safety Information

U IV./Scielley Information
The Translet you haveing done them to high values audio for long periods of time. Bell lampentative Vivoring temperature is between 0.7 and 4.5 °C, and the stronger matter is between 0.7 and 4.5 °C. So, and the stronger matter is between 0.7 and 4.6 °C. So, and the stronger matter is between 0.7 and 4.6 °C. So, and the stronger matter is the most 0.7 and 4.6 °C. So, and the stronger matter is the most of the stronger matter is the production of the stronger matter is the stronger matter in the stronger matte

Procustions
To ensure perfunctioning of the earphones, please leep the media, earplags, and metal contact points on the earphones and charging case clean.

If you experience any skin inflammation while wearing earphones, please remove them and thinoughly clean them. If the problem perishes, please consult a medical professional.

WIRELESS TRANSLATOR EARBUDS

Please contact our E-mail address: support@iamjoy.tech

1 st Prize: Get one more for FREE

2 nd Prize: 50%off discount 3 rd Prize: Extend your Warranty to 2 Years

The probability of winning the first prize is 0,34%

Please Scratch Here: 1st Prize

This device complies with part 15 of the PCC Pulses, Operation is subject to the following hear conditions: (1) this device may not cause here'd pronting even and (2) this device must accept as interference societies, including interference that may cause undestend operation. Any disruption or conditionar and speaking largered by the party responsibility for compliance could velid the user's authority to operate the oppinment.

NOTE. The experience who was varied on the second with the first for a Claud 1 cityld deep gravant has the Claud 1 cityld consequence of the control of the

- Storeton or describe in receiving primons.
- Accesses the separate between the separate rand models is
- Connect the separate links are noted on a circuit offerent from that to which the notation is
connected.
- Connected for the conference or superprimons of soft Three Continues to the Connected for the Connected