



For Android4.4 & above

The diagram illustrates the front and back views of the Fitbit Charge 3 smartwatch. The front view on the left shows the display screen displaying the time 09:36, the day MON, and various activity rings. Labels point to the 'Display screen' and the 'Power button' on the right side. The back view on the right shows the heart rate sensing area and the charging contacts. Labels point to the 'Heart rate sensing area' and the 'Charging contacts'.

Note: When the magnetic charging cord is aligned with the chip, the charging symbol will appear on the watch. Please place the watch for charging, do not move the watch to avoid the charging cord fall off.



1. Power on: Long press the power button to turn it on.
2. Power off: Long press the power button, then click the "Power off".




-


1. The initial device will not display the Blood pressure &



You can turn on the wrist wake on the watch



1. Please switch the setting page on your smart watch---
Display---Brightness---Set up the brightness.



2. Bright screen time: please go to the app---click device---click Bright screen duration---turn off "Default Duration"

The language will sync with the phone after paired

The language will sync with the phone after paired

Run, Walk, Breathe, HIIT, Yoga, Cycle, Plank, Rope Skipping, Climb, Hiking, Spinning Bike, Rowing, Stepper, Elliptical, Basketball, Tennis, Badminton, Football, Baseball, Rugby

Please click the sports icon to start the sport; the sport time and the real-time heart rate and calories will show on the watch screen. After finishing the sports, click the "X" icon. The app and smart watch will record your sports

The water-resistant performance of the device is not

1. The watch falls, bumps, or suffers from other impacts.
2. The watch is exposed to soap water, shower gel,

1. Bluetooth: 5.0
2. Screen size: 1.28" Screen pixel: 240*240
3. compatible system: Above Android 4.0 and IOS 9.0.
4. Stand-by time: Standby time at normal state: 30 days
Standby time at use state: 7-15 days.

1. Do not use corrosive cleaners to clean this product.
2. Store this product in a dry environment and charge it at

3. When using this device, please keep a long distance from implanted medical devices (such as pacemakers, cochlear implants, etc.)