

<div data-bbox="93 151 561 186" data-label="Section-Header"> <h2>Smart Watch User Manual</h2> </div> <div data-bbox="156 303 468 661" data-label="Image"> </div>	<div data-bbox="655 88 1155 166" data-label="Text"> <p>Welcome to use our high-performance wrist-band Smart Watch which creates thoughtful and health experience for you.</p> </div> <div data-bbox="655 196 1155 450" data-label="Text"> <p>Device Maintenance Please remember the following tips when you maintain your Smart Watch: •Clean the Smart Watch regularly, especially its inner side, and keep it dry. •Adjust the Smart Watch tightness to ensure air circulation. •Excessive skincare product should not be used for the wrist wearing the Smart Watch. •Please cease wearing the Smart Watch in case of skin allergy or any discomfort.</p> </div> <div data-bbox="655 480 1155 529" data-label="Section-Header"> <h3>Schematic diagram of main body of the Smart Watch</h3> </div> <div data-bbox="655 548 1155 725" data-label="Image"> </div> <div data-bbox="655 759 1155 852" data-label="Text"> <p>Power-on Long press the side button for 3 seconds or plug in the Magnetic charging cable to charge the Smart Watch.</p> </div>	<div data-bbox="1217 88 1717 235" data-label="Image"> </div> <div data-bbox="1248 245 1685 294" data-label="Section-Header"> <h3>Downloading and binding of Smart Watch APP</h3> </div> <div data-bbox="1248 298 1685 436" data-label="Text"> <p>1.Download and install APP Scan QR code with mobile phone to download APP. For IOS system, select APP , storesearch Da Fit. Android system, select Google Play to download and install Da Fit.Or scan QR code to download</p> </div> <div data-bbox="1248 450 1685 607" data-label="Image"> </div> <div data-bbox="1248 627 1685 695" data-label="Text"> <p>Note: your mobile phone must support Android 5.1 or IOS 8.0 or above, and Bluetooth 4.0 or above.</p> </div> <div data-bbox="1248 720 1685 739" data-label="Section-Header"> <h3>Bind Smart Watch with APP</h3> </div> <div data-bbox="1248 744 1685 882" data-label="List-Group"> <ol style="list-style-type: none"> 1.Click on "Add Device" to bind the Smart Watch. 2. Click on your device in the device list scanned. 3.The IOS system will show a Bluetooth pairing request and you can click on Bluetooth "Pairing" to confirm. Connect it directly to Android system. 4. Successfully bound. </div>	<div data-bbox="2341 88 2841 107" data-label="Section-Header"> <h3>Bluetooth call connect</h3> </div> <div data-bbox="2341 112 2841 343" data-label="Text"> <p>Android: After the APP successfully connects to the watch's Bluetooth. 1. The phone will automatically pop up a "pairing" request, click "Allow". 2. For some brands of mobile phone models, there is no need to pop up the pairing confirmation permission. After connecting to Bluetooth, the call function is also directly connected. After the binding is successful, you can answer and make calls on the watch.</p> </div> <div data-bbox="2341 367 2841 460" data-label="Text"> <p>iPhone: Enter into Settings – Bluetooth, search device and connect pair (P45_PHONE). After pair successfully, you can make call/ answer incoming call.</p> </div> <div data-bbox="2341 485 2841 504" data-label="Section-Header"> <h3>Remove Bluetooth Call connection</h3> </div> <div data-bbox="2341 509 2841 578" data-label="Text"> <p>Android: For the Android mobile phone, the device can be disconnected from your mobile phone by simply clicking on Remove device.</p> </div> <div data-bbox="2341 602 2841 695" data-label="Text"> <p>iPhone: firstly, users need dismiss pair, then enter into mobile phone Setting – Bluetooth, find P45_PHONE, click icon on the right, ignore device, watch and mobile phone are disconnection.</p> </div> <div data-bbox="2341 720 2841 739" data-label="Section-Header"> <h3>Introduction of Smart Watch functions</h3> </div> <div data-bbox="2341 744 2841 813" data-label="Text"> <p>Power-on status switch the menu interfaces of main screen, as the interfaces shown in the following;</p> </div>	<div data-bbox="2903 88 3340 176" data-label="Image"> </div> <div data-bbox="2903 205 3340 294" data-label="Image"> </div> <div data-bbox="2903 313 3340 406" data-label="Text"> <p>1. Introduction of main interface functions After the smart bracelet and APP are first paired, the time and date of the mobile phone will be synchronized.</p> </div> <div data-bbox="2903 416 3340 529" data-label="Text"> <p>2. Step counting, distance and calorie The step-counting interface shows steps. Wear the smart bracelet on wrist, and the smart bracelet can automatically count steps, distance and calories.</p> </div> <div data-bbox="2903 539 3340 744" data-label="Text"> <p>3. Sleep monitoring Wearing the smart bracelet at night to automatically judge whether you are in the sleep state, to record deep sleep and light sleep respectively, and to summarize the total sleep time to help you monitor your sleep quality. The sensor can measure your sleep quality according to the range and frequency of wrist movements when you sleep.</p> </div> <div data-bbox="2903 754 3340 798" data-label="Text"> <p>Note: Because user's sleep time and habits are different, the time of sleep monitoring is only for reference.</p> </div> <div data-bbox="2903 808 3340 877" data-label="Text"> <p>4. Heart rate measurement Enter the heart rate test interface, the motor will</p> </div>	<div data-bbox="3434 88 3933 156" data-label="Text"> <p>vibrate once after "Start measurement" and "Stop" , and the current measurement data will be displayed.</p> </div> <div data-bbox="3434 166 3933 254" data-label="Text"> <p>5.Exercise Sports interface, including a variety of sports, walking, running, cycling, skipping rope, badminton, basketball, football and so on.</p> </div> <div data-bbox="3434 264 3933 401" data-label="Text"> <p>6.AI voice Click on the voice, through the connection with the mobile phone, the user's spoken language is converted into text, intelligent dialogue and intelligent interaction of instant question and answer.</p> </div> <div data-bbox="3434 411 3933 592" data-label="Text"> <p>7. Phone Turn on the Bluetooth function of your phone and smartwatch. The phone searches for the smartwatch's Bluetooth device and initiates pairing. When both parties confirm the pairing, there will be a prompt that the connection is successful. Click the dial pad of the watch to dial and answer the phone.</p> </div> <div data-bbox="3434 602 3933 715" data-label="Text"> <p>8.Blood pressure Enter the blood pressure test interface, the motor will vibrate once after "Start measurement" and "Stop" , and the current measurement data will be displayed.</p> </div> <div data-bbox="3434 725 3933 877" data-label="Text"> <p>The environment for measuring blood pressure should be quiet with an appropriate temperature. The user should rest for at least 5 minutes, and avoid tension, anxiety and emotional excitement before measurement. Repeatedly measure blood pressure for three times at the interval of 2 minutes. Record the average of three readings.</p> </div>	<div data-bbox="3996 88 4495 200" data-label="Text"> <p>9.Blood oxygen Enter the blood oxygen test interface, the motor will vibrate once after "Start measurement" and "Stop" , and the current measurement data will be displayed.</p> </div> <div data-bbox="3996 205 4495 318" data-label="Text"> <p>Blood oxygen saturation (SpO2) is the percentage of the volume of oxyhemoglobin (HbO2) combined by oxygen in the blood to the volume of all (Hb,hemoglobin) which can be combined, i.e, the concentration of blood oxygen in the blood.</p> </div> <div data-bbox="3996 328 4495 392" data-label="Text"> <p>Note: the data measured for blood pressure and blood oxygen are for reference only, and cannot be used as the basis of relevant medical purposes.</p> </div> <div data-bbox="3996 406 4495 499" data-label="Text"> <p>10.Weather The weather page will display the current weather today, and swipe up to display the weather forecast for the next 6 days.</p> </div> <div data-bbox="3996 504 4495 592" data-label="Text"> <p>For weather information, it needs to connect with the client end before data can be obtained. If the disconnection time is long, the weather information cannot be updated.</p> </div> <div data-bbox="3996 602 4495 739" data-label="Text"> <p>11. Messages You can view the content pushed by the message in the information interface. At most five messages can be saved. After five messages are saved, the messages displayed before will be replaced by new messages one by one.</p> </div> <div data-bbox="3996 749 4495 862" data-label="Text"> <p>12.Shutter After connecting with the mobile phone, the smart bracelet can be used as a remote controller for the mobile phone camera. Open "Photo control" in APP to "Shake" the smart bracelet and click on</p> </div>	<div data-bbox="4589 88 5088 107" data-label="Text"> <p>the icon to take a photo.</p> </div> <div data-bbox="4589 117 5088 279" data-label="Text"> <p>13. Music control After connecting with the mobile phone, the smart bracelet can control the music player of the mobile phone. When the mobile phone plays music, you can use the smart bracelet to control the mobile phone for playing/pausing, the previous song and the next song.</p> </div> <div data-bbox="4589 289 5088 382" data-label="Text"> <p>14.Flashlight After opening, the screen will be adjusted to the maximum brightness and always on, and you can exit the interface after swiping left.</p> </div> <div data-bbox="4589 392 5088 460" data-label="Text"> <p>15.Game Three built-in games Bird, 2048 and Whack-a-Mole can help you relieve stress</p> </div> <div data-bbox="4589 470 5088 651" data-label="Text"> <p>16.Setting Click the "Settings" icon to enter the function list, which includes display (brightness, screen time, watch face, menu view, turning the wrist to brighten the screen,) sound and vibration, do not disturb, phone: off, save mode, call reset, System (restart, shutdown, factory reset), about (version, APP download)</p> </div> <div data-bbox="4589 661 5088 867" data-label="Text"> <p>17.Drainage Pull down the shortcut menu on the dial interface, enter the drainage system function, enter the drainage interface and wait for 3 seconds, the wristband will make a drainage sound, turn the speaker outlet down, and the wristband will automatically drain water, you can also shake the wristband to speed up the water droplets from Flare discharge.</p> </div>	<div data-bbox="5120 88 5588 107" data-label="Section-Header"> <h3>Remove Device</h3> </div> <div data-bbox="5120 112 5588 269" data-label="Text"> <p>For the Android mobile phone, the device can be disconnected from your mobile phone by simply clicking on Remove device. For Apple mobile phone after binding removal, you need to click on the symbol on the right in Setting- Bluetooth, and choose to ignore the device. As shown below:</p> </div> <div data-bbox="5120 279 5588 524" data-label="Image"> </div> <div data-bbox="5120 534 5588 553" data-label="Section-Header"> <h3>Frequently Asked Questions (FAQs)</h3> </div> <div data-bbox="5120 558 5588 627" data-label="Text"> <p>1. Why does the Smart Watch automatically disconnect Bluetooth when the Android screen goes out?</p> </div> <div data-bbox="5120 632 5588 695" data-label="Text"> <p>1> Lock background APP. When the Da Fit process is cleared, the Smart Watch will be disconnected from the mobile phone.</p> </div> <div data-bbox="5120 700 5588 720" data-label="Text"> <p>2 > Set APP self-startup</p> </div> <div data-bbox="5120 725 5588 833" data-label="Text"> <p>3 > Unrestricted background operation. The Android mobile phone installed with APP intelligently restricts the background operation by default, and App should be set manually without any restriction.</p> </div> <div data-bbox="5120 837 5588 877" data-label="Text"> <p>2. Why cannot the Smart Watch receive message push?</p> </div> <div data-bbox="5650 88 6181 426" data-label="List-Group"> <ol style="list-style-type: none"> 1> Please confirm that you have turned on the switch for message push at the mobile phone client. 2 > Please confirm that messages can be displayed normally in the mobile phone notification bar. The message push on the Smart Watch is completed by reading the message from the mobile phone notification bar. The Smart Watch will not receive the message push if there is no message in the mobile phone notification bar. (You need to find notification settings in the mobile phone settings, and turn on the notification switch of WeChat, QQ, call, SMS and mobile phone client). 3 > Turn on the mobile phone --- Settings. Enter "Notification use right" on the top search box, re-open Da Fit. 3. Why can't take a hot bath with the Smart Watch? Answer: the bath water has a relatively high temperature, and generates a lot of vapor which is in the gas phase with small molecular radius and can easily infiltrate into the Smart Watch from the shell gap. When the temperature drops down, the vapor will condensate into liquid-phase droplets which will easily cause the short circuit inside the Smart Watch and damage the circuit board and then damage the Smart Watch </div> <div data-bbox="5650 436 6181 803" data-label="Text"> <p>Warning: Please consult your doctor before you take a new sport. The Smart Watch should not be used for any medical purpose though it may dynamically monitor the heart rate at real time.</p> </div> <div data-bbox="5650 813 6181 862" data-label="Image"> </div>
--	--	--	---	--	---	--	--	--