



2 Device
Settings regarding the smartwatch and its functionality.

- **Watch Faces:** You can change the look of the watch face.
- **Notifications:** Select which notifications appear on the watch.
- **Alarms:** Switching On/Off and the configuration of alarm clocks activated on the watch.
- **Shutter:** Take photos by shaking the wrist on which the watch is placed.
- **Others:** Additional functions and settings for the watch.
- **Upgrade:** View the version of the smartwatch software and update it.



3 My device tab - Others
In this tab, you can view the settings related to the smartwatch.


- **Find device:** Watch search function, it activates a vibration alarm.
- **Time formats:** Choose a 24/12-hour time format.
- **Unit system:** Select the measurement units.
- **Do not disturb:** Turn on/off watch vibrations for new notifications.
- **Reminder to move:** Turn on/off inactivity reminders.
- **24-hour heart rate measurement:** Turn on/off automatic heart rate measurement.
- **Language:** Select the language of the smartwatch menu.
- **Reset:** Restore to factory settings.
- **Quick view:** Turn on/off the function of unlocking the screen with a hand gesture.
- **Weather:** Settings for the weather displayed on your watch.
- **City:** Ability to select a town/city in order to obtain more accurate measurements.



4 Drink Water Reminder tab
Settings related to notifications about hydration.


5 Physiological cycle reminder tab
Settings related to the physiological cycle.

- **Physiological cycle reminder:** Turn on/off the function.
- **Cycle days:** Select the number of days in the cycle.
- **Menstrual days:** Select the number of days of menstruation.
- **Last menstrual start date:** Start date of your last menstrual period.
- **Reminder mode:** Set reminders for the day before the menstrual and ovulation period, the day before peak ovulation and the end of the ovulation period.
- **Reminder time:** Select the time of the reminder.
- **Physiological cycle calendar:** With automatic indication of your menstrual period, predicted menstrual period and ovulation.



6 My
The ability to configure and view personal data and settings related to the smartwatch user profile.

- **Profile:** Data of the smartwatch user.
- **Goal:** Define the daily step goal.
- **Health (iOS only):** Connecting the app to Apple Health.
- **Background guide protection (Android only):** Instructions in case of a lack of notifications from the app.
- **About:** Information about the Da Fit app.



TECHNICAL SPECIFICATIONS

- **Bluetooth:** 5.0
- **Processor:** Realtek8762C
- **Battery:** 150 mAh
- **Weight:** max. 45 g
- **Display:** TFT 1,08"
- **Face dimensions:** 39 x 39 x 10 mm
- **Interchangeable strap**
- **Waterproof:** IP67
- **Dedicated app:** Da Fit
- **Warranty:** 24 months

More information about this device is available at www.garett.pl. Visit our website to see more products and accessories.

WARRANTY/RETURNS

The product is covered by a 24-month manufacturer's warranty. The warranty does not cover: defects and damage caused by the user or as a result of improper use (misuse), mechanical damage and damage resulting from using consumables or accessories other than those provided with the device. When submitting a claim, fill in the warranty card supplied with the device and send the device along with proof of purchase to the address of the service centre provided on the warranty card.

Contact details are available on the website:
www.garett.eu

Manufacturer:
GARETT sp. z o.o.
Targowa 18/1413
25 - 520 Kielce
www.garett.eu



As indicated by the marking on the product or in the related text, the device should not be disposed of with other household waste after the end of its service life. To avoid harm to the environment and human health as a result of uncontrolled waste disposal, please separate the product from other types of waste and recycle responsibly in order to promote reuse of material resources as a regular practice. For information about where and how to recycle this product in a way that is safe for the environment, household users should contact the retail outlet in which they purchased the product, or local authorities. Business users should contact their supplier and check the terms of the purchase agreement. Do not dispose of the product with other commercial waste.



Manufactured in P.R.C.

