

Bluetooth® compatible speaker



Reference : TES202
Version : 1.5
Language : English

LIVOO
Feel good moments
User manual

Thank you to have purchased a product brand LIVOO. We take great care in design, ergonomics and simple use of our products. We hope that this product will give you complete satisfaction.

This manual is also available on www.livoo.fr

IMPORTANT SAFETY INSTRUCTION

- Before using the unit please read the manual carefully.
- Keep this product away from any water, liquid or wet areas.
- This product shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus.
- Use in dry locations only.
- Keep this product away from naked flames such as candles.
- This product should be only operated from the type of power source indicated on the marking label.
- Do not place the product in direct sunlight or heat. Keep away from temperatures over 40°C.
- Make sure the product has plenty of ventilation.
- Do not press the buttons or the display too hard as it could damage the product.
- Do not use a wet cloth on the product. Always use a dry cloth to clean this product and keep it free from dust.
- Do not use chemicals on this product.
- Never try to repair this product yourself, take it to an approved technician. Trying to remove panels or repairing the unit yourself could lead to electric shock.
- When the unit is not in use, make sure it is correctly turned off and stored in a cool dry place.
- Do not insert foreign objects into the product.
- Adult Supervision is recommended with children using this product.
- Avoid dropping or standing on the product, as harsh impacts could damage the product.
- Ensure children and infants do not play with plastic bags or any packaging materials

SPECIFICATIONS

Bluetooth® standard: 4.1+ESR

Bluetooth® reception range: 10 m

Speaker Power: 4Ω 3W

Battery capacity: 500 mAh

Play time about: 90 minutes

Charging time about: 90 minutes

Microphone: 4.0*1.5MM

DC input: 5V-500MA (or 5V-1A)

Audio frequency: 87.5-108MHZ(Extrapolation of USB cable to do antenna radio with good results)

Support U disk playback

LIVOO
Feel good moments
User manual

Support TF card playback

Music format support: MP3 WAV WMA

Model size: 11,8 × 5,5 × 8,8 cm

Wrap weight: 218 g

PACKING DETAILS

1 speaker

1 Instruction manual

1 USB charging cable

OPERATING INSTRUCTION

Charging:

Please use provided USB cable for charging. Plug one side to micro USB port of the unit and the other side connect with the PC, wall charger or other 5V charging devices.

During charge, the red charging indicator light is on.

When the battery is fully charged, the red charging indicator light is off.

Power on/off

1. To turn on the unit, slide ON/OFF button. The indicator blue lights flashes rapidly after power on.
2. To turn off the unit, slide ON/OFF button.

Bluetooth Pairing:

1. Once the unit turned on. Blue indicator light will flash rapidly to detect nearby Bluetooth® enabled devices.
2. Look for "TES202" appear on the list of Bluetooth® devices from your device.
3. Once unit is successfully paired and connected. Lights will flash slowly.

Pause and resume Playback:

In Bluetooth® mode, press "⏸" button to pause or playback music from your media device.

Skip Track:

LIVOO
Feel good moments
User manual

In Bluetooth® mode, press the forward ►►|” or backward “|◄◄” key to skip the track.

Adjusting the volume:

Rotate the spin button to the right to increase and to the left to decrease the speaker volume.

USB Play:

Use USB flash disk to connect your device through the USB socket.

TF Card Play:

Use TF Card to connect your device through the TF Card socket.

Receiving and ending calls:

When there is incoming call, the unit will pause the playback and ring to alert.

To answer a call, press twice the phone key “☎” to answer.

To end a call, press the phone key “☎” again.

Radio Mode:

Turn on speaker, then plug in the USB cable. Switch the "M" button shortly until the speaker says FM mode. Long-press the “☎” button to search the channel. The radio is working on searching the channels when the blue light is flashing fastly. When all channels found, blue light is flashing slowly.

The button ◄◄” and button ►►|is for selecting the channel.

EU DECLARATION OF CONFORMITY

We
DELTA
BP61071
67452 Mundolsheim – France

Herewith declare under our sole responsibility, that the radio equipment

Bluetooth® compatible speaker
TES202 (Frequency range 2402MHz-2480MHz)

Fulfil the essential requirements of the Directive 2014/53/UE

The following standards were applied:

Radio:
EN 300 328 V2.1.1

EMC:
EN 301 489-1 V2.1.1 (2017-02)
EN 301 489-17 V3.1.1 (2017-02)

Health and Safety:
EN 62479: 2010
EN 60950-1 :2006 + A11 :2009 + A1 :201 + A12 :2011 + A2 :2013

Mundolsheim, 06/09/2018

LIVOO
Feel good moments
User manual



**Correct Disposal of this product
(Waste Electrical & Electronic Equipment)
(Applicable in the European Union and other European countries with separate collection systems)**

The European Directive 2012/19/EU on Waste Facilities Electrical and Electronic (WEEE)
This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.
Household users should contact either the retailer where they purchased this product or their local authority office, for details of where and how they can take this item for environmentally safe recycling.



Pour en savoir plus :
www.quefairedemesdechets.fr

LIVOO
BP 61071
67452 Mundolsheim - FRANCE

- Photo no contractual
- Worried about the quality of his products the manufacturer reserves the right to make modifications without advance notice