

# **Ooma Motion Sensor Setup Guide**

Home » Ooma » Ooma Motion Sensor Setup Guide 🖫



#### **Contents**

- 1 Key Features
- 2 Step 1: Install the App
- 3 Step 2: Pair Your Sensor
- 4 Step 3: Mount Your Sensor
- **5 Additional Information** 
  - 5.1 First time setup
  - 5.2 Starting pairing mode
  - 5.3 Status indicator reference
- 6 Need Help?
- 7 Legal
  - 7.1 This device complies with part 15 of the FCC rules.
- **8 Related Posts**

# **Key Features**



- A Status indicator light (hidden)
- B Motion sensor lens
- Standing attachment



- Pairing button
- Tamper sensor
- Battery door
- Magnetic mounting plate

Step 1: Install the App

To get started, download and install the **Ooma Home Monitoring** app on your iOS or Android device. The app can be found at: <u>ooma.com/app</u>

When the app is installed, log in using your Ooma phone number and My Ooma password. If you **forgot** your **password**, **reset** it at: **my.ooma.com** Complete the initial setup in the app



Step 2: Pair Your Sensor

For the best pairing performance, hold your sensor within 10 feet of your Telo. In the mobile app, press the "Add Sensor" button on the Dashboard. Select the type of sensor you would like to pair. Follow the instructions on your screen to pair your sensor.



**Step 3: Mount Your Sensor** 

If you are using the included adhesive pads to mount your sensor, use a damp cloth to wipe the surface where you are placing your sensor.



Use the included adhesive pads or screws to mount the sensor within range of the desired area.



If desired, the motion sensor may be mounted in a 90° corner using these four screw mounts.



The included Standing attachment can be used to install the motion sensor on any flat surface without adhesive pads or screws.



#### First time setup


After installing batteries for the first time, initial setup lasts 30 secs. Status indicator blinks red until complete.

#### Starting pairing mode

Press and hold pairing button for five seconds to start pairing mode. Status indicator quickly blinks **green** while in this mode.



## Status indicator reference



**Need Help?** 

Support articles
www.ooma.com/support
User manuals
www.ooma.com/userguide
Community forum
forums.ooma.com
Live customer care
1-888-711-6662 (US)

## 1-866-929-5552 (Canada)

## Legal

For warranty, safety, and other legal information, visit ooma.com/legal

This device complies with part 15 of the FCC rules.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Ooma Motion Sensor Setup Guide – Optimized PDF
Ooma Motion Sensor Setup Guide – Original PDF

Manuals+,