

**PBX FINDER**  
**PB02 Global Locator**



## PBX FINDER PB02 Global Locator User Manual

[Home](#) » [PBX FINDER](#) » PBX FINDER PB02 Global Locator User Manual 

### Contents

- [1 PBX FINDER PB02 Global Locator](#)
- [2 Specifications](#)
- [3 Button Functions](#)
- [4 How to Pair](#)
- [5 FFC STATEMENT](#)
- [6 FAQs](#)
- [7 Documents / Resources](#)
  - [7.1 References](#)

# PBX FINDER

## PBX FINDER PB02 Global Locator



### Specifications

- **Product Name:** PBX FINDER
- **Compatibility:** iOS, iPadOS 14.5 and above

- **Battery:** CR2032 coin cell
- **Integration:** Works with Apple Find My network

## Product Usage Instructions

### Overview and Introduction

The FINDER integrates with Apple Find My network to provide a secure and user-friendly solution for tracking items, making it easy to locate keys, wallets, and more, with security and privacy at the forefront. PBX FINDER is designed for the convenience of users, simplifying daily life, allowing you to say goodbye to lost belongings and enjoy a peace of mind lifestyle.

### Button Functions

- **Power On:** Tap the button once to hear 1 beep.
- **Power Off:** Press and hold the button for about 5 seconds to hear 3 prompt sounds and release.
- **Factory Reset:** Click 3 times in a row and long-press the 4th time to hear a long beep tone.

### How to Pair

Note: iOS or iPadOS version 14.5 or above is required.

1. Place the FINDER next to your Apple device (iPhone).
2. Turn on Bluetooth on your iPhone and connect to the internet.
3. Press the button of the PBX FINDER once to turn it on.
4. Open the 'Find My' app on your iPhone.
5. In the 'Find My' app, tap '+', then 'Add Other Item.'
6. Once your FINDER is located, tap 'Connect.'
7. Enter a name and choose an emoji for your FINDER and tap 'Continue.'
8. Confirm to add your FINDER to your Apple ID by tapping 'Agree.'
9. Tap 'Finish' to complete the setup.

### Battery

The PBX FINDER contains a CR2032 coin cell battery. During the product's lifespan, it may be necessary to replace the battery. And you should pay attention to the positive and negative electrodes of the battery.

### Battery Replacement

1. Force in the opposite direction along the buckle position to separate the upper and lower shells.
2. Replace the battery with a new CR2032 cell, ensuring the positive pole faces up.
3. Align the button position, squeeze inward, and fasten the shell.

### Additional Tips

1. When the device is paired with the Find My app, the phone needs to be linked to the Apple server. Pairing failures may occur due to network issues. We recommend the following:

- Change the cellular network, such as switching between WIFI and mobile networks;
  - Factory reset the PBX FINDER;
  - Re-pairing.
2. To remove PBX FINDER from your Apple device, open the Find My app, select "Items", find the device, then scroll down and tap "Remove this device".
  3. Battery life, related to personal usage habits; frequent use of the call function will accelerate battery drain.

## Important Matters

The PBX FINDER contains delicate electronics, including a battery, to avoid damage, loss of function, or potential harm. Please refrain from dropping, hitting, puncturing, crushing, disassembling, exposing it to extreme heat or liquids, or placing it in areas with a high concentration of industrial chemicals.

## Safety Warnings



**WARNING:** Do not swallow the battery; it poses a chemical burn hazard. The PBX FINDER may pose a choking hazard for small children; keep it out of their reach. The electromagnetic fields and magnets in the device may interfere with medical devices like pacemakers; maintain a safe distance.

### Choking Hazard Warning

The PBX FINDER, its battery compartment door, the battery itself, and the case may pose a choking hazard or cause injury to small children. Please keep these items out of reach of young children.

### Medical Device Interference

The PBX FINDER contains components and radios that emit electromagnetic fields, as well as magnets. These elements may potentially interfere with pacemakers, defibrillators, or other medical devices. To ensure safety, maintain a safe distance between your medical device and the PBX FINDER. We strongly advise consulting your physician and the manufacturer of your medical device for information that is specific to your situation. If you suspect that the PBX FINDER is interfering with your pacemaker defibrillator or any other medical device, discontinue its use immediately.

### Important Handling Guidelines

It's normal for the PBX FINDER to show discoloration with regular use. To clean it, use a soft, dry, lint-free cloth. Avoid applying pressure with sharp objects on the rubber seal or the battery terminal contacts inside the device. Do not allow moisture to enter any openings or use aerosol sprays, solvents, or abrasive materials to clean the device.

### Legal Notice

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My Network product specifications and requirements. Apple is not responsible for the operation of this device or the use of this product or its compliance with safety and regulatory standards. Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS, and watchOS are trademarks of Apple Inc., registered in the U.S. and other countries. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

## FFC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device under Part 15 of the FCC Rules. These limits are designed to protect reasonably against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used according to the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. Suppose this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on. In that case, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet the general RF exposure requirement. The device can be used in portable exposure conditions without restriction.

## FAQs


### **Q: How do I know if my PBX FINDER is connected to my Apple device?**

Once your FINDER is located in the 'Find My' app, you will see a 'Connect' option, indicating successful pairing.

### **Q: How long does the CR2032 battery last in the PBX FINDER?**

The battery life may vary but typically lasts several months, depending on usage.

## Documents / Resources

	<b><a href="#">PBX FINDER PB02 Global Locator</a></b> [pdf] User Manual 2BLCN-PB02, 2BLCNPB02, PB02 Global Locator, PB02, Global Locator, Locator
---	--

## References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.