

PEDROLLO P2 Automatic Control Device User Guide

Home » pedrollo » PEDROLLO P2 Automatic Control Device User Guide 🖺





Contents

- 1 PEDROLLO P2 Automatic Control Device User
- 2 Documents / Resources
 - 2.1 References

PEDROLLO P2 Automatic Control Device User Guide



PERFORMANCE RANGE

Restart pressure: 1.5 bar

Maximum volume capacity: 170 I/min (10 m³/h)

INSTALLATION AND USE

EASYPRESS is a durable and reliable electronic device designed to control and safeguard single-phase domestic pumps with a power capacity up to 2 HP.


PRODUCT DESCRIPTION


- * EASYPRESS features a pressure sensor and a flow sensor linked to an electronic system that automatically activates the pump when a faucet's opening lowers the pressure below a specified level and deactivates it when the flow stops or dips under 2 l/min.
- * The EASYPRESS is equipped with:
- Circuit board
- Pressure Gauge
- Integrated micro-accumulation enables operation even without an expansion tank, though the use of a 1SF tank is recommended.

The integrated electronics protect the pump from:

- * dry running
- * frequent start-ups due to leaks in the system;
- * lockout due to plant inactivity.

DIMENSIONS AND WEIGHT












TECHNICAL DATA

TYPE	P ₂		Power supply		Continuous
Single-phase	kW	HP	Volt	Hz	duty current
EASYPRESS	1.5	2	230	50/60	13 A



The **EASYPRESS** features 2 LED indicators to show the system's operating status and alerting to any issues through blinking patterns. A guide on the electrical panel helps to identify specific problems indicated by the LEDs..

APPLICATION LIMITS

- * Liquid temperature up to +55 °C
- * Ambient temperature up to +40 °C
- * Maximum operating pressure 10 bar
- * Protection rating: IP 65

PATENTS - TRADE MARKS - MODELS

- * Registered Community Model No. 868062
- * Patent No. IT 1388969, IT 1388970
- * EASYPRESS® registered trademark No. 0001334481

ACCESSORIES


* GSR Special three-piece coupling with o-ring seal (1")



CON

AVAILABLE UPON REQUEST

- EASYPRESS version with 0.8 bar restart pressure
- EASYPRESS version with restart pressure 2.2 bar
- Wersion with power cable with Schuko plug and motor pump connection cable



EASYPRESS | 50 Hz

Read More About This Manual & Download PDF:

Documents / Resources



<u>PEDROLLO P2 Automatic Control Device</u> [pdf] User Guide P2 Automatic Control Device, P2, Automatic Control Device, Control Device, Device

References

• User Manual

Manuals+, Privacy Policy