

Supereyes M1 Mini Screen LCD Bubble Remover Machine **Instruction Manual**

Home » SUPEREYES » Supereyes M1 Mini Screen LCD Bubble Remover Machine Instruction Manual



Contents

- 1 Supereyes M1 Mini Screen LCD Bubble Remover **Machine**
- 2 Safety Rule
- 3 Specification
- 4 Features
- **5 Installation**
- **6** Operation
- 7 Maintenance 8 Documents / Resources
- **9 Related Posts**



Supereyes M1 Mini Screen LCD Bubble Remover Machine



Safety Rule

For your own safety, please read this manual carefully. Please familiar with the application and limitation of the machine, as well as the relevant potential risk.

- Please read this manual carefully before using the machine.
- Please keep the grounding good, bad grounding may result in equipment damage or endanger personal safety.
- It is strictly forbidden to open the electric box as non-professionals.

Specification

- Voltage AC220V (AC110V Optional)
- Working Environment 20-30°C Clean Dust-free
- Heating Mode: Constant temperature heating
- Equipment size 350*180*88mm
- Platform size 350*280mm 7 inch
- · Equipment weight:
 - Net weight 6.58KG
 - Gross weight 6.82KG
- Equipment Power 300W

It is recommended that use a vacuum pump who not less than 2 liters

Features

- 1. 7inch small size, ultra-thin in addition to foam machine, powerful.
- 2. High efficient, 30 seconds per piece
- 3. High intelligent equipment, one button automatic operation

4. Operation is extremely simple bubble remove machine

Installation

- 1. Plug in and put the vacuum pump triangle plug into the triangle port while put the vacuum tube into the under port.
- 2. Install the muffler on the air compressor
 - 1. Press the top red button is turned off, up is start up.
 - 2. The right side is open valve, vertical is pumping, sideways is deflated.



Operation

Check setting on the screen

• Laminating temperature: 40°C;

Vacuum time: 30s;Laminating time: 30s;

• Defoaming temperature: 40°C.

Attention: This is factory settings, please don't adjust it by yourself.

Put the screen into the door, the cable on the bottom



Press the start button, about 30 seconds, you can press the stop button, take out the screen.



Attention: Press the screen after turn the cable

Maintenance

Items	Notes
Platform and platen	Keep clean, no clutter inside.
Life of machine	For keep it long use, turn off
	the power when not in use.

Documents / Resources



<u>Supereyes M1 Mini Screen LCD Bubble Remover Machine</u> [pdf] Instruction Manual M1, Mini Screen LCD Bubble Remover Machine, M1 Mini Screen LCD Bubble Remover Machine, LCD Bubble Remover Machine, Machine

Manuals+,