

Suprema BioStar 2 Time And Attendance Software



Suprema BioStar 2 Time And Attendance Software User Guide

[Home](#) » [suprema](#) » Suprema BioStar 2 Time And Attendance Software User Guide 

Contents

- 1 Suprema BioStar 2 Time And Attendance Software
- 2 Product Information
- 3 Product Usage Instructions
- 4 How to Use the New Dashboard
 - 4.1 System Usage
 - 4.2 Edit Widget
- 5 Documents / Resources
 - 5.1 References

suprema

Suprema BioStar 2 Time And Attendance Software



Product Information

Specifications:

- **Product Name:** BioStar 2

- **Type:** Administrator Guide
- **Feature:** New Dashboard Customization

Product Usage Instructions

Adding Widgets:

1. Click on the main screen of BioStar 2.
2. Click on Dashboard Settings, and then click Add Widget.
3. Select the desired Widget Types, then enter or set the required fields, depending on the widget.

Widget Types:

- **Chart:** Selecting desired chart data enables the display of the number of events that occurred in a chart.
- **Counter:** Selecting desired counter data enables the display of the number of events that occurred as a number.
- **Text:** In the widgets area of New Dashboard, you can enter and place desired text.
- **Real-time Events:** Shows events occurring in BioStar 2 in real time.
- **Checkpoint:** Select one device and display the profile photo and information of the user who successfully authenticated to the device in real time.
- **System Usage:** Displays various usage statuses of BioStar 2 in numbers.
- **Door Control:** Check and control the status of a selected door.

Refreshing Dashboard:

To refresh the new dashboard page and update the data in the modified widget, click on the Refresh button.

Dashboard Settings:

Add new widgets or set the data and appearance of the added widgets by entering Dashboard Settings.

Frequently Asked Questions (FAQ)

Q: How can I customize the widgets on the new dashboard?

A: To customize widgets, click on Dashboard Settings, then click Add Widget, select the desired Widget Types, and set the required fields accordingly.

Q: What happens to real-time events if I navigate away from the New Dashboard?


A: If you navigate away and return, the list will be cleared, and events will be logged anew.

How to Use the New Dashboard

The newly added dashboard can be customized as desired by selecting the desired information for each user, adding widgets, and freely arranging the widgets.

- For each user, the New Dashboard can be configured for them personally.
- Information available on the New Dashboard may vary depending on Operator Level.



New Dashboard Main Screen



The image above is an example screen and may differ from the actual screen.


No.	Item	Description
1	Widget Area	<p>The area where user-added widgets are displayed.</p> <ul style="list-style-type: none"> The size of each widget can be freely adjusted within the size limits for each widget. Widgets can only be placed in empty areas, and they cannot overlap each other.
2	Refresh	<p>Refresh the new dashboard page to update the data in the modified widget.</p> <ul style="list-style-type: none"> Set the refresh cycle in Auto Refresh Interval in Dashboard Settings.
3	Dashboard Settings	<p>Add new widgets or set the data and appearance of the added widgets.</p>

Adding Widgets


- Click  on the main screen of BioStar 2.
- Click Add Widget.
 - If widgets have already been added, click  to enter Dashboard Settings, and then click Add Widget.
- Select the desired Widget Types, then enter or set the required fields, depending on the widget.

Widget Types

- The default widget size is set differently for each widget and is optimized to look best at the default.
- All widgets can be resized by dragging the lower-right corner.



Chart



The image above is an example screen and may differ from the actual screen.

Selecting desired chart data enables the display of the number of events that occurred in a chart.

- Chart Data: From the daily or weekly event list, select the desired chart data.
 - Daily Access Granted, Daily Access Denied, Daily Communication Issue, Daily APB Violation, Weekly Access Granted, Weekly Access Denied, Weekly Communication Issue, Weekly APB Violation
- Chart Type: Select the desired type among Vertical Bar, Horizontal Bar, Line, and Pie.
- Color Schemes: Select the desired color among 5 color schemes.

The charts shown when selecting Color Schemes are random values for preview, not actual values.

Counter

Device Disconnection 0	Forced Door Open 0
Held Door Open 0	Access Denied 0

The image above is an example screen and may differ from the actual screen.

Selecting desired counter data enables the display of the number of events that occurred as a number.

- Counter Data: From the daily or weekly event list, select the desired counter data.
 - Daily Access Granted, Daily Access Denied, Daily Communication Issue, Daily APB Violation, Weekly Access Granted, Weekly Access Denied, Weekly Communication Issue, Weekly APB Violation

Text


For Text widget, line-break is allowed, so when the user typed more lines than the number of lines the widget can display, the exceeded lines will be cut. The font size will not be resized.

The image above is an example screen and may differ from the actual screen.

In the widgets area of New Dashboard, you can enter and place desired text. After creation, you can place it in the required location and use it as a title for a widget or as a notice.

If you select the Remove Background option while creating a Text widget, transparency will be applied to the background.

Real-time Events



► The image above is an example screen and may differ from the actual screen.

Shows events occurring in BioStar 2 in real time. You can check events by filtering specific events, users, doors, and devices.

- **Pause:** To pause the real-time event.
- **Play:** Resume a real-time event that stopped.
- **Clear:** The entire captured record will be removed.

If you navigate to another page and subsequently return to the New Dashboard, the list will be cleared, and events will be logged anew.

Checkpoint




► The image above is an example screen and may differ from the actual screen.

Select one device and display the profile photo and information (Name, ID, Period, Device Name) of the user who successfully authenticated to the selected device in real time.

- **Pause:** To pause the checkpoint.
- **Play:** To resume the checkpoint that paused.
- **Clear:** The entire captured record will be removed.

Checkpoints are recorded for up to 5 people.

System Usage



► The image above is an example screen and may differ from the actual screen.

The various usage statuses of BioStar 2 are displayed in numbers.

- The usage status that can be displayed is as follows:
 - User, Card, Fingerprint, Visual Face, Face, QR/Barcode, Mobile Access, Device, Door, Zone, Access Group, User Group, Device Group

Door Control



► The image above is an example screen and may differ from the actual screen.




Select one door to check and control its status.

- The following items can be controlled with the Actions buttons:
 - Open, Normalize, Manual Lock, Manual Unlock, Clear Alarm, Clear APB

The name of the Door Control widget is automatically assigned to the name of the door and cannot be modified.

After completing the settings of the widget, click Apply, and the widget will be created in the widget area. Adjust it to the desired size and location, then click Apply, and the widget will be added to the New Dashboard.

Edit Widget

1. Click  on the main screen of BioStar 2.
2. Click  at the top right to enter Dashboard Settings.
3. Click  at the top right of the Widget you want to edit, then edit the desired part.



위젯 수정

- 위젯 이름: Device Disconnection
- 위젯 유형: 카운터
- 항목




항목	종류
항목 1	Device Disconnection


적용 취소

► The image above is an example screen and may differ from the actual screen.

4. After making edits, click Apply to save the changes.
5. After making adjustments to the widgets, select Apply, located at the top-right of the Dashboard Settings screen, to apply and save the changes.
 - The Widget Types cannot be changed in the Edit Widget.
 - System Usage, Checkpoint, and Door Control that use a specific name cannot modify the Widget Name.

Delete Widget

1. Click  on the main screen of BioStar 2.
2. Click  in the upper right to enter Dashboard Settings.
3. Click  at the top right of the Widget you want to delete.



Confirm

✓ Deleting widget. Continue?


Yes No

► The image above is an example screen and may differ from the actual screen.

4. Check the deletion confirmation pop-up and click Yes.
5. Click Apply at the top right of the Dashboard Settings screen to apply the deletion.

© 2024 Suprema Inc. Suprema and identifying product names and numbers herein are registered trade marks of Suprema, Inc. All non-Suprema brands and product names are trademarks or registered trademarks of their respective companies. Product appearance, build status and/or specifications are subject to change without notice.

Documents / Resources

	Suprema BioStar 2 Time And Attendance Software [pdf] User Guide BioStar 2 Time And Attendance Software, BioStar 2, Time And Attendance Software, Attendance Software, Software
---	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.