



TASCAM Portacapture X8 High Resolution Multi Track Handheld Recorder User Guide

[Home](#) » [TASCAM](#) » TASCAM Portacapture X8 High Resolution Multi Track Handheld Recorder User Guide 

Contents

- [1 TASCAM Portacapture X8 High Resolution Multi Track Handheld Recorder](#)
- [2 Overview](#)
- [3 Installing the Windows dedicated software](#)
- [4 Uninstalling the Windows dedicated software](#)
- [5 Setting Sound Properties](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)

TASCAM®

TASCAM Portacapture X8 High Resolution Multi Track Handheld Recorder



Overview

- Download the latest version of the dedicated software from the TEAC Global Site (<https://teac-global.com/>).
- Installing the dedicated software will install a driver and a settings application (Portacapture Settings Panel).

CAUTION

- Before starting to install software, quit other applications.
- With a Mac, the standard OS driver will be used, so there is no need to install any software.

Before using this software, read the Software Use License Agreement and agree to its terms.

Trademarks

- TASCAM is a registered trademark of TEAC Corporation.
- Microsoft, Windows and Windows Media are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Apple and Mac are trademarks of Apple Inc.
- ASIO is a trademark and software of Steinberg Media Technologies GmbH.



- Other company names, product names and logos in this document are the trademarks or registered trademarks of their respective owners.

System requirements

Check the TASCAM website (<https://tascam.com/>) for the latest information about supported operating systems.

Supported operating systems

- Windows 11 64-bit
- Windows 10 64-bit

Computer hardware requirements

- Windows computer with a USB2.0 or USB 3.0 port
- Operation is not guaranteed using the TASCAM driver with ARM64 CPUs.

CAUTION

Operation of this unit was confirmed using standard computers that meet the above requirements. This does not guarantee operation with all computers that meet the above requirements. Even computers that meet the same system requirements might have processing capabilities that differ according to their settings and other operating conditions.

Installing the Windows dedicated software

Follow the procedures below to install the Windows dedicated software.

CAUTION

- Complete installation of the Windows dedicated software on the computer before connecting a Portacapture X6 or Portacapture X8 to it with a USB cable.
- If a Portacapture X6 or Portacapture X8 is accidentally connected to the computer with a USB cable before the dedicated Windows software is installed and the “Found New Hardware Wizard” launches, close the wizard and disconnect the USB cable.

Windows dedicated software installation procedures

1. Download the latest Windows dedicated software from the TEAC Global Site (<https://teac-global.com/>) and


save it on the computer to be used with the unit.

2. ncompress the saved software (zip file) on the computer desktop or another location.
3. ouble-click the “TASCAM_Portacapture_Installer_x.xx.exe” file in the folder that appears after uncompression to launch the installation software.


CAUTION

If you open a zip file without decompressing it and doubleclick the “TASCAM_Portacapture_Installer_x.xx.exe” file in the folder that opens, installation will not start. Right-click the zip file and select “Extract All”, for example, to decompress it and then try again.


4. When a Security Warning or User Account Control screen appears, click the “Yes” button.
5. Read the contents of the User License Agreement, and select “I accept the agreement” if you agree to the terms. Then, click the “Next” button.



6. Next, click the “Install” button.



7. The following screen appears when installation has completed. Click the “Finish” button.



The installer will quit and the Windows Settings Panel will launch.

NOTE

The first time you connect the unit by USB to the computer after installing the software, installation of the device driver will be executed. Some time might be necessary before the unit is recognized because Windows Update will be automatically searched at this time. If the unit is still not recognized after a while, open the software installation screen from the notification area at the bottom right of the computer display, and click "Skip obtaining driver software from Windows Update" to stop the search.

Uninstalling the Windows dedicated software

NOTE

Normally, there is no need to uninstall the dedicated software. Follow these procedures if a problem occurs or you no longer intend to use the unit with the computer.


1. Open the "Uninstall or change a program" screen using the procedures for the operating system being used (Windows 10).
2. Select "TASCAM Portacapture Series x.xx" from the list, and double-click it.
3. Then, follow the instructions that appear on the screen.

Opening the settings application

Follow the procedures below to open the settings application.

- From the "Start" menu select "Portacapture Settings Panel" under "TASCAM".

Settings application overview




Input latency

You can adjust the input latency of audio input and output signals transferred between the unit and the computer. Smaller values result in less audio signal delay, but require high-speed processing by the computer. If the processing cannot keep up, for example, due to other system operations, clicking and popping noises might occur and the audio signal might even drop out. Increasing the value will stabilize operation and suppress negative effects on audio signals, but the delay in audio signal transfer between the unit and the computer will increase. You can adjust the amount of latency for this unit according to your use conditions.

Setting Sound Properties

1. Open the “Sound” screen using the procedures for the operating system being used (Windows 10).
2. On the “Playback” page, right-click “Portacapture X6” or “Portacapture X8” and click “Set as Default Device” in the pop-up menu that appears.

When you do this, the green check mark appears next to the selected device.



NOTE


Set the default device according to the ASIO device being used on the "Recording" tab in the same manner as on the "Playback" tab.

After completing the setting, click the "OK" button.

NOTE

- you change the setting while Windows Media Player is running, the software will not recognize that the device has been changed. In this case, restart Windows Media Player.
- if you still cannot hear sound after making the settings and completing the procedures above, restart the computer.
- If you make this setting, sound will be output through this unit, but no sound will be output from the computer's speakers or headphone jack.

Documents / Resources

	<p>TASCAM Portacapture X8 High Resolution Multi Track Handheld Recorder [pdf] User Guide</p> <p>Portacapture X8, Portacapture X6, Portacapture X8 High Resolution Multi Track Handheld Recorder, High Resolution Multi Track Handheld Recorder, Multi Track Handheld Recorder, Handheld Recorder, Recorder</p>
---	--