




# **TECH8 USA TECH8 Mouse Mover Device User Guide**

Home » TECH8 USA » TECH8 USA TECH8 Mouse Mover Device User Guide

# Contents

- 1 TECH8 USA TECH8 Mouse Mover
- Device
- 2 Product Usage Instructions
- **3 GET STARTED**
- **4 OPTIONAL SETTINGS**
- 5 FAQs
- 6 Documents / Resources
  - 6.1 References
- **7 Related Posts**



**TECH8 USA TECH8 Mouse Mover Device** 



# **Specifications**

- Device Name: Mouse Mover
- Compatibility: Works with most popular PC optical, laser, wired, and wireless mouse types
- Power Source: Draws 5V power from a USB port or can be plugged into a phone charger
- Features: Prevents computer sleep mode by randomly moving the optical mouse
- Warranty: 30-day Money Back Guarantee, 1-year Limited Warranty
- Origin: Invented, Patented, Designed, Engineered, and Packaged in the USA

# **Product Usage Instructions**

- 1. Step 1: Connect the Mouse Mover to a 5V USB power source or the USB port on your PC.
- 2. Step 2: Place the mouse on the spinning disc, ensuring the mouse sensor is on the disc.

# **Optional Settings**

- Glow Ring: Press and Hold the Power button to cycle through Blue, Red, Green, and OFF.
- Timer (Hourglass icon): Press the Timer button to cycle between 1 Hour (Blue), 2 Hours (Red), or Non-Stop (Green, default).

#### **FAQs**

## 1. Q: What does the Mouse Mover do?

• **A:** The Mouse Mover prevents your computer from going to sleep by randomly moving your optical mouse. It prevents Away status on the Team Lync, Zoom, Skype, WebEx, etc.

# 2. Q: Does it work on all mouse types?

• A: Yes! Mouse Mover has been tested on the most popular PC optical, laser, wired, and wireless mouse. Also, it can accommodate most sizes.

#### 3. Q: Is there any software to install?

• A: No, there is no software to install. The Mouse Mover only draws 5V power from the USB port of your PC. Alternatively, it can be plugged into a phone charger.

#### 4. Q: How often will my mouse move?

- A: The device will move the cursor randomly with short, long, left, and right spins, with varying speeds and pauses between each spin.
- This makes it truly undetectable.

## 5. Q: Can this be detected by my IT?

• A: No. Tech8 Mouse Mover is a mechanical device that imitates a human physically moving the mouse. There are no software or drivers to install.

# 6. Q: What about Returns and Warranty?

• A: You are covered with a 30-day Money Back and a 1-year Limited Warranty. Contact us at <a href="mailto:help@tech8usa.com">help@tech8usa.com</a> with your order number.

# 7. Q: Is Tech8 USA an American company?

• A: Yes, we are an American company created, set up, and incorporated in Austin, and take pride in our roots and heritage.

#### **GET STARTED**

- 1. Step 1 Connect the mouse mover to a 5V USB power source or the USB port on your PC.
- 2. Step 2 Place the mouse on the spinning disc, ensuring the mouse sensor is on the disc.



## **OPTIONAL SETTINGS**

- Glow Ring: Press and Hold the Power button to cycle through Blue, Red, Green, and OFF.
- Activity (Arrow icon): Press the Activity button to increase/ decrease random pauses between each disc spin.

# **Choose from 3 levels:**

- High (Red): 10-12 seconds.
- Medium (Blue): 30-40 seconds. Default.
- Low (Green): 50-60 seconds.
- The last used Activity setting is saved to the device's memory
- Timer (Hourglass icon): Need to turn the Mouse Mover OFF after a certain time automatically?
- Press the Timer button to cycle between 1 Hour (Blue), 2 Hours (Red), or Non-Stop (Green, default).

#### 1. What does the Mouse Mover do?

• The Mouse Mover prevents your computer from going to sleep by randomly moving your optical mouse. It prevents" Away" status on Team Lync, Zoom, Skype, WebEx, etc.

#### 2. Does it work on all mouse types?

Yes! Mouse Mover has been tested on the most popular PC optical, laser, wired, and wireless mouse.
 Also, it can accommodate most sizes.

## 3. Is there any software to install?

No, there is no software to install. The Mouse Mover only draws 5V power from the USB port of your PC.
 Alternatively, it can be plugged into a phone charger.

# 4. How often will my mouse move?

• The device will move the cursor randomly with short, long, left and right spins, with varying speeds and pauses between each spin. This makes it truly undetectable.

# 5. Can this be detected by my IT?

• No. Tech8 Mouse Mover is a "mechanical device" that imitates a human physically moving the mouse. There are no software or drivers to install.

# 6. What about Returns and Warranty?

Simple! You are covered with a 30-day Money Back, and 1 year Limited Warranty. Contact us at help@tech8usa.com with your order number.

# 7. Is Tech8 USA an American company?

• Yes, we are an American company created, set up, and incorporated in Austin, and take pride in our roots and heritage.

#### **NEED HELP?**

Resolution in minutes. Our Guarantee.

• Email <a href="help@tech8usa.com">help@tech8usa.com</a> or just scan the QR code on the right to chat with our support team for all Support and Replacement requests.

## Chat



## Thank You, Amy!

- Amy with Tech8 customer services was amazing.
- She went above and beyond to address my concerns and resolve the issue quickly!
- THANK YOU for supporting our small American business.
- Your purchase plays a vital role in supporting our economy.
- Help us in our mission by giving us a thumbs up on Amazon. Just scan the QR code below.



- It was always such a hassle to have my computer go to sleep.
- Not anymore! I should have gotten this sooner.
- www.tech8usa.com

# **Documents / Resources**



TECH8 USA TECH8 Mouse Mover Device [pdf] User Guide
TECH8 Mouse Mover Device, TECH8, Mouse Mover Device, Mover Device, Device

# References

- <u>O Tech8 USA Mouse Mover</u>
- User Manual

## Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.