


Drawer Dresser

Instruction Manual




1 Component List

A X1




Side Frame

B X1




Middle Frame

C X1




Side Frame

D X2




Cross Tube

E X6




Drawer

F X6




Base Board for
Drawer

G X2



Reinforcement Bar


H X1



Top Board


2 Supplied Parts and Hardware

1 X12



Bolts
M6×25mm

2 X6



Bolts
M5×10mm

3 X6



Drawer Handle

4 X4



Adjusting Foot
M6×14mm

5 X1



Wrench
M4

6 X2



Expansion Tube

7 X2



Bolts
M4×60mm

8 X1




Wrench
M4


9 X12



Bolts
M4×12mm



Step 1




As shown in the figure, use bolts (1) * 6 and a wrench (5) to secure the side frame and intermediate frame (A&B&C) to the back of the top plate (H).

NOTE:


1. Place a blanket under the top plate to avoid scratches or damage.
2. The side frame (A&B&C) faces in the same direction, with the holes facing forward.

Step 2




As shown in the figure, install the Cross tube **(D)** * **2** onto the frame **(A&B&C)** using bolts **(1)** * **6** and a wrench **(5)**.

Step 3




As shown in the figure, use bolts **(2)** * **6** and wrenches **(5)** to secure the reinforcement bars **(G)** * **2** to the frame **(A&B&C)**.

Step 4




Install the adjustment feet **(4) * 4** onto the side frame **(A&C)** as shown in the figure.

Step 5




As shown in the picture, flip the cabinet over with the back facing back.

Step 6



As shown in the figure, place the bottom plate **(F)** of the drawer into the expansion drawer **(E)** and install the drawer handle **(3)** with bolts **(9) * 2**. Install six drawers in the same way.

Step 7



As shown in the figure, place the installed drawers **(E) * 6** into the frame in sequence. If you need to fix the drawer trimmer to the wall, use an electric drill to drill holes on the wall, then insert an expansion tube **(6) * 2**, and secure the drawer trimmer with bolts **(7) * 2**.

