




NOTE:

This brochure contains IMPORTANT safety info. Please read and keep for future reference.

MAINTAINANCE AND WARNING


- 1.Keep furniture away from heat sources.
- 2.Do not clean furniture with harsh cleaner or polishes. Do not use detergents, solvents, abrasives, spray packs or leather cleaner. Use non-color mild soa with warm water to clean spills(Mix 1:10 soap to water).
- 3.Do not place furniture under direct sunlight, material will possibly fade over time.
- 4.Do not use on site dry cleaning machine. Children should not climb or jump on the furniture.
- 5.Do not write on furniture that is not protected by a padded barrier.
- 6.Not for commercial use, only for residential use.
















Weight Limitation

100 LBS




EXPLOSIVE VIEW





PARTS LIST 1

A x1 	B x1 	C x1 	D x1 
E x1 	F x1 	G x1 	H x1 
I x1 	J x4 	K x1 	L x1 
M x1 	N x1 	O x1 	P x1 

HARDWARE LIST

#1	x1	#2	x2	#3	x1	#4	x15	#5	x1	#6	x16
											
Ø5/32*30MM		Ø3*15MM				Ø4*25MM				Ø3*15MM	
#7	x4	#8	x10	#9	x4	#10	x2	#11	x2	#12	x1
											
Ø1/4*40MM		Ø8*30MM									
#13	x2	#14	x2								
											
Ø4*38MM		Ø3*20MM									

TOOL LIST

#15	x1	#16	x1
			
M4		Not including	


HARDWARE SPARE LIST


#7	x1	#8	x1	#4	x1	#6	x1
							
Ø1/4*40MM		Ø8*30MM		Ø4*25MM		Ø3*15MM	

ASSEMBLY INSTRUCTIONS

STEP-1

1. Install leg (J) on of bottom panel (B), ensure the corresponding holes are aligned and fix with, wood dowel #8 and using bolt #7, then tighten the screw with an Allen key #15.




#8	x8	#7	x4	#15	x1
					
Ø8*30MM		Ø6*40MM		M4	

ASSEMBLY INSTRUCTIONS

STEP-2


1.Insert panel (F&H) into side panel (C&D), make sure all holes aligned and then pull panel (F&H) forward fix with as picture show.



ASSEMBLY INSTRUCTIONS

STEP-3


1. Insert part (G) into part (C&D&H), make sure all holes align aligned, wood dowel #8 and fix, with screw #4 then tighten the screw with an screwdriver #16.



ASSEMBLY INSTRUCTIONS

STEP-4


1.Insert panel (C&D) into part (B), make sure all holes aligned and then pull panel (C&D) forward fix with as picture show.




ASSEMBLY INSTRUCTIONS

STEP-5

1.Insert part (I) into the preassembled step 4, make sure all holes aligned and use screw #4 to attach them, tighten screw #4 with screwdriver #16.






#4	x4	#16	x1
			
Ø4*25MM		Not including	

ASSEMBLY INSTRUCTIONS

STEP-6

1.Insert part #5 into the preassembled step 5, make sure all holes aligned and use screw #2 to attach them, tighten screw #2 with screwdriver #16.




#5	x1	#2	x2	#16	x1
					
		Ø3*15MM		Not including	

ASSEMBLY INSTRUCTIONS

STEP-7


1.Insert panel (C&D) into side panel (A), make sure all holes aligned and then pull panel (C&D) forward fix with as picture show.




ASSEMBLY INSTRUCTIONS

STEP-8






1.Insert back panel (K) into the groove of preassembled step 7 back, make sure all holes aligned and use screw #6 to attach them, tighten screw #6 with screwdriver #16.



#6	x16	#16	x1
			
Ø3*15MM		Not including	

ASSEMBLY INSTRUCTIONS




STEP-9



ASSEMBLY INSTRUCTIONS

STEP-10

1.Insert part (E) into part (C&D), insert part #9 into the preassembled step 9, make sure all holes aligned and fix.




ASSEMBLY INSTRUCTIONS


STEP-11



1. Connect part (M&N) to part (L) using screw #4 and tighten it with screwdriver #16.
2. Slide in the part (O) into the groove in part (M&N). Make sure they are also in groove in part (L).

1:



2:




#4	x4	#16	x1
			
Ø4*25MM		Not including	

ASSEMBLY INSTRUCTIONS


STEP-12

1. Connect the (P) and (M&N) using screw #4, and tighten it with screwdriver #16.
2. Install handle #3 to panel (P) using bolt #1 and tighten it with screwdriver #16.





ASSEMBLY INSTRUCTIONS


STEP-13



Attention: When installing the drawer, slide the steel ball slide rail of side panel to the most front as picture show.




Schematic diagram of slide rail disassembly




ASSEMBLY INSTRUCTIONS

STEP-14



Use screw #14 to attach plastic bracket #11 to panel (A), make sure all holes aligned and tighten screw #14 with screwdriver #16.




#11	x1	#14	x2	#16	x1
					
		Ø3*20MM		Not including	

ASSEMBLY INSTRUCTIONS

STEP-15


#11	x1	#10	x2	#13	x2	#16	x1
							
				Ø4*38MM		Not including	

1. Mark the position on the wall, that corresponds to the location of bracket #11 on the panel A. Drill and insert the expandable screw #10 by hammer.
2. Assemble the bracket #11 to the wall. Align the hole in the bracket #11 with the expandable screw #10, use screw #13 to attach it, tighten screw #13 with screwdriver #16.



STEP-16

3. Let the plastic belt #12 pass through bracket #11 and pull tightly.



WARRANTY

1. We strive to offer high-quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed.
2. We provide 30 days warranty starting from the time you receive the item. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive.
3. Replacement parts by purchasing them with our company if they are available.