


ASSEMBLY INSTRUCTIONS


BATH VANITY-CABINET






Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware.


Compare with the parts list to be sure all parts are present.

DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED



* Use of power tool to assemble this product will invalidate any claim and damage this product making unsafe !!!
* Please assemble on a clean soft surface to avoid damage.



Tools Required



(Not included)



(Not included)

IMPORTANT:
PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY

PLEASE DO NOT RETURN TO STORE



**Please do not return this product to the retailer!!
We are able to assist you in ANY way**

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.







Before Installation

Important – Please read these instructions fully before starting assembly


Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.

- We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area, small parts could choke if swallowed.
- Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

Cam Lock Assembly Instructions

	Insert Cam Bolt into hole as shown in diagram A.
	Make sure not to insert the Cam Bolt: Too deep as shown in figure B as this will cause the Cam Lock to be misaligned and unable to interlock properly.
	Also avoid inserting the Cam Bolt too close to the surface of the hole as shown in figure C, as this will cause the Cam Lock to be too loose, and not interlock properly.
	Connect the panels together.
	Insert the Cam Lock so the side opening fits over the head of the Cam Bolt.
	To tighten the Cam Lock, turn it clockwise on half a turn with a flat screwdriver. <i>*Do not use an automatic screwdriver as it may bend or break if too much power is imposed.</i>


Detail View



Identifying the Hardware-Identify the hardware using the illustrations below.


Part Lists N710P195628

1




Side Panel (L) - 1pc

2




Side Panel (R) - 1pc

3




Mid Panel - 1pc

4




Top Front Crossbar - 1pc

5




Side Front Crossbar(L) - 1pc

6




Side Front Crossbar(R) - 1pc

7




Fake Drawer - 1pc

8




Mid Front Crossbar - 1pc

9




Bottom Front Crossbar - 1pc

10




Bottom Frame - 1pc

11



Top Rear Crossbar - 1pc

13




Side Rear Crossbar (L) - 1pc

14



Side Rear Crossbar (R) - 1pc


15



Side Mid Crossbar (L) - 1pc


Part Lists N710P195628

16




Side Mid Crossbar (R)- 1pc

17




Mid Rear Crossbar - 1pc

18




Bottom Rear Crossbar - 1pc

19




Adjustable Shelf - 2pcs

20




Door Cabinet (L) - 1pc

21




Door Cabinet (R) - 1pc

22




Drawer Face - 2pcs

23




Side Drawer Panel (L) - 2pcs

24




Side Drawer Panel (L) - 2pcs

25




Rear Drawer Panel - 2pcs

26





















Bottom Panel - 2pcs




Sink - 1pc

Hardware Lists - N710P195628

A  $\varnothing 8 \times 20 \text{mm}$ Wood dowel (35pcs)	B  $\varnothing 6 \times 32 \text{mm}$ Three in one bolts (35pcs)	C  $\varnothing 14.5 \times 9.5 \text{mm}$ Three in one locks (35pcs)
D  $\varnothing 8 \times \varnothing 4 \times 25 \text{mm}$ Round head screw (10pcs)	E  Damping hinge (2sets)	F  $\varnothing 13 \times \varnothing 1/4 \times 30 \text{mm}$ Hex-Head bolt (8pcs)
G  K4mm Allen key (1pc)	H  Shelf Pin (8pcs)	I  $\varnothing 6 \times \varnothing 3 \times 12 \text{mm}$ Round head screw (10pcs)
J  Handle(16pcs)	K1  $\varnothing 5/32 \times 19 \text{mm}$ Handle screw (12pcs)	K2  $\varnothing 5/32 \times 15 \text{mm}$ Handle screw (4pcs)
L  45*12*1mm 45*17*14mm Plastic Door Magnet (2sets)	M  $\varnothing 6 \times \varnothing 3 \times 15 \text{mm}$ Flat head screw (8pcs)	N  $\varnothing 10 \times 10 \text{mm}$ Plastic Canopy (8pcs)
O  $\varnothing 8 \times \varnothing 4 \times 50 \text{mm}$ Round head screw (8pcs)	P  Anti fall Hardware (2sets)	12  Support Piece (4pcs)

STEP: 1



D



8PCS

L



2PCS

M













4PCS

STEP: 2

B



15PCS




STEP: 3


B



12PCS



STEP: 4



C



2PCS

A



2PCS

I




2PCS

(1)

(2)

(3)

STEP: 5



C




4PCS

A



8PCS

STEP: 6



C




1 PC

A



1 PC

STEP: 7



C




4PCS

A



4PCS

STEP: 8



C




2PCS

A




2PCS

STEP: 9



C




4PCS

A




5PCS

F



2PCS

STEP: 10



C




4PCS

A



7PCS


F




6PCS

STEP: 11


D



2PCS



STEP: 12



C





6PCS

A




6PCS

STEP: 13




E	
4PCS	
E	
8PCS	
L	
2PCS	
M	
4PCS	

STEP: 14




E



16PCS

J




12PCS

K1





12PCS





Use the screws to adjust up or down

Use the screws to permanent



Use the screws to adjust left or right

Use the screws to adjust in or out




STEP: 15

H



8PCS




STEP: 16



I











8PCS




STEP: 17





B	J	K2
		
8PCS	4PCS	4PCS
C	N	O
		
8PCS	8PCS	8PCS



STEP: 18




STEP: 19





STEP: 20

Install the sink on the cabinet with glue.
Let stand for 24 hours




*Silicone glue is not included in the package to comply with safety regulations in certain shipping conditions.

STEP: 21



HINGE ADJUSTMENTS




① Sideways / Tilt adjustment

Turn the screw

clockwise to move the door further away from the side of the cabinet

anticlockwise to move the door closer to the side of the cabinet




② ④ Height adjustment

While supporting the weight of the door, turn the screws

clockwise to move the door up

anticlockwise to move the door down



③ Forward and back adjustment

If the gap between the back of the door and the cabinet is too small, and the door may not close fully. Turn the screw

clockwise to decrease the gap between the door and the cabinet

anticlockwise to increase the gap between the door and the cabinet

