

ROLL-A-SHADE RASCPORMVER.4 Contract Plus Open Roll Installation Guide

Home » ROLL-A-SHADE » ROLL-A-SHADE RASCPORMVER.4 Contract Plus Open Roll Installation Guide 🖺



ROLL-A-SHADE RASCPORMVER.4 Contract Plus Open Roll



Contents

- **1 HARDWARE INCLUDED**
- **2 TOOLS REQUIRED**
- **3 INSIDE OR OUTSIDE APPLICATION**
- **4 MOUNTING LOCATION**
- **5 SCREW INSTALLATION**
- **6 ALIGNMENT**
- **7 SHADE PIN END INSTALLATION**
- **8 MOTOR END INSTALLATION**
- **9 LOCK RING INSTALLATION**
- **10 PLUG IN MOTOR**
- 11 SHADE ADJUSTING (IF

NECESSARY)


- **12 ADJUSTING LIMITS (IF NECESSARY)**
- **13 Customer Support**
- 14 Documents / Resources
 - 14.1 References
- **15 Related Posts**

HARDWARE INCLUDED


• Shade + Motor




Motor Bracket




Motor Bracket Idler End



• Wall Switch




• Switch Box



• #14 Screw




• Screws



• Zip Ties




• Wire Tie Pads




TOOLS REQUIRED

• 3/8" Hex Head




Phillips Head



• 1/8" Drill Bit



• Drill




INSIDE OR OUTSIDE APPLICATION

NOTE: ALL SHADES MAY BE PRE-PROGRAMMED TO SENSORS, REMOTES, AND/OR WALL SWITCHES UPON ARRIVAL



MOUNTING LOCATION

Place your first bracket in its mounting location and mark the screw holes. Place your second bracket in its mounting location and repeat the process.



SCREW INSTALLATION

Next, pre-drill your screw holes using a 1/8" drill bit. Install the brackets with the provided screws using the 1/4" hex head driver.




ALIGNMENT

Check to make sure your brackets are level and aligned.




SHADE PIN END INSTALLATION

Swivel ball bearing to align with idler shaft for easy installation. Press idler shaft all the way to the bracket.



MOTOR END INSTALLATION

Remove locking ring. Lineup to motor bracket. Push motor into motor bracket.



LOCK RING INSTALLATION

Add locking ring to motor bracket. Check motor is secured correctly.





PLUG IN MOTOR

- Run motor power cord to nearest power outlet.
- Install wire tie pads and secure with zip ties to hold wire down.
- The path of the wire should be parallel with mullions and/or drop ceiling tiles ensuring the cable is neatly organized.
- Any modifications to the power cable should be done by a certified electrician to meet your city/state code requirements.



SHADE ADJUSTING (IF NECESSARY)

- Roll shade up and down to confirm hembar is level and material rolls up straight on center tube.
- If the hembar is not level, lower shade until you see the metal tube.
- Add layers of masking tape to the metal tube to the end that is too low until hembar is straight.
- If the material tracks to one side, lower shade until you see the metal tube.
- Add layers of masking tape to the metal tube to the end that is opposite the direction of tracking, until shade rolls up straight.



ADJUSTING LIMITS (IF NECESSARY)

See programming instructions based on the motor used for your application.

Customer Support

Rollashade.com info@rollashade.com

951.245.5077 © Copyright Roll A Shade® Inc. All Rights Reserved.





Documents / Resources



ROLL-A-SHADE RASCPORMVER.4 Contract Plus Open Roll [pdf] Installation Guide RASCPORMVER.4 Contract Plus Open Roll, RASCPORMVER.4, Contract Plus Open Roll, Open Roll

References

- Q Roll A Shade Commercial Window Shade Solutions
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.