

Altronix T1CVK3F4 4 Door Kit with Fused Outputs Installation Guide

Home » Altronix » Altronix T1CVK3F4 4 Door Kit with Fused Outputs Installation Guide 1



More than just power.

Access & Power Integration
Altronix/CDVI Kits
T1CVK3F4 4-Door Kit with Fused Outputs
Installation Guide

Contents

- 1 T1CVK3F4 4 Door Kit with Fused Outputs
- 2 Overview
- **3 Configuration Chart**
- 4 Installation Instructions
- **5 Features**
- 6 Documents / Resources
 - **6.1 References**
- 7 Related Posts

T1CVK3F4 4 Door Kit with Fused Outputs

Models Include:

T1CVK3F4

4 Door Kit with Fused Outputs

The fully assembled kit includes:

- Trove1 enclosure with TC1 Altronix/CDVI backplane
- One (1) eFlow6NB Power Supply/Charger

• One (1) ACM4 - Fused Access Power Controller

T2CVK7F10

10 Door Kit with Fused Outputs

The fully assembled kit includes:

- Trove2 enclosure with TCV2 Altronix/CDVI backplane
- One (1) eFlow104NB Power Supply/Charger
- One (1) ACM8 Fused Access Control Module
- One (1) ACM4 Fused Access Control Module
- One (1) PD8UL Fused Power Distribution Module

T2CVK33F10

10 Door Kit with PTC Outputs

The fully assembled kit includes:

- Trove2 enclosure with TCV2 Altronix/CDVI backplane
- Two (2) eFlow6NB Power Supply/Chargers
- Two (2) MOM5 PTC Power Distribution Modules with Fire Alarm Interface

T2CVK33F10Q

10 Door Kit with PTC Outputs

The fully assembled kit includes:

- Trove2 enclosure with TCV2 Altronix/CDVI backplane
- One (1) LINQ2 Network Communication Module
- Two (2) eFlow6NB Power Supply/Chargers
- Two (2) MOM5 PTC Power Distribution Modules with Fire Alarm Interface

T3CVK77F20

20 Door Kit with Fused Outputs

The fully assembled kit includes:

- Trove3 enclosure with TCV3 Altronix/CDVI backplane
- Two (2) eFlow104NB Power Supply/Chargers
- Two (2) ACM8 Fused Access Control Modules
- One (1) ACM4 Fused Access Control Module
- One (1) PD8UL Fused Power Distribution Module
- One (1) RSB2 Rocker Switch Bracket with Two (2) Rocker Switches (Not evaluated by UL

All components of this Trove kit are UL Listed as sub-assemblies.

Please refer to the included corresponding Sub-Assembly Installation Guides for further information. All registered trademarks are the property of their respective owners.

Rev. TCVK_042619	specify of anom respective connects.	
Installing Company:	Service Rep. Name:	
Address:	 Phone #:	

Overview

Altronix Trove CDVI kits are pre-assembled and consist of Trove enclosures/backplanes with factory-installed Altronix power supply/chargers and sub-assemblies. These kits also accommodate various combinations of CDVI Atrium A22K/A22NB/ADH10 boards for up to twenty (20) doors in a single enclosure.


Configuration Chart

		Supply Board use Rating	/ Board Rating	(A)	Maximum Supply Current for Main and Aux. Outputs on Power Supply board,		nal DC Voltage Supply [Aux]	-Secure or Outputs	Fuse or PTC Outputs	Board	Output Fuse	Output Fuse	d Rating	
Altronix Model Number	Networkable	Power Supply Bos Input Fuse Rating	Power Supply Board Battery Fuse Rating	120VAC 60Hz Input Current	MOM5 power distribution module or ACM4/ACM8 Access Power Controllers' outputs	Output Range (VDC)	Output Range (VDC)	Fail-Safe/Fail-Secure or Dry Form "C" Outputs	Additional Fuse or Protected Outputs	ACM4/ACM8 Board Input Fuse Rating	ACM4 Board Rating	ACM8 Board Rating	PD8UL Board Output Fuse F	MOM5 Output PTC Rating
T1CVK3F4	-1	5A/250V	15A/ 32V	3.5	24VDC @ 5.7A	20.17- 26.4	20.28- 26.4	4	-	10A/ 250V	3A/ 32V	-	-	-
T2CVK7F10	_	6.3A/250V	15A/ 32V	4.5	24VDC @ 9.4A	20.17- 26.4	20.28- 26.4	12	8	10A/ 250V	2.5A/ 250V	2.5A/ 250V	3.5A/ 250V	-
T2CVK33F10		5A/250V	15A/ 32V	7.0	24VDC @ 5.9A + 24VDC @ 5.9A	20.17- 26.4	20.28- 26.4	_	10	12	_	_	<u>-</u> -	2A/ 250V
T2CVK33F10Q	~	5A/250V	15A/ 32V	7.0	24VDC @ 5.9A + 24VDC @ 5.9A	20.17- 26.4	20.28- 26.4	_	10	12 <u>—</u> 13	_	_	<u>-</u>	2A/ 250V
T3CVK77F20	-	b 3/1/25(11/	15A/ 32V	9.0	24VDC @ 9.4A +	20.17-26.4	20.28-26.4	20	8	10A/	3A/	2.5A/	3.5A/	_
			32V		24VDC @ 9.7A	9.7- 13.2	10.03- 13.2			250V	32V	250V	250V	

Installation Instructions

Wiring methods shall be in accordance with the National Electrical Code/NFPA 70/ANSI, and with all local codes and authorities having jurisdiction. The product is intended for indoor use only.

- 1. Remove the backplane from the enclosure. Do not discard hardware. If your application requires a raised backplane, re-mount it using metal spacers and screws (provided).
- 2. Mark and predrill holes in the wall to line up with the top three keyholes in the enclosure. Install two/three upper fasteners and screws in the wall with the screw heads protruding. Place the enclosure's upper keyholes over the two/three upper screws; level and secure. Mark the position of the lower two/three holes. Remove the enclosure. Drill the lower holes and install the fasteners. Place the enclosure's upper keyholes over the upper screws. Install the lower screws and make sure to tighten all screws.
- 3. Mount included UL Listed tamper switch(es) (Altronix Model TS112 or equivalent) in the desired location, opposite hinge. Slide the tamper switch bracket onto the edge of the enclosure approximately 2" from the right side (Fig. 1, pg. 2). Connect the tamper switch wiring to the Access Control Panel input or the appropriate UL Listed reporting device. To activate the alarm signal open the door of the enclosure.
- 4. Mount CDVI A22K/A22NB/ADH10 boards to the backplane, refer to pages 3-6.
- 5. Refer to the eFlow Power Supply/Charger Installation Guide (eFlow6NB, eFlow102NB, eFlow104NB) and corresponding Sub-Assembly Installation Guide (LINQ2, ACM4, ACM8, PD8UL, MOM5) for further installation instructions.




T1CVK3F4: Configuration of CDVI A22K/A22NB/ADH10 Boards

- 1. Fasten spacers (supplied with A22K/A22NB/ADH10) to CDVI A22K/A22NB/ADH10 board (Fig. 2b, pg. 3).
- 2. Mount CDVI A22K/A22NB/ADH10 boards into the correct positions (Fig. 2, pg. 3) by positioning spacers over appropriate holes on the backplane and depressing down on board to secure the spacer to the backplane (Fig. 2a, 2b, pg. 3).

Note: CDVI A22K/A22NB/ADH10 boards have one (1) RJ45 jack each.

Please make sure that they are mounted correctly, as shown in Fig. 2 below.

3. Fasten the backplane to the Trove2 enclosure utilizing pan head screws (provided).




T2CVK7F10: Configuration of CDVI A22K/A22NB/ADH10 Boards

- 1. Fasten spacers (supplied with A22K/A22NB/ADH10) to CDVI A22K/A22NB/ADH10 board (Fig. 3b, pg. 4).
- 2. Mount CDVI A22K/A22NB/ADH10 boards into the correct positions (Fig. 3, pg. 4) by positioning spacers over appropriate holes on the backplane and depressing down on board to secure the spacer to the backplane (Fig. 3a, 3b, pg. 4).

Note: CDVI A22K/A22NB/ADH10 boards have one (1) RJ45 jack each.

Please make sure that they are mounted correctly, as shown in Fig. 3 below.

3. Fasten the backplane to the Trove2 enclosure utilizing pan head screws (provided).




T2CVK33F10 and T2CVK33F10Q: Configuration of CDVI A22K/A22NB/ADH10 Boards

- 1. Fasten spacers (supplied with A22K/A22NB/ADH10) to CDVI A22K/A22NB/ADH10 board (Fig. 4b, pg. 5).
- 2. Mount CDVI A22K/A22NB/ADH10 boards into the correct positions (Fig. 4, pg. 5) by positioning spacers over appropriate holes on the backplane and depressing down on board to secure the spacer to the backplane (Fig. 4a, 4b, pg. 5).

Note: CDVI A22K/A22NB/ADH10 boards have one (1) RJ45 jack each.

Please make sure that they are mounted correctly, as shown in Fig. 4 below.

3. Fasten the backplane to the Trove2 enclosure utilizing pan head screws (provided).



T3CVK77F20: Configuration of CDVI A22K/A22NB/ADH10 Boards


- 1. Fasten spacers (supplied with A22K/A22NB/ADH10) to CDVI A22K/A22NB/ADH10 board (Fig. 5b, pg. 6).
- 2. Mount CDVI A22K/A22NB/ADH10 boards into the correct positions (Fig. 5, pg. 6) by positioning spacers over appropriate holes

on the backplane and depressing down on board to secure the spacer to the backplane (Fig. 5a, 5b, pg. 6).


Note: CDVI A22K/A22NB/ADH10 boards have one (1) RJ45 jack each.

Please make sure that they are mounted correctly, as shown in Fig. 5 below.

3. Fasten the backplane to the Trove3 enclosure utilizing pan head screws (provided).



eFlow Power Supply/Chargers can be Controlled and Monitored while Reporting Power/Diagnostics from Anywhere over the Network...




LINQ2 provides remote IP access to real-time data from eFlow power supply/chargers to help keep systems up and running at optimal levels. It facilitates fast and easy installation and set-up, minimizes system downtime, and eliminates unnecessary service calls, which helps reduce the Total Cost of Ownership (TCO) – as well as creates a new source of Recurring Monthly Revenue (RMR).


Features

- UL is Listed in the U.S. and Canada.
- Local or remote control of up to (2) two Altronix eFlow power output(s) via LAN and/or WAN.
- Monitor real-time diagnostics: DC output voltage, output current, AC & battery status/service, input trigger state change, output state change, and unit temperature.
- · Access control and user management: Restrict read/write, Restrict users to specific resources
- Two (2) integral network controlled Form "C" Relays.
- Three (3) programmable input triggers: Control relays and power supplies via external hardware sources.
- · Email and Windows Dashboard notifications
- · The event log tracks history.
- Secure Socket Layer (SSL).
- Programmable via USB or web browser includes operating software and 6 ft. USB cable.


LINQ2 Mounts Inside any Trove Enclosure



T1CVK3F4 (Trove1) Enclosure Dimensions (H x W x D approximate): 18" x 14.5" x 4.625" (457mm x 368mm x 118mm)




T2CVK7F10 and T2CVK33F10 (Trove2) Enclosure Dimensions (H x W x D approximate): 27.25° x 21.5° x 6.5° (692.2mm x 552.5mm x 165.1mm)



T3CVK77F20 (Trove3) Enclosure Dimensions (H x W x D approximate):

36.12" x 30.125" x 7.06" (917.5mm x 768.1mm x 179.3mm)



Altronix is not responsible for any typographical errors.


140 58th Street, Brooklyn, New York 11220 USA | phone: 718-567-8181 | fax: 718-567-9056

web site: www.altronix.com
e-mail: info@altronix.com
Lifetime Warranty
IITrove CDVI Kits
127U



Trove CDVI Kits Installation Guide

Documents / Resources



References

• Altronix Home

Manuals+,