Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > Raymarine /
- > Raymarine Element 9 HV Sonar/GPS User Manual

Raymarine E70534-05-NAG

Raymarine Element 9 HV Sonar/GPS User Manual

Model: E70534-05-NAG

1. Introduction

This manual provides essential instructions for the installation, operation, and maintenance of your Raymarine Element 9 HV Sonar/GPS unit. Please read this manual thoroughly before using the device to ensure proper functionality and to maximize your experience.

The Raymarine Element 9 HV series offers advanced sonar and GPS capabilities, including HyperVision 1.2 megahertz sonar technology for high-resolution DownVision, SideVision, and RealVision 3D imaging. It features a sunlight-viewable display, an integrated GPS/GNSS receiver, and a fast Quad-Core processor for efficient chart redraw and sharp 3D imaging. The LightHouse Sport Operating System is designed for ease of use, with intuitive controls and programmable keys.

2. PACKAGE CONTENTS

Verify that all items listed below are present in your product packaging:

- Raymarine Element 9 HV Display Unit
- HV-100 Transducer (if included with your specific model)
- · Trunnion bracket with mounting hardware
- Power/NMEA2000 cable
- · Documentation pack (including this manual)



Figure 1: Raymarine Element 9 HV Display Unit. This image shows the main display unit with a sonar view of the underwater environment, highlighting its user interface and physical design.

3. SETUP AND INSTALLATION

Proper installation is crucial for the optimal performance of your Element 9 HV unit. It is recommended that installation be performed by a qualified marine electronics technician.

3.1 Mounting the Display Unit

The Element 9 HV display unit can be mounted using the included trunnion bracket. Choose a location that provides clear visibility, is protected from excessive moisture, and allows for easy access to controls.

- 1. Position the trunnion bracket on the desired mounting surface.
- 2. Mark the drill holes using the bracket as a template.
- 3. Drill pilot holes appropriate for the mounting hardware.
- 4. Secure the trunnion bracket using the provided screws.
- 5. Attach the Element 9 HV display unit to the trunnion bracket and secure it with the side knobs.

3.2 Transducer Installation (HV-100)

The HV-100 transducer is designed for transom mounting. Ensure the transducer is mounted in a location free from turbulence and obstructions for best sonar performance.

· Select a mounting location on the transom that is clear of propellers, strakes, and other hull features that could

create air bubbles.

- Ensure the transducer face is submerged and parallel to the waterline when the vessel is at speed.
- Follow the specific instructions provided with the HV-100 transducer for drilling and sealing mounting holes.
- Route the transducer cable away from engine noise and other electrical interference.

3.3 Power and Network Connections

Connect the Element 9 HV to a 12V DC power source and, if applicable, to a NMEA2000 network.

- Connect the red wire from the power cable to the positive (+) terminal of your vessel's 12V DC power supply.
- Connect the black wire from the power cable to the negative (-) terminal of your vessel's 12V DC power supply.
- · Ensure all connections are secure and properly insulated.
- For NMEA2000 connectivity, connect the NMEA2000 cable to the appropriate port on the Element 9 HV and to your vessel's NMEA2000 backbone.

4. OPERATING INSTRUCTIONS

The Element 9 HV features the LightHouse Sport Operating System, designed for intuitive control.

4.1 Powering On/Off

- To power on: Press and hold the Power button (usually located on the side or front panel) until the Raymarine logo appears.
- To power off: Press and hold the Power button until the shutdown menu appears, then select "Power Off".

4.2 Basic Navigation and Menus

The Element 9 HV uses a combination of physical buttons and an intuitive menu system.

- **Directional Pad:** Use to navigate through menus and pan charts.
- · OK Button: Confirms selections.
- Menu Button: Accesses the main menu or context-sensitive menus.
- WPT (Waypoint) Button: Quickly marks your current location as a waypoint.
- Zoom In/Out (+/-) Buttons: Adjusts zoom levels on charts and sonar views.

4.3 Sonar Operation (HyperVision, DownVision, SideVision, RealVision 3D)

The Element 9 HV provides various sonar views for detailed underwater imaging.

- 1. From the home screen, select the desired sonar application (e.g., "Sonar", "DownVision", "SideVision", "3D").
- 2. Adjust gain, range, and other settings via the menu to optimize the sonar image for current conditions.
- 3. Utilize HyperVision mode for extremely high-resolution imaging of structures and fish.

4.4 Chartplotter and GPS Functions

The integrated GPS/GNSS receiver allows for precise navigation and chart plotting.

- Chart View: Displays your vessel's position on electronic charts (LightHouse NC2, Navionics, C-MAP supported).
- Waypoints: Mark and save specific locations. Use the WPT button for quick marking.
- Routes: Create and follow routes between multiple waypoints.
- Tracks: Record your vessel's path for later review.

• RealBathy / SonarCharts Live: Create custom bathymetric maps in real-time using your sonar data.

5. MAINTENANCE

Regular maintenance ensures the longevity and performance of your Element 9 HV unit.

5.1 Cleaning the Display

- Use a soft, clean, damp cloth to wipe the screen.
- For stubborn marks, use a mild glass cleaner applied to the cloth (not directly to the screen).
- · Avoid abrasive cleaners or solvents, as these can damage the screen coating.

5.2 Transducer Care

- Periodically inspect the transducer for marine growth or damage.
- Clean the transducer face with a soft brush and mild soap and water. Do not use harsh chemicals or abrasive tools.
- Ensure the transducer cable is free from kinks or damage.

5.3 Software Updates

Raymarine regularly releases software updates to improve performance and add new features. Visit the official Raymarine website for the latest software and update instructions.

6. TROUBLESHOOTING

This section addresses common issues you might encounter with your Element 9 HV unit.

Problem	Possible Cause	Solution
Unit does not power on	No power, faulty connection, blown fuse	Check power cable connections, inspect fuse in power circuit, verify battery voltage.
No sonar image	Transducer not connected, faulty transducer, air bubbles under transducer	Ensure transducer is securely connected. Check transducer for damage. Verify transducer mounting location is free from turbulence.
Inaccurate GPS position	Poor satellite reception, GPS antenna obstruction	Ensure the unit has a clear view of the sky. Check for any obstructions blocking the GPS antenna.
Screen freezing or unresponsive	Software glitch, overheating	Perform a soft reset (refer to the full manual for instructions). Ensure adequate ventilation around the unit.

If the problem persists after attempting these solutions, please contact Raymarine customer support.

7. SPECIFICATIONS

Feature	Detail
Model Name	Element 9 HV

Feature	Detail
Model Number	E70534-05-NAG
Brand	Raymarine
Screen Size	9 Inches
Display Type	LCD
Power Source	DC Power Supply (12V)
Sonar Technology	HyperVision 1.2 MHz, DownVision, SideVision, RealVision 3D, CHIRP Sonar
GPS/GNSS	Integrated Receiver
Cartography Support	Raymarine LightHouse NC2, Navionics, C-MAP
Mounting Type	Surface Mount (Trunnion Bracket)
Product Dimensions	12.05"L x 12.05"W x 15.63"H
Item Weight	9.55 Pounds
UPC	723193831649

8. WARRANTY AND SUPPORT

Raymarine products are backed by a manufacturer's warranty. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official Raymarine website.

For technical support, service, or to register your product, please visit the Raymarine support portal or contact their customer service department. Keep your model number (E70534-05-NAG) and serial number ready when contacting support.

Online Resources: www.raymarine.com/support

© 2024 Raymarine. All rights reserved.

This manual is for informational purposes only. Raymarine reserves the right to change product specifications without notice.

Related Documents - E70534-05-NAG

ELEMENT HV

Raymarine ELEMENT HV: Guida all'Installazione

Questa guida dettagliata fornisce istruzioni passo-passo per l'installazione dei display Raymarine ELEMENT HV, inclusi consigli su montaggio, cablaggio e collegamenti dei trasduttori per un'esperienza di navigazione e pesca ottimale.

Raymarine



Raymarine ELEMENT HV: Guida all'Installazione e Manuale Tecnico

Guida completa all'installazione e all'uso del sistema di navigazione Raymarine ELEMENT HV. Include specifiche tecniche, collegamenti, risoluzione problemi e accessori per chartplotter/ecoscandaglio.



Raymarine CP370 / CP470 / CP570 Installation Instructions

Comprehensive installation instructions for Raymarine CP370, CP470, and CP570 CHIRP broadband sonar modules. Learn how to plan, install, and connect these marine electronics for optimal performance.



Raymarine Dragonfly / Dragonfly 7 Installation and Operation Instructions

Comprehensive guide for installing and operating Raymarine Dragonfly and Dragonfly 7 series marine fishfinder and chart plotter combo devices, covering setup, features, and troubleshooting.



Raymarine a Series, c Series, e Series Installation and Operation Manual

This manual provides installation and operation instructions for the Raymarine a Series, c Series, and e Series multifunction displays. It covers important safety information, system integration, cabling, mounting, basic operation, data management, radar, AIS, fishfinder, and troubleshooting.



Raymarine i70s Instrument Installation & Operation Instructions

This comprehensive manual provides detailed instructions for installing and operating the Raymarine i70s multifunctional instrument display. It covers system planning, connections, transducer calibration, AIS features, troubleshooting, and technical specifications for marine navigation.