

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [OOCYOO](#) /

› [OOCYOO 100 Amp MPPT Solar Charge Controller User Manual \(Model KP60 100\)](#)

OOCYOO KP60 100

OOCYOO 100 Amp MPPT Solar Charge Controller User Manual

Model: KP60 100

1. INTRODUCTION

The OOCYOO 100 Amp MPPT Solar Charge Controller is designed to efficiently manage power flow from your solar panels to your battery bank. This manual provides essential information for safe installation, operation, and maintenance of your solar charge controller. Please read this manual thoroughly before installation and use.

2. PRODUCT OVERVIEW

2.1 Key Features

- 100 Amp MPPT Solar Charge Controller with 12V/24V/36V/48V automatic system voltage identification.
- Equipped with a blacklight LCD display for clear visibility of operational data.
- Directly displays accumulated charge in KWH, eliminating the need for external measuring instruments.
- Features two newly designed vents for enhanced convection cooling.
- Incorporates multiple safety protection functions.
- Achieves a maximum DC/DC transfer efficiency of up to 98.7%.
- Compatible with various battery types: USER (programmable for Lithium, LiFePO4, Li(NiCoMn)O2), Flooded, Sealed, and Gel batteries.
- User-programmable settings for absorption voltage, floating voltage, low voltage disconnect, and load timer.
- Built-in cooling fan activates when temperature exceeds 45°C and deactivates below 40°C, designed for extended life.
- Maximum Power Point Tracking (MPPT) rate ≥99% and conversion rate >98%.

2.2 Product Components

The following image illustrates the main components and connection points of the OOCYOO 100 Amp MPPT Solar Charge Controller.




Figure 1: Front and bottom view of the OOYCYOO MPPT Solar Charge Controller with labeled ports. Key components include the LCD display, 5S Reset button, Solar Panel terminals, Battery terminals, Load terminals, USB 5V 2A ports, Remote Temp Sensor port, RS485 Communication port, and mounting holes.

- **LCD Display:** Shows real-time system status and parameters.
- **5S Reset Button:** Used for system reset or accessing certain settings.
- **Solar Panel Terminals:** Connect to your solar panel array.
- **Battery Terminals:** Connect to your battery bank.
- **Load Terminals:** Connect to your DC loads.
- **USB 5V 2A Ports:** For charging compatible USB devices.
- **Remote Temp Sensor Port:** Connects to the included temperature sensor for accurate battery temperature compensation.
- **RS485 Communication Port:** For external communication and monitoring.
- **Mounting Holes:** For secure installation of the controller.

3. SETUP AND INSTALLATION

3.1 Safety Precautions

- Ensure all connections are tight and secure to prevent loose connections that can cause excessive heat.
- Install the controller in a well-ventilated area, away from flammable materials and direct sunlight.

- Always wear appropriate personal protective equipment (PPE) during installation.
- Disconnect all power sources (solar panels and battery) before performing any wiring or maintenance.

3.2 Mounting

Mount the controller vertically on a solid surface to allow for proper heat dissipation. Ensure there is adequate clearance around the unit for airflow. The controller dimensions are approximately 12 inches (L) x 7.8 inches (W) x 3.2 inches (H).

COMPATIBLE WITH MULTIPLE BATTERY TYPES

- AGM
- GEL
- FLOODED
- LITHIUM



AGM / Sealed, Gel, Flooded, and Lithium-Iron phosphate
(—12V/24V—12V/24V/48V) Ready

Figure 2: Illustration of the OOYCYOO MPPT Solar Charge Controller's dimensions (12.60 inches / 32 cm height, 7.87 inches / 20 cm width, 3.15 inches / 8 cm depth) and its compatibility with AGM, Gel, Flooded, and Lithium battery types.

3.3 Wiring Instructions

Follow the connection order carefully to avoid damage to the controller or other components.

- 1. Connect the Battery:** First, connect the battery to the controller's battery terminals. Ensure correct polarity (positive to positive, negative to negative). The controller will automatically detect the battery voltage (12V/24V/36V/48V).
- 2. Connect the Solar Panels:** Next, connect the solar panel array to the controller's solar panel terminals.

Ensure correct polarity.

3. **Connect the Load:** Finally, connect your DC loads to the controller's load terminals.

Disconnection Order: To disconnect the system, reverse the order: first disconnect the load, then the solar panels, and finally the battery.

Wire Gauge: Use 10 AWG wire for power terminals to ensure optimal performance and safety.

3.4 Battery Compatibility

The controller is compatible with a wide range of battery types, including:

- AGM (Absorbent Glass Mat)
- Sealed Lead-Acid
- Gel
- Flooded Lead-Acid
- Lithium (LiFePO4, Li(NiCoMn)O2) - User programmable

4. OPERATING INSTRUCTIONS

4.1 LCD Display

The integrated blacklight LCD display provides real-time information about your solar system's performance. It shows parameters such as battery voltage, charging current, load current, and accumulated energy (KWH).

4.2 System Settings

The controller allows for user-programmable settings to optimize charging for different battery types and system requirements. These settings typically include:

- **Battery Type Selection:** Choose the appropriate battery type (AGM, Gel, Flooded, Lithium, or USER-defined).
- **Absorption Voltage:** Set the voltage at which the battery is held during the absorption charging stage.
- **Floating Voltage:** Set the voltage at which the battery is maintained after absorption, to keep it fully charged.
- **Low Voltage Disconnect (LVD):** Configure the voltage threshold at which the load will be disconnected to protect the battery from over-discharge.
- **Load Timer:** Program the operating hours for the DC load output.

Refer to the detailed instructions within the controller's interface for navigating and adjusting these settings.

5. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your solar charge controller.

- **Cleaning:** Periodically clean the controller's exterior with a dry cloth. Ensure vents are free from dust and debris to maintain proper airflow.
- **Connection Checks:** Annually inspect all wiring connections for tightness and signs of corrosion. Loose connections can lead to overheating and system inefficiency.
- **Fan Operation:** The built-in cooling fan will activate automatically when the internal temperature exceeds 45°C and turn off when it drops below 40°C. Ensure the fan is not obstructed and operates freely.
- **Environmental Check:** Verify that the installation environment remains dry and free from excessive humidity.

or extreme temperatures.

6. TROUBLESHOOTING

If you encounter issues with your OOCYOO MPPT Solar Charge Controller, consider the following general troubleshooting steps:

- **No Display/Power:** Check battery connections and ensure the battery voltage is within the controller's operating range. Verify that the battery is charged.
- **No Charging:** Confirm solar panel connections and polarity. Check for sufficient sunlight and ensure solar panel voltage is above the battery voltage. Inspect for any blown fuses in the solar array.
- **Load Not Working:** Check load connections and ensure the load is not exceeding the controller's rated current. Verify that the battery voltage is above the Low Voltage Disconnect (LVD) setting.
- **Overheating:** Ensure the controller is mounted in a well-ventilated area and that its cooling vents are not obstructed. Reduce the load if consistently overheating.
- **Error Codes:** If the LCD displays an error code, consult the specific error code section of the full user manual (if available) or contact customer support.

For persistent issues, it is recommended to contact OOCYOO customer support.

7. SPECIFICATIONS

Technical specifications for the OOCYOO 100 Amp MPPT Solar Charge Controller (Model KP60 100):

100A 5000W MPPT CHARGE CONTROLLER 12V 24V 48V BATTERY



- Auto identity 12V/24V/48V DC systems voltage.
- Max Power Current: 100A, Load output current: 40A
- Max. PV Input VOC: 60V@12V battery, 112V@24V battery, 144V@48V battery
- Max. PV Input Power: 1300W@12V battery/2600W@24V battery/5000W@48V battery
- Compatible with Lead-Acid(Lithium/Sealed/Gel/Flooded) batteries
- Common-Positive Ground MPPT Controller
- A key to open and close the load
- A key to restore the factory settings
- 0 layer display-it will display all information at one time, one screen
- USB 5V charge 2A

Application

System	Solar panel		MAX.PV input power
Battery voltage	Open circuit voltage	Max.power voltage	100A
12V system	≤60V (Voc)	≤96V(Vmp)	1300W
24V system	≤96V (Voc)	≤112V(Vmp)	2600W
48V system	≤112V (Vol)	≤144V(Vmp)	5000W

Figure 3: Overview of the OOYCYOO 100A 5000W MPPT Charge Controller, highlighting its auto-identification for 12V/24V/48V DC systems, maximum power current, PV input voltage limits, and maximum PV input power for different battery systems. Also shows compatibility with various battery types and key operational features.

Parameter	Value
Rated Charge Current	100A
System Nominal Voltage	12V/24V/36V/48V DC Auto Identifying
Max. PV Open Circuit Voltage	150VDC
Max. PV Input Power (12V System)	1300W (Voc ≤96V)
Max. PV Input Power (24V System)	2600W (Voc ≤112V)
Max. PV Input Power (48V System)	5000W (Voc ≤150V)
Power Terminal Wire Gauge	10 AWG

Parameter	Value
Product Dimensions (L x W x H)	12 x 7.8 x 3.2 inches (30.5 x 19.8 x 8.1 cm)
Item Weight	8.86 pounds (4.02 kg)
Operating Temperature	40°C (104°F)
Display Type	LCD

8. SAFETY INFORMATION AND PROTECTIONS

The OOCYOO MPPT Solar Charge Controller is equipped with comprehensive protection features to ensure safe operation of your solar power system:


- PV Over Current/Power Protection
- PV Short Circuit Protection
- PV Reverse Polarity Protection
- Night Reverse Charging Protection
- Battery Reverse Polarity Protection
- Battery Over Voltage Protection
- Battery Over Discharge Protection
- Battery Overheating Protection
- Controller Overheating Protection
- Lithium Battery Low Temperature Protection
- Load Short Circuit Protection
- Load Overload Protection
- TVS High Voltage Transients Protection

9. WARRANTY AND SUPPORT

Warranty information for the OOCYOO 100 Amp MPPT Solar Charge Controller is typically provided with the product packaging or through the point of purchase. Please retain your proof of purchase for warranty claims.

For technical support, troubleshooting assistance, or inquiries regarding your product, please refer to the contact information provided by OOCYOO or your authorized dealer. This package includes a user manual in English for detailed guidance.

Related Documents - KP60 100

 OOYCYOO™ <small>MPPT Solar power generation system controller</small>	<p><u>OOYCYOO MPPT Solar Power Generation System Controller User Manual</u></p> <p>This document provides comprehensive instructions and technical specifications for the Ooycyoo MPPT Solar Power Generation System Controller. Learn about installation, parameter settings, protection features, and system wiring for optimal solar energy utilization.</p>
	<p><u>Ooycyoo MPPT 'P' Series 40A/60A Solar Charge Controller User Manual</u></p> <p>Explore the Ooycyoo MPPT 'P' Series 40A/60A Solar Charge Controller. This user manual details advanced MPPT technology, features like real-time display, USB charging, and multi-stage battery charging, along with essential safety and installation guidance for solar energy systems.</p>
 OOYCYOO™ <small>MPPT Solar power generation system controller</small>	<p><u>OOYCYOO MPPT Solar Power Generation System Controller User Manual</u></p> <p>This document provides comprehensive instructions and technical specifications for the Ooycyoo MPPT Solar Power Generation System Controller. Learn about installation, parameter settings, protection features, and system wiring for optimal solar energy utilization.</p>
	<p><u>Victron Energy SmartSolar MPPT Charge Controllers Manual</u></p> <p>User manual for Victron Energy SmartSolar MPPT charge controllers (models 75/10, 75/15, 100/15, 100/20, 100/20-48V). Covers features like Bluetooth Smart, VE.Direct, MPPT tracking, load output, battery management, installation, safety, and troubleshooting.</p>
	<p><u>MPPT Solar Charger Error Codes - Victron Energy</u></p> <p>Comprehensive guide to MPPT Solar Charger error codes from Victron Energy, detailing common issues, causes, and troubleshooting steps for SmartSolar models.</p>
	<p><u>Victron Energy SmartSolar Charge Controllers with Load Output - MPPT 75/10, 75/15, 100/15, 100/20-48V</u></p> <p>Detailed specifications and features of Victron Energy SmartSolar MPPT charge controllers, including Bluetooth connectivity, ultra-fast MPPT technology, intelligent battery management, and load output functionality. Covers models MPPT 75/10, 75/15, 100/15, and 100/20-48V.</p>