

DALY 4S 12V 100A LifePO4 BMS

DALY 4S 12V 100A LifePO4 BMS Protection Board Instruction Manual

Brand: DALY | Model: 4S 12V 100A LifePO4 BMS

1. INTRODUCTION

This manual provides essential information for the safe and effective installation, operation, and maintenance of your DALY 4S 12V 100A LifePO4 Battery Management System (BMS) Protection Board. The DALY BMS is designed to optimize the performance and extend the lifespan of your lithium battery pack by providing crucial protection features. Please read this manual thoroughly before proceeding with any installation or operation.

2. PRODUCT FEATURES

- Comprehensive Protection:** Includes overcurrent, overcharge, overdischarge, short circuit, and temperature protection to safeguard your battery pack.
- Enhanced Durability:** Features double protection through injection patent technology and a robust patent shell, making it waterproof, dustproof, shockproof, and anti-static.
- High-Quality Components:** Constructed with high-quality components for reliable performance and high acquisition accuracy.
- Optimized Battery Performance:** Maximizes and optimizes lithium battery performance, significantly extending battery lifetime.
- Easy Installation:** Designed for straightforward plug-and-unplug connections, simplifying the electrical connection between the battery pack and the BMS.

Basic protection, complete functions




Figure 1: DALY BMS Basic Protection Functions. This diagram illustrates the comprehensive protection features integrated into the BMS, ensuring battery safety and longevity.

Advanced technology-excellent strength

Moisture-proof, anti-vibration, anti-oxidation

National patented plastic injection technology improves the protective performance of BMS

National patent NO.ZL 2018 2 1243978.5



Small size,easy to install

Small size saves space and with screw holes for easy installation.


Figure 2: Advanced Technology and Compact Design. The images demonstrate the BMS's moisture-proof, anti-vibration, and anti-oxidation properties, along with its small size for easy installation.

3. SPECIFICATIONS

Parameter	Value
Product Type	LifePO4 4S 100A BMS with Balance
Product Dimensions	2.56 x 6.54 x 0.94 inches
Item Weight	13.6 ounces (260±60g)
Voltage	12 Volts
Input Voltage	12 Volts
Discharge Current	100A
Overdischarge Current	266±20A
Charging Current	100A
Overcharge Current	106±20A

Parameter	Value
Overcharge Voltage	3.75V±0.05V
Overdischarge Voltage	2.2V±0.05V
Charge Voltage	14.6V
Output Wire	7AWG/100mm
Cable	24AWG/300mm

Specification



Product: LiFePO4 4S 100A common port with balance

Discharge current: 100A

Overdischarge current: 266±20A

Charging current: 100A

Overcharge current: 106±20A

Overcharge voltage: 3.75V±0.05V

Overdischarge voltage: 2.2V±0.05V

Charge voltage: 14.6V

Model: R10K(3~10S)

Size: 123*65*14 (mm)/4.84*2.55*0.55(inch)

Output wire: 7AWG/100mm

Cable: 24AWG/300mm

Weight: 260±60g

Figure 3: DALY BMS Product Specifications. This image provides a comprehensive list of technical parameters for the BMS.

4. PACKAGE CONTENTS

The DALY 4S 12V 100A LifePO4 BMS Protection Board package includes the following items:

- 3.2V LifePO4 BMS x1
- NTC Temperature Sensor x1
- Sampling Cable x1
- Instruction Manual x1
- B-P-Cable (Gift) x1

Packing list



Product list	Quantity
① K-BMS	X 1
② Manual	X 1
③ B-P-Cable(Gift)	X 1
④ NTC	X 1
⑤ Cable	X 1



* Note: The packing list takes 24S 40A BMS as an example.

Figure 4: Package Contents. This image displays the items included in the product package.

5. SAFETY INFORMATION

Always prioritize safety when working with battery management systems and lithium battery packs. Incorrect installation or handling can lead to serious damage to the BMS, battery, or personal injury.

- Ensure all connections are correct and secure before applying power.
- Do not insert the BMS connector into the battery pack until all balance wires are properly connected and verified.
- Avoid short circuits during wiring and installation.
- Use appropriate insulated tools when working with battery components.
- If you are unsure about any step, consult a qualified professional or contact DALY customer support.

6. INSTALLATION AND WIRING

Proper installation and wiring are critical for the correct function and safety of your DALY BMS. Follow these steps carefully.

6.1 Common Wiring Errors to Avoid

Understanding common mistakes can prevent damage to your BMS and battery pack. Pay close attention to these points:

- **Incorrect Wiring Use:** Always use the wiring provided with your DALY BMS. Wires from different manufacturers may have slight differences that can lead to poor contact or socket shedding.
- **Inserting BMS Before Wiring:** Never insert the BMS connector into the battery pack before all balance wires are correctly welded to the battery. Doing so can cause internal components of the BMS to break down, leading to charging/discharging failures.
- **Virtual Welding:** Ensure all welds are solid and complete. Virtual welding (poor contact) can lead to leakage, increased burden pressure, and eventual damage to the battery or BMS.
- **Lack of Pre-Inspection:** Always inspect the battery pack wiring and verify the voltage of each string before inserting the BMS. Failure to do so can cause the BMS to burn out or damage sampling points.
- **Incorrect P-line and B-line Connection:** Ensure the P- line (total negative electrode of output/charging end) and B- line (total negative electrode of battery pack) are connected correctly. Incorrect connections can cause internal short circuits or burn out the protective plate.

Video 1: DALY BMS Wiring Common Errors. This video highlights five common mistakes made during BMS wiring and their potential consequences, emphasizing the importance of correct procedures.

6.2 Preparing Materials

Gather the necessary tools and components before starting the wiring process:

- DALY BMS Protection Board
- Balance Wires (Sampling Cable)
- NTC Temperature Sensor
- Lithium Battery Pack
- Multimeter (for voltage verification)
- Ceramic Scissors (insulated, for cutting wires)
- Soldering Iron and Solder Wire
- Double-sided tape (for securing wires)

Video 2: Preparing Materials for DALY BMS Wiring. This video demonstrates the tools and components required for the wiring process, including the BMS, battery pack, multimeter, and soldering equipment.

6.3 Determining Sampling Points

Accurately identifying the sampling points on your battery pack is crucial for correct balance wire connection. Use a multimeter to verify each point.

1. Identify the total negative electrode of the battery pack and mark it as **B-**. This will be your first sampling point.
2. Identify the connection point between the second negative and the first positive electrode. Mark this as **B1**.
3. Continue this process for all subsequent cells, marking each connection point (e.g., B2, B3, etc.) up to the total positive electrode, which will be **B+**.
4. Use a multimeter set to DC voltage to verify the voltage at each sampling point. The voltage should increase incrementally by approximately 3V (for LifePO4 cells) as you move from B- towards B+.

Video 3: DALY BMS Sampling Point Determination. This video guides you through the process of identifying and verifying

the correct sampling points on your battery pack using a multimeter.

6.4 Connecting the Balance Wires

Once the sampling points are determined and verified, proceed with connecting the balance wires:

1. Secure the BMS to the battery pack using double-sided tape in an appropriate position.
2. Identify the black wire in the sampling cable set. This is the B- wire. Connect it to the total negative terminal of the battery pack (B0).
3. Connect the first red wire (B1) to the positive terminal of the first battery string.
4. Continue connecting the red wires sequentially (B2, B3, etc.) to the positive terminals of each subsequent battery string.
5. The last red wire will connect to the total positive electrode of the battery pack (B+).
6. Ensure all connections are soldered securely.
7. After all balance wires are connected to the battery pack, carefully insert the sampling cable connector into the BMS.
8. Verify the voltage between adjacent cables starting from the header to ensure there are no wrong connections or missing connections.




Figure 5: BMS Installation and Wiring Diagram. This diagram illustrates the correct connection of balance wires and output wires to the battery pack and BMS.

Video 4: DALY BMS Wires Soldering Guide. This video provides a visual guide on how to properly solder the balance wires to the battery pack for the DALY BMS.

7. OPERATION

Once correctly installed, the DALY BMS will automatically manage your LifePO4 battery pack. It continuously monitors cell voltages, currents, and temperatures to ensure safe charging and discharging within specified limits. The BMS will intervene by cutting off charge or discharge if any parameter exceeds safe thresholds, protecting the battery from damage.

8. MAINTENANCE

To ensure the longevity and optimal performance of your DALY BMS and battery pack, consider the following maintenance tips:

- Keep the BMS and battery pack clean and free from dust and debris.
- Regularly inspect all wiring and connections for any signs of wear, corrosion, or looseness.
- Avoid exposing the BMS to extreme temperatures or direct sunlight for prolonged periods.
- Ensure adequate ventilation around the BMS, especially during high current operations.

9. TROUBLESHOOTING

If you encounter issues with your DALY BMS, consider the following basic troubleshooting steps:

- **No Charge/Discharge:** Verify all main power connections (P- and B-) and ensure the sampling cable is fully inserted and all balance wires are correctly connected to the battery. Check individual cell voltages with a multimeter.
- **Overheating:** Ensure the BMS has adequate ventilation and is not operating beyond its specified current limits.
- **Unusual Readings:** Recheck all balance wire connections and ensure they are secure and free from corrosion. Verify the multimeter is functioning correctly.

For more complex issues, refer to the detailed troubleshooting section in the full instruction manual or contact DALY customer support.

10. WARRANTY AND SUPPORT

The DALY 4S 12V 100A LifePO4 BMS Protection Board is manufactured under strict quality control and is ISO/FCC/RoHS/PSE/CE APPROVED, ensuring a quality guarantee.

DALY offers 24-hour one-on-one customer service and lifetime technical support. For any inquiries, technical assistance, or warranty claims, please contact DALY customer support through the official channels provided at the point of purchase or on the manufacturer's website.

