

sofirn LSY-AAZV-IT-20230804-27150

Sofirn Universal 4-Bay Smart Battery Charger User Manual

Model: LSY-AAZV-IT-20230804-27150

1. INTRODUCTION

Thank you for choosing the Sofirn Universal 4-Bay Smart Battery Charger. This device is designed to provide efficient and safe charging, discharging, capacity testing, and repair functions for a wide range of rechargeable batteries. Please read this manual thoroughly before use to ensure proper operation and to maximize the lifespan of your batteries and charger.



This image displays the Sofirn Universal 4-Bay Smart Battery Charger, showcasing its four independent charging slots and the integrated LCD screen. Different battery types, including Li-ion and Ni-MH, are shown inserted into the bays, illustrating the charger's versatility.

2. SAFETY INSTRUCTIONS

- Use this charger only for specified rechargeable batteries. Attempting to charge non-rechargeable batteries may lead to explosion, rupture, or leakage, causing personal injury or property damage.
- Do not disassemble, modify, or short-circuit the charger.
- Keep the charger away from water, moisture, and high temperatures.
- Ensure proper ventilation during operation. Do not cover the charger.
- Unplug the charger from the power outlet when not in use or before cleaning.
- Keep out of reach of children.
- If any abnormal conditions occur (e.g., smoke, unusual smell, excessive heat), immediately unplug the charger and discontinue use.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- Sofirn S4 Plus Fast Charger Unit
- Power Adapter
- User Manual (this document)



This image displays the items included in the product package: the S4 Plus Fast Charger unit, a power adapter, and the user manual.

4. PRODUCT OVERVIEW


Key Features:

- **4 Independent Charging Bays:** Each bay operates independently, allowing for simultaneous charging, discharging, or testing of different battery types and sizes.
- **Wide Compatibility:** Supports various battery types including Li-ion (10440, 14500, 16340, 18350, 18650, 21700, 26650, etc.) and Ni-MH/Ni-Cd (AA, AAA, C). Compatible with battery diameters 10-26mm and heights 34-75mm.
- **Fast Charging:** Capable of charging at up to 3A per slot, with a total output of 12A. A 2500mAh battery can be fully charged in approximately 1 hour.
- **Multi-functional Modes:** Offers Charge, Discharge, Capacity Test, and Repair modes.
- **LCD Display:** Provides real-time information on charge/discharge capacity, voltage, current, time, internal resistance, and temperature for each slot.
- **Intelligent Temperature Control:** Equipped with a temperature sensor to prevent overheating. Charging current automatically decreases if the battery temperature rises excessively.
- **Flexible Control:** Features a switch to toggle between Automatic and Manual operating modes for current selection.

3A each slot, 12A in total

Four slots can charge 3A at the same time, 12A in total, efficient and time-saving.

The 2500mAh battery can be fully charged in 1 hour.




This diagram highlights the charger's fast charging feature, capable of delivering up to 3A per slot simultaneously, totaling 12A. It indicates that a 2500mAh battery can be fully charged in approximately one hour.

Compatibility and Enough Space



- **Compatible with:** Battery Dia: $\phi 10-26\text{mm}$; L: 34-75mm
- **Li-ion :** 10340(RCR123)/10440/14500/16340/16650/17500/17650/17670/18350/18490/18500/18650/20700/21700/22650/26500/26650/20650/22500/25500
- **Ni-MH/Ni-Cd :** AA, AAA ,SC, C
- **Enough space for 20700/21700 batteries (button top & PCB)**

This image illustrates the wide compatibility of the charger, supporting batteries with diameters from 10-26mm and heights from 34-75mm. It lists compatible Li-ion types (e.g., 18650, 21700, 14500) and Ni-MH/Ni-Cd types (AA, AAA, C), noting sufficient space for 20700/21700 batteries.



5 small grid cycles increase

Li-ion CH2

Charge

Manual 25% 3.63v 22mΩ 1000mA 00:06h 32°C 0.48wh

Flicker

MODE DISPLAY CURRENT

Easily set the ideal charge current

- In manual mode, the default current is 500mA. It is very convenient to choose the charge or discharge current you want.
- Flexible charge current options :
250mA/500mA/1000mA/1500mA/2000mA/2500mA/3000mA

This diagram shows the charger's specialized design for efficient heat dissipation. It highlights the cooling fins and airflow paths that help manage internal temperatures during operation.



This image describes the charger's automatic intelligent temperature control system. It explains that a built-in temperature sensor automatically reduces charging current if the battery becomes too hot, ensuring safety and stability.

5. SETUP

1. Connect the power adapter to the charger's DC input port.
2. Plug the power adapter into a suitable wall outlet. The LCD screen will illuminate, indicating the charger is ready.
3. Observe the 'Manual & Auto' switch on the side of the charger. For most users, the 'Auto' mode is recommended for automatic current selection. For advanced users, switch to 'Manual' mode to set charging parameters.



This image highlights the 'Manual & Auto' switch located on the side of the charger. This switch allows users to toggle between automatic current selection and manual control over charging parameters.

6. OPERATING INSTRUCTIONS

Inserting Batteries:

Carefully insert one or more rechargeable batteries into the charging bays, ensuring correct polarity (+/-). The charger will automatically detect the battery type and display information on the LCD.

Automatic Mode:

In 'Auto' mode, the charger intelligently selects the optimal charge current based on the battery's internal resistance and type. This is the default and recommended mode for general use.



Automatically select the optimum charge current

The charger automatically selects the optimum charge current according to the battery internal resistance.

This image demonstrates the charger's intelligent function to automatically select the optimal charge current. The LCD screen shows the charger assessing the battery's internal resistance to determine the most suitable charging rate.

Manual Mode (Setting Charge Current):

If the 'Manual & Auto' switch is set to 'Manual', you can adjust the charge current:

1. After inserting a battery, press the **MODE** button to select the desired function (Charge, Discharge, Cap Test, Repair).
2. Press the **CURRENT** button to cycle through available charge current options: 250mA, 500mA (default), 1000mA, 1500mA, 2000mA, 2500mA, 3000mA.
3. The selected current will be applied to the battery in that slot. Each slot can have different settings.

5 small grid
cycles increase



Easily set the ideal charge current

- In manual mode, the default current is 500mA. It is very convenient to choose the charge or discharge current you want.
- Flexible charge current options :


250mA/500mA/1000mA/1500mA/2000mA/2500mA/3000mA

This image displays the manual mode interface on the LCD screen, allowing users to select specific charge currents. Available options include 250mA, 500mA (default), 1000mA, 1500mA, 2000mA, 2500mA, and 3000mA.

Discharge Mode:

The Discharge mode is used to analyze the actual capacity of a battery. It discharges the battery at a specified current.

1. Insert the battery.
2. Press the **MODE** button until 'Discharge' is selected.
3. The charger will begin discharging the battery. The LCD will show discharge progress and capacity.
4. For example, a 21700 5000mAh battery discharged at 1A will take approximately 5 hours.



This image illustrates the discharge mode on the charger's LCD. This function is used to analyze battery capacity by discharging at a set current, such as 1A for the first and fourth slots.

Capacity Test Mode:

This mode measures the true capacity of a battery by performing a full charge-discharge-charge cycle.

1. Insert the battery.
2. Press the **MODE** button until 'Cap Test' is selected.
3. The charger will first fully charge the battery, then fully discharge it to measure capacity, and finally recharge it to full.
4. The measured capacity will be displayed on the LCD.

Capacity test

S4 plus intelligently charge batteries fully firstly, then fully discharged to show battery capacity, and S4 plus recharge battery intelligently again to ensure you use whenever you want.



This image depicts the capacity test mode on the LCD. In this mode, the charger fully charges a battery, then fully discharges it to measure its actual capacity, and finally recharges it.

Repair Mode:

The Repair function is designed to help restore the capacity of low-voltage or older Ni-MH batteries through a series of charge/discharge cycles. This process can take an extended period.


1. Insert the battery.
2. Press the **MODE** button until 'Repair' is selected.
3. The charger will initiate a repair cycle. Monitor the battery during this process.

7. DISPLAY INFORMATION

The LCD screen provides detailed real-time data for each battery. Use the **DISPLAY** button to cycle through the information for each slot.

Display battery data in real time

Press the “display” button, you can view the battery data in the current slot and the other three batteries datum.



This image provides a comprehensive guide to the information displayed on the charger's LCD screen. It labels indicators for battery capacity status, battery type, charge mode (Auto/Manual), battery percentage, charge time, voltage, internal resistance, battery temperature, and energy in Wh.

- **Battery Capacity Status:** Visual representation of charge level.
- **Battery Type:** Indicates detected battery chemistry (e.g., Li-ion, NiMH/NiCd).
- **Charge Mode:** Shows current operating mode (Charge, Discharge, Cap Test, Repair).
- **Auto/Manual:** Indicates whether automatic or manual current selection is active.
- **Battery Percentage:** Estimated charge level.
- **Charge Time:** Duration of the current operation.
- **Voltage:** Real-time battery voltage.
- **Internal Resistance:** Displays the battery's internal resistance (mΩ).
- **Current:** Displays the charging or discharging current (mA).
- **Temperature:** Real-time battery temperature (°C).
- **Energy (Wh):** Accumulated energy transferred.

8. MAINTENANCE

- **Cleaning:** Disconnect the charger from power before cleaning. Use a soft, dry cloth to wipe the surface. Do not use abrasive cleaners or solvents.
- **Contact Points:** Periodically inspect and gently clean the battery contact points on both the charger and your batteries. Dirt or corrosion can affect charging performance.
- **Storage:** Store the charger in a cool, dry place away from direct sunlight and extreme temperatures when not in use.

9. TROUBLESHOOTING

- **Charger Not Powering On:** Ensure the power adapter is securely connected to both the charger and a working wall outlet. Check if the outlet has power.
- **Battery Not Detected/Charging:**
 - Ensure the battery is inserted with correct polarity.
 - Clean the battery terminals and the charger's contact points with a dry cloth.
 - Verify the battery is a rechargeable type and within the charger's supported specifications.
- **Inconsistent Capacity Readings:** Ensure battery terminals and charger contacts are clean. Repeat the capacity test if necessary.
- **Charger Beep Volume Too Low:** This version (V3) allows you to turn the beep and display off. Refer to the manual's specific instructions for adjusting these settings if available, or note that the volume is fixed.
- **Battery Overheating:** The charger has an automatic temperature control system that reduces current if overheating is detected. Ensure adequate ventilation around the charger. If overheating persists, discontinue use and contact support.
- **Slow Charging:** In Manual mode, ensure a higher charge current is selected if desired. In Auto mode, the charger selects an optimal current which may be lower for battery health.

10. SPECIFICATIONS

Parameter	Value
Model Number	LSY-AAZV-IT-20230804-27150
Input Voltage	5 Volts
Output Voltage	5 Volts (DC)
Max Charge Current	3A per slot
Compatible Battery Diameter	10-26mm
Compatible Battery Height	34-75mm
Supported Battery Types	Li-ion (10440, 14500, 16340, 18350, 18650, 21700, 26650, etc.), Ni-MH/Ni-Cd (AA, AAA, C)
Item Weight	1.57 pounds (0.71 Kilograms)

Package Dimensions	8.03 x 7.36 x 2.52 inches
Color	Black

11. WARRANTY AND SUPPORT

Sofirn products are manufactured to high-quality standards. For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official Sofirn website. Keep your purchase receipt as proof of purchase for warranty claims.

© 2025 Sofirn. All rights reserved.

Related Documents - LSY-AAZV-IT-20230804-27150

Sofirn SC28 Manual

The Sofirn SC28 is a rechargeable EDC flashlight with a compact design and a powerful beam. It features a built-in USB-C charging port and a durable, anodized aluminum body. The flashlight is available in multiple colors and finishes.

ANSI/NEMA FL1 Chart

Mode	Beam Distance (ft)	Beam Diameter (in)	Runtime (hrs)
High	1000	10.0	10
Med	500	5.0	20
Low	200	2.0	40

Sofirn SC28 Rechargeable EDC Flashlight User Manual

Comprehensive user manual for the Sofirn SC28 rechargeable EDC flashlight, covering specifications, operation, safety, and troubleshooting. Features 2800 lumens output and ANSI/NEMA FL1 performance data.

Sofirn SP40/SP40A Manual

The Sofirn SP40/SP40A is a high-performance LED headlamp with a powerful beam and a long runtime. It features a built-in USB-C charging port and a durable, anodized aluminum body. The headlamp is available in multiple colors and finishes.

ANSI/NEMA FL1 Chart

Mode	Beam Distance (ft)	Beam Diameter (in)	Runtime (hrs)
High	1000	10.0	10
Med	500	5.0	20
Low	200	2.0	40

Notes: The beam distance is measured at a 1000-foot range. The beam diameter is measured at the same range.

Runtime is based on a 100% battery level.

Beam diameter is measured at the same range.

Beam distance is measured at the same range.

Sofirn SP40/SP40A LED Headlamp User Manual and Specifications

Comprehensive user manual and technical specifications for the Sofirn SP40 and SP40A LED headlamps, detailing features, operation, battery information, and maintenance.

The SR23 is a high-performance floodlight featuring a powerful white light as the primary output and a secondary UV light for added versatility. The UV light allows for effective disinfection and sterilization. The floodlight also includes a built-in USB-C charging port and a durable, anodized aluminum body.




ANSI/NEMA FL1 Chart

Mode	Beam Distance (ft)	Beam Diameter (in)	Runtime (hrs)
High	1000	10.0	10
Med	500	5.0	20
Low	200	2.0	40

Mode	Beam Distance (ft)	Beam Diameter (in)	Runtime (hrs)
High	1000	10.0	10
Med	500	5.0	20
Low	200	2.0	40

Sofirn SR23 High-Performance Floodlight: Features, Specifications, and Operation

Detailed overview of the Sofirn SR23 flashlight, including its powerful white and UV light modes, ANSI/NEMA FL1 performance data, technical specifications, battery indicators, charging information, and important safety warnings.

<div><div>Sofirn SP35 Manual</div><div></div></div>	<div>Sofirn SP35 Rechargeable EDC Flashlight User Manual</div> <div>Comprehensive user manual for the Sofirn SP35 EDC flashlight, detailing specifications, operation, safety instructions, and troubleshooting. Features include USB-C recharging, 2000 lumens, stepped and ramping modes, and ATR temperature regulation.</div>
<div><div>Sofirn HS40 Manual</div><div></div></div>	<div>Sofirn HS40 Headlamp: Manual, Specifications, and Operation Guide</div> <div>A comprehensive guide to the Sofirn HS40 headlamp, detailing its specifications, safety instructions, operation modes (stepped and ramping), circuit protection, battery details, and troubleshooting tips. Learn how to use and maintain your Sofirn HS40 for optimal performance.</div>
<div><div></div></div>	<div>Sofirn IF23 PRO LED Flashlight User Manual</div> <div>Comprehensive user manual for the Sofirn IF23 PRO, an upgraded, powerful, and rechargeable LED flashlight. Includes specifications, operation instructions, battery indicators, and contact information.</div>