

Explore Scientific RDC1008

Explore Scientific Travel Alarm with Radio-Controlled Clock and Indoor Temperature Display

Model: RDC1008

INTRODUCTION

Thank you for choosing the Explore Scientific Travel Alarm Clock. This compact and versatile device is designed to provide accurate timekeeping, alarm functions, and indoor temperature readings, making it an ideal companion for travel or home use. Its radio-controlled feature ensures precise time synchronization, while the clear digital display offers easy readability.



Figure 1: Front view of the Explore Scientific Travel Alarm Clock. The display shows 12:38 PM, December 28, Saturday, and 78.5°F.

KEY FEATURES

- **Radio-Controlled Time:** Time is automatically set via DCF radio signal for precise accuracy.
- **Indoor Temperature Display:** Shows temperature in Celsius or Fahrenheit.
- **Comprehensive Display:** Clearly displays time, date, and day of the week.
- **Dual Alarms with Snooze:** Two independent alarms with a convenient snooze function.
- **Multi-Language Day Display:** Day of the week display available in 7 languages.
- **Blue Backlight:** Provides illumination for easy viewing in low light conditions.
- **Low Battery Indicator:** Alerts you when batteries need replacement.
- **Portable Design:** Compact and ideal for travel.

PACKAGE CONTENTS

Please check the package contents to ensure all items are present:

- Explore Scientific Travel Alarm Clock (RDC1008)
- 2x AAA Batteries
- Instruction Manual (this document)

SETUP

1. Battery Installation

The clock requires 2x AAA batteries for operation. These are included in the package.

1. Locate the battery compartment cover on the back of the unit.
2. Slide the cover downwards to open the compartment.
3. Insert 2x AAA batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Replace the battery compartment cover by sliding it upwards until it clicks into place.



Figure 2: Back view of the clock, highlighting the battery compartment and control buttons.

2. Initial Power-On and Radio Signal Reception

Upon battery installation, the clock will power on and automatically begin searching for the DCF radio time signal. This process may take several minutes to an hour, depending on your location and signal strength. During this time, the radio signal icon () will flash on the display.

- Place the clock near a window for optimal signal reception.
- Avoid placing it near electronic devices that may cause interference.
- Once the signal is successfully received, the time will be set automatically, and the radio signal icon will appear solid.

OPERATING INSTRUCTIONS

Button Overview

Refer to Figure 2 for the location of the buttons on the back of the clock:

- **SNZ/LIGHT Button (Top):** Activates snooze during an alarm, or illuminates the backlight.
- **▼ (Down) Button:** Decreases values, navigates menus.

- **▲ (Up) Button:** Increases values, navigates menus.
- **⚙️ (SET) Button:** Enters settings mode, confirms selections.
- **(ALARM) Button:** Enters alarm setting mode, activates/deactivates alarms.
- **(WAVE) Button:** Manually initiates radio signal search.

1. Manual Time and Date Setting

While the clock primarily relies on the radio signal, you can manually set the time and date if needed (e.g., outside signal range or for specific time zones).

1. Press and hold the **⚙️ (SET)** button for approximately 3 seconds to enter time setting mode. The hour digits will flash.
2. Use the **▲ (Up)** or **▼ (Down)** buttons to adjust the hour.
3. Press **⚙️ (SET)** again to confirm the hour and move to minutes. Adjust minutes using **▲ (Up)** or **▼ (Down)**.
4. Continue pressing **⚙️ (SET)** to cycle through and set the year, month, date, and 12/24 hour format.
5. Press **⚙️ (SET)** one last time to exit setting mode, or wait 15 seconds for it to automatically exit.

2. Setting Alarms (Alarm 1 and Alarm 2)

The clock features two independent alarms.

1. Press the **(ALARM)** button once to view Alarm 1 time. Press it again to view Alarm 2 time.
2. While viewing the desired alarm (e.g., Alarm 1), press and hold the **(ALARM)** button for 3 seconds. The alarm hour will flash.
3. Use **▲ (Up)** or **▼ (Down)** to adjust the alarm hour. Press **(ALARM)** to confirm and move to minutes.
4. Adjust alarm minutes using **▲ (Up)** or **▼ (Down)**. Press **(ALARM)** to confirm and exit.
5. To activate or deactivate an alarm, press the **(ALARM)** button repeatedly until the corresponding alarm icon (SNZ1 or SNZ2) appears or disappears on the display.

3. Snooze Function

When an alarm sounds, press the large **SNZ/LIGHT** button on top of the clock to activate the snooze function. The alarm will temporarily stop and sound again after approximately 5 minutes.

To stop the alarm completely, press any other button on the back of the clock.

4. Temperature Display (°C/°F)

The clock displays indoor temperature. To switch between Celsius (°C) and Fahrenheit (°F):

- In normal time display mode, press the **▼ (Down)** button. The temperature unit will toggle between °C and °F.

5. Backlight

Press the large **SNZ/LIGHT** button on top of the clock to briefly illuminate the display backlight for easy viewing in dark conditions.

6. Day of the Week Language Setting

The day of the week can be displayed in 7 languages.

- In normal time display mode, press the **▲ (Up)** button repeatedly to cycle through the available languages for the day of the week display.

MAINTENANCE

Battery Replacement

When the low battery indicator appears on the display, it is time to replace the batteries. Follow the "Battery Installation" steps in the Setup section to replace the 2x AAA batteries.

Cleaning

To clean the clock, use a soft, dry cloth. Do not use abrasive cleaners or solvents, as these may damage the display or casing.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Display is blank or dim.	Batteries are low or incorrectly installed.	Replace batteries with new 2x AAA batteries, ensuring correct polarity.
Clock does not set time automatically or time is incorrect.	Poor DCF radio signal reception; interference; incorrect time zone setting.	<div><ul style="list-style-type: none">• Move the clock closer to a window or to a different location away from electronic devices.• Manually initiate a signal search by pressing the (WAVE) button.• Ensure the clock is set to the correct time zone if applicable. If the clock keeps reverting to a default time zone, try a factory reset by removing batteries for 1 minute and reinserting.• Manually set the time as described in "Manual Time and Date Setting".</div>
Alarm does not sound.	Alarm is not activated.	Ensure the alarm icon (SNZ1 or SNZ2) is visible on the display. Re-set the alarm time.
Temperature reading seems inaccurate.	Clock is placed near a heat source or vent.	Move the clock to a location with stable ambient temperature.

SPECIFICATIONS

Feature	Detail
Brand	Explore Scientific
Model Number	RDC1008
Display Type	Digital
Power Source	2x AAA batteries (included)
Special Features	Alarm, Radio-Controlled, Snooze, Indoor Temperature
Temperature Units	°C / °F
Day of Week Languages	7 languages

Feature	Detail
Backlight	Blue
Material	Acrylonitrile Butadiene Styrene
Mounting Type	Tabletop

WARRANTY AND SUPPORT

Explore Scientific products are designed for quality and reliability. For warranty information and technical support, please refer to the warranty card included with your product or visit the official Explore Scientific website. Please have your model number (RDC1008) and purchase details ready when contacting support.

Website: explorescientific.com



© 2023 Explore Scientific. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Documents - Explore Scientific – RDC1008

[pdf] User Manual Instructions



Explore Scientific Instruction Manual WSH4002 v1bhphtovideo lit files 1014200 msockid 10eb3839c4ed6cd01c852e68c5226ddb |||


COMPACT RADIO CONTROLLED CLOCK WITH INDOOR TEMPERATURE S
OROLOGIO RADIOCONTROLLATO COMPATTO CON TEMP ...
ADIOCONTROLADO CON TEMPERATURA INTERIOR COMPACTE
RADIOGESTUURDE KLOK MET BINNENTEMPERATUUR ART.NO.: **RDC1008** EN
INSTRUCTION MANUAL 2 IT ISTRUZIONI PER L USO..... 10 DE
BEDIENU...
lang:en score:52 filesize: 2.91 M page_count: 68 document date: 2020-05-11

[pdf] User Manual Instructions

Explore Scientific Instruction Manual WSH4002 Download Here Travel Alarm with radio controlled Clock and Indoor — LLC ba167fc2f301d8abdf24fb19a33cd8ce v 1611593238 cdn shopify s files 1 0390 6029 |||

COMPACT RADIO CONTROLLED CLOCK WITH INDOOR TEMPERATURE S
OROLOGIO RADIOCONTROLLATO COMPATTO CON TEMP ...
ADIOCONTROLADO CON TEMPERATURA INTERIOR COMPACTE
RADIOGESTUURDE KLOK MET BINNENTEMPERATUUR ART.NO.: **RDC1008** EN
INSTRUCTION MANUAL 2 IT ISTRUZIONI PER L USO..... 10 DE
BEDIENU...
lang:en score:45 filesize: 2.91 M page_count: 68 document date: 2020-05-11





[\[pdf\]](#) User Manual Instructions


ManualRDC1008EU2022021101 Manuale utenteExplore Scientific RDC1008 Orologio radiocontrollato da viaggio Retroilluminazione azzurra Doppio allarme Snooze Calendario Nero Amazon it Casa e cucinaB1Qbj6yP3bLm media amazon images I B1Qbj6yP3bL ref dp product quick view ||| COMPACT RADIO CONTROLLED CLOCK WITH INDOOR TEMPERATURE S OROLOGIO RADIOCONTROLLATO COMPATTO CON TEMP ... ADIOCONTROLADO CON TEMPERATURA INTERIOR COMPACTE RADIOGESTUURDE KLOK MET BINNENTEMPERATUUR ART.NO.: **RDC1008** EN INSTRUCTION MANUAL 2 IT ISTRUZIONI PER L USO..... 10 DE BEDIENU...

lang:en **score:29** filesize: 2.55 M page_count: 68 document date: 2022-02-23



[\[pdf\]](#) Catalog

Weather and Time 2023 Catalog View Documents — Explore Scientific ES WeatherTime v 1694634057 cdn shopify s files 1 0390 6029 ||| 2023 Weather Time Catalog Weather Stations Clocks Sensors 7-in-1 Wifi Professional Weather S ... ts, the time is easy to read, even when your eyes aren t wide open first thing in the morning. SKU: **RDC1008** UPC: 811803033184 Case Pack: 20 Product Size: 3 x 1.2 x 3.18 in Large Display Radio Control... lang:en **score:21** filesize: 7.79 M page_count: 12 document date: 2022-12-21



[\[pdf\]](#) User Manual Instructions

ManualRDC1008EU2021052401 COMPACT RADIO CONTROLLED CLOCK WITH INDOOR TEMPERATURE S PRODUCT OVERVIEW 1 Press SNZ LIGHT to activate the backlight or snooze function delay alarm for 5 minutes 2 While in normal display mode press select °C °F f7d385cfbd284bce8c8163020ac21b41 bresser de out media ||| COMPACT RADIO CONTROLLED CLOCK WITH INDOOR TEMPERATURE S OROLOGIO RADIOCONTROLLATO COMPATTO CON TEMP ... ADIOCONTROLADO CON TEMPERATURA INTERIOR COMPACTE RADIOGESTUURDE KLOK MET BINNENTEMPERATUUR ART.NO.: **RDC1008** EN INSTRUCTION MANUAL 2 IT ISTRUZIONI PER L USO..... 10 DE BEDIENU...

lang:en **score:19** filesize: 644.52 K page_count: 68 document date: 2021-10-21