

[manuals.plus](#) /› [Ambrane](#) /› [Ambrane Wireless Gaming Controller OP-WLGC01 User Manual](#)

Ambrane OP-WLGC01

Ambrane Wireless Gaming Controller OP-WLGC01 User Manual

Model: OP-WLGC01

1. INTRODUCTION

Thank you for choosing the Ambrane Wireless Gaming Controller OP-WLGC01. This controller is designed to provide an immersive gaming experience across multiple platforms, including PC (Windows), PS3 Console, and Android TV. Featuring 2.4GHz wireless technology, dual vibration motors, and dynamic RGB lighting, this manual will guide you through its setup, operation, and maintenance.



Image 1.1: The Ambrane Wireless Gaming Controller OP-WLGC01, showcasing its transparent design and illuminated elements.

2. PRODUCT OVERVIEW

The Ambrane OP-WLGC01 controller combines advanced features with a unique aesthetic. Key components and features include:

- **Transparent Design:** A visually distinct transparent casing.
- **2.4GHz Wireless Technology:** Ensures stable and responsive connectivity.
- **Integrated Dual Intensity Motor:** Provides haptic feedback for an immersive gaming experience.
- **Illuminated Pad (RGB Lighting):** Features 16.8 million colors with breathing RGB effects.
- **Ergonomic Design:** Easy-to-hold body for comfortable extended gaming sessions.
- **Special Function Buttons:** Dedicated Turbo and Clear buttons for enhanced gameplay.

Comfortable Gaming

with easy to hold design



**Dual Vibrating
Motors**

provide immersive
haptic feedback

Image 2.1: Illustration of the dual vibrating motors providing haptic feedback.

Dynamic Visual Effect

Modern Translucent Body

16.8M



16.8M colours breathing RGB Lighting

Image 2.2: The controller displaying its dynamic 16.8 million color breathing RGB lighting effect.


3. SETUP

3.1 Charging the Controller

Before initial use, fully charge the controller. The integrated 800mAh battery provides up to 12 hours of gameplay on a full charge.

1. Connect the provided Type-C charging cable to the charging port on the controller.
2. Connect the other end of the cable to a USB power source (e.g., computer USB port, USB wall adapter).
3. The indicator lights on the controller will show charging status and turn off or change color when fully charged.

Dual Powerful Vibrating Motors



500,000
500,000

Joystick Lifecycles



Comfortable Gaming

2.4GHz

Seamless Wireless Connectivity



Type-C Charging



Image 3.1: The controller highlighting its Type-C charging port and other features.

3.2 Connecting to Devices

The controller utilizes 2.4GHz wireless technology for connection. It is compatible with PC (Windows systems, supporting X-Input & D-Input modes), PS3 consoles, and Android TV devices.

1. Insert the 2.4GHz USB receiver (dongle) into an available USB port on your PC, PS3 console, or Android TV.
2. Turn on the controller by pressing the MODE button.
3. The controller will automatically pair with the receiver. The indicator lights will stabilize once connected.
4. For PC, ensure the correct input mode (X-Input or D-Input) is selected if prompted by your game or system.

Versatile Compatibility

PS3

PS3 Console



Windows System



Android TV



PC



Image 3.2: The controller demonstrating its compatibility with PS3 Console, Windows System, Android TV, and PC.

4. OPERATING INSTRUCTIONS

4.1 Button Layout and Functions

Familiarize yourself with the controller's button layout for optimal gameplay.

Lag-free Gaming Sessions with Seamless Wireless Connectivity

2.4GHz



Image 4.1: Detailed diagram of the controller's buttons, including joysticks, directional pad, action buttons (A, B, X, Y), shoulder buttons (L1, L2, R1, R2), SELECT, START, TURBO, CLEAR, MODE, and RGB Control.

- **Left/Right Joysticks:** For analog movement and camera control.
- **Directional Button (D-Pad):** For precise directional input.
- **Action Buttons (A, B, X, Y):** Standard game actions.
- **Shoulder Buttons (L1, L2, R1, R2):** For various in-game functions.
- **SELECT/START:** Menu and pause functions.
- **MODE Button:** Power on/off and mode switching.
- **RGB Control:** Button or combination for adjusting RGB lighting effects.

4.2 Turbo Mode

The Turbo mode allows for rapid and continuous actions by repeatedly pressing a single button. This can be useful for certain in-game scenarios.

1. Press and hold the desired action button (e.g., A, B, X, Y, L1, R1).
2. While holding the action button, press the **TURBO** button once.
3. Release both buttons. The selected action button will now perform rapid presses when held down.

8ms Low Latency Rate

for quick response time



Image 4.2: Close-up view of the TURBO and CLEAR special function buttons.

4.3 Clearing Turbo Mode

To deactivate Turbo mode for a specific button:

1. Press and hold the action button for which Turbo mode is active.
2. While holding the action button, press the **CLEAR** button once.
3. Release both buttons. Turbo mode for that button is now deactivated.

To clear all Turbo settings, press and hold the **CLEAR** button for approximately 3 seconds.

5. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your controller.

- **Cleaning:** Use a soft, dry cloth to wipe the controller. For stubborn dirt, slightly dampen the cloth with water. Avoid harsh chemicals or abrasive materials.

- Storage:** Store the controller in a cool, dry place away from direct sunlight and extreme temperatures.
- Battery Care:** Avoid fully discharging the battery frequently. If storing for an extended period, charge the controller to about 50% to prolong battery life.
- Avoid Drops:** Protect the controller from physical impact, which can damage internal components.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Controller does not turn on.	Low battery.	Charge the controller using the provided Type-C cable.
Controller does not connect to device.	USB receiver not properly inserted or out of range.	Ensure the USB receiver is securely plugged in. Move closer to the receiver (within 10 meters). Re-pair by turning the controller off and on.
Buttons or joysticks are unresponsive.	Software glitch or physical obstruction.	Restart the controller and the connected device. Check for any physical debris around buttons/joysticks.
Vibration function is not working.	Game does not support vibration or feature is disabled.	Check in-game settings for vibration options. Ensure the game supports haptic feedback.

7. SPECIFICATIONS

Feature	Detail
Model Number	OP-WLGC01
Connectivity	2.4GHz Wireless
Compatibility	PC (Windows X-Input/D-Input), PS3 Console, Android TV
Battery Capacity	800mAh Lithium Battery
Battery Backup	Up to 12 hours
Charging Port	Type-C
Vibration	Dual Intensity Motor
Lighting	16.8M Colours Breathing RGB
Operating Range	Up to 10 meters
Dimensions (LxWxH)	16.9 x 15.9 x 9 cm
Item Weight	195 g

8. WARRANTY AND SUPPORT

This Ambrane product comes with a 365-day (1 Year) brand warranty against any manufacturing-related issues. For warranty claims, technical support, or any inquiries, please contact Ambrane customer service:

- Email: Care@ambraneindia.com

Please retain your purchase receipt for warranty validation.



© 2023 Ambrane. All rights reserved.

Related Documents - OP-WLGC01

 <p>Flex FASHION MEETS FUNCTION</p> <p>YOUR TIMEPIECE, BUT SMARTER</p> <p>USER MANUAL</p>	<p>Ambrane Flex Smartwatch User Manual: Features, Setup, and Usage Guide</p> <p>Comprehensive user manual for the Ambrane Flex smartwatch. Learn about setup, features like heart rate monitoring, sleep tracking, exercise modes, and warranty information.</p>
 <p>DOTS PLAY CRAFTED FOR PRO GAMERS</p> <p>ULTRA-LOW GAMING LATENCY</p> <p>USER MANUAL</p>	<p>Ambrane Dots Play True Wireless Earphones User Manual</p> <p>User manual for Ambrane Dots Play True Wireless Earphones, detailing features, setup, operation, specifications, safety instructions, and warranty information.</p>
 <p>Stylo Boost 40000 mAh</p> <p>CHARGE TYPE-C LAPTOPS BSW PD TECHNOLOGY</p> <p>GIANT BATTERY, GIANT WATTAGE!</p> <p>USER MANUAL</p>	<p>Ambrane Stylo Boost 40000mAh Power Bank User Manual: 65W PD Fast Charging Guide</p> <p>Explore the Ambrane Stylo Boost 40000mAh Power Bank with this comprehensive user manual. Learn about its 65W Power Delivery, laptop charging capabilities, fast charging protocols, safety instructions, and troubleshooting for optimal use.</p>
 <p>FitShot Zest BLUETOOTH CALLING</p> <p>CONVERSE ON THE MOVE</p> <p>USER MANUAL</p>	<p>Ambrane FitShot Zest Smartwatch User Manual</p> <p>Comprehensive user manual for the Ambrane FitShot Zest smartwatch, detailing setup, features like heart rate monitoring, sports modes, notifications, and maintenance. Includes pairing instructions, charging, and safety information.</p>



[Ambrane PowerVolt Router UPS: Non-Stop Internet Connectivity & Power Backup User Manual](#)

Get uninterrupted internet with the Ambrane PowerVolt Router UPS. This user manual provides details on setup, specifications, features, and warranty for your 5-hour power backup solution.



[Ambrane Dots Slay True Wireless Earphones User Manual](#)

Comprehensive user manual for the Ambrane Dots Slay True Wireless Earphones, detailing setup, operation, key functions, charging, specifications, safety guidelines, and troubleshooting FAQs.