

Cozion M1-FT-FR

Cozion Automatic Solar Chicken Coop Door

USER MANUAL

1. Introduction

Thank you for choosing the Cozion Automatic Solar Chicken Coop Door. This intelligent device is designed to simplify the daily management of your poultry by automating the opening and closing of their coop door. Featuring multiple control modes, a robust design, and solar charging capabilities, it provides convenience and security for your chickens, ducks, and geese.

Key features include:

- **Dual Power Supply:** Equipped with a 5000mAh high-capacity battery and high-conversion solar panels for charging on sunny days. DC charging cable included for other weather conditions.
- **Four Control Modes:** Light sensor control, timer control, manual control, and remote control for flexible operation.
- **Intelligent Anti-Pinch Design:** A sensitive sensor automatically stops the door from closing and reopens if it detects a chicken in its path, preventing injury.
- **Extreme Weather Operation:** Constructed from durable aluminum and AES material with IPX7 waterproofing, ensuring reliable performance in snow, rain, and dust from -26°C to 60°C.
- **Easy Installation & Operation:** Simple setup in under 10 minutes with all necessary accessories. Features a large LCD screen for easy programming and status display.




Figure 1: Cozion Automatic Solar Chicken Coop Door in open and closed states.

2. Safety Information

- Read all instructions carefully before installation and operation.
- Ensure the installation surface is stable and secure to prevent the door from falling.
- Keep hands and loose clothing clear of the door's path during operation.
- The anti-pinch sensor is designed to protect animals. However, always supervise initial operations to ensure proper function.
- Do not attempt to modify or disassemble the device. Refer all servicing to qualified personnel.
- Keep the solar panel clean to ensure optimal charging efficiency.
- This product is designed for poultry. Do not use it for other purposes or with larger animals that may exceed its weight or size capacity.



Figure 2: Intelligent Anti-Pinch Protection in action.

3. Package Contents

Please verify that all items are present and in good condition:

- 1x Cozion Automatic Solar Chicken Coop Door Unit
- 1x Remote Control
- 1x DC Charging Cable
- Mounting Screws and Wall Plugs
- 1x User Manual (this document)



Figure 3: Included components and product dimensions.

4. Setup and Installation

Installation typically takes less than 10 minutes. Follow these steps:

- 1. Choose Location:** Select a flat, vertical surface on your chicken coop where the door can operate freely without obstruction. Ensure the solar panel receives adequate sunlight.
- 2. Mark Drilling Points:** Hold the door unit against the desired installation spot. Use a pencil to mark the positions for the mounting screws through the pre-drilled holes on the unit.
- 3. Drill Holes:** Drill pilot holes at the marked positions. If installing on masonry or concrete, use appropriate drill bits and wall plugs.
- 4. Mount the Unit:** Align the door unit with the drilled holes and secure it firmly using the provided mounting screws. Do not overtighten the screws, as this may impede the door's movement.
- 5. Initial Charge:** Before first use, it is recommended to fully charge the internal battery using the DC charging cable, especially if solar charging conditions are not optimal. Connect the cable to the charging port on the unit and a suitable power source (power bank, laptop, adapter).
- 6. Power On:** Press the power button on the unit to turn it on. The LCD screen will illuminate.

LARGE CAPACITY BATTERY WITH DUAL POWER SUPPLY



5000mAh battery built-in,
which can last up to 100
days after full charged



High quality solar panel,
save money.



Equipped with charging cable,
charged via powebank, laptop
and adapter etc.



Figure 4: Dual power supply options for the door unit.

5. Operating Instructions

The Cozion Automatic Chicken Coop Door offers four intelligent control modes and four opening/closing modes for maximum flexibility.

5.1 LCD Display Overview

The clear LCD display shows the current time, battery status, selected mode, and open/close times. Use the buttons below the screen to navigate and set parameters.

LARGE LCD DISPLAY FOR EASY OPERATION



The clear LCD display screen can help you check the battery status, monitor your coopdoor's functions. Managing your chickens has never been easier.



Figure 5: Large LCD display for easy programming.

5.2 Control Modes

- Light Sensor Control:** The door opens at dawn and closes at dusk based on ambient light levels. This mode adapts to seasonal changes automatically.



Light Sensor Mode

- Timer Control:** Set specific opening and closing times. The door will operate precisely according to your

programmed schedule.



Timer Mode

- **Manual Control:** Use the buttons on the unit to open or close the door manually at any time.



Manual Mode

- **Remote Control:** Operate the door wirelessly from a distance of 24-40 meters (80-130ft) using the provided remote control.



Remote Control Mode

4 INTELLIGENT CONTROL MODE

Light sensor control

Open at dawn, close at dusk



Timing control

Presetting specific time to open and close



Manual control

Press the buttons to open or close the door manually



Remote control

Open and close by remote



Figure 6: Overview of the four intelligent control modes.

5.3 Opening and Closing Modes

The device supports four combined opening and closing modes:

- **T-T Mode:** Opening and closing at preset times.
- **L-L Mode:** Opening at dawn and closing at dusk (Light Sensor for both).
- **T-L Mode:** Opening at a preset time and closing at dusk (Light Sensor for close).
- **L-T Mode:** Opening at dawn (Light Sensor for open) and closing at a preset time.

Select the mode that best suits your needs and seasonal changes via the LCD display settings.

4 OPENING AND CLOSING MODES

T-T Mode:

Opening & closing at preset times



L-L Mode:

Open at dawn and close at dusk



T-L Mode:

Open at preset times and close at dusk



L-T Mode:

Open at dawn and close at preset times



Figure 7: Four flexible opening and closing modes.

6. Maintenance

- Cleaning:** Periodically wipe the door unit, especially the solar panel and the door tracks, with a soft, damp cloth to remove dust, dirt, or debris. Do not use abrasive cleaners or solvents.
- Battery Care:** The integrated 5000mAh battery is designed for long life. Ensure the solar panel is exposed to direct sunlight for optimal charging. If the battery level is low during prolonged cloudy periods, use the DC charging cable to recharge the unit.
- Track Inspection:** Regularly check the door tracks for any obstructions or signs of wear. Ensure the door slides smoothly.
- Sensor Check:** Test the anti-pinch sensor periodically by gently placing an object in the door's path as it closes to ensure it reverses correctly.

QUALITY ALUMINUM MATERIAL PROTECT CHICKENS FROM PREDATOR



Figure 8: Durable aluminum material provides protection in extreme weather.

7. Troubleshooting

Problem	Possible Cause	Solution
Door does not open/close at programmed times.	Incorrect time settings; low battery; light sensor obstructed or miscalibrated.	Verify time settings on LCD. Ensure battery is charged. Clean light sensor and ensure it's not blocked. Recalibrate light sensor if necessary.
Door stops or reverses during closing.	Anti-pinch sensor activated by obstruction (chicken, debris); door tracks are dirty or misaligned.	Check for obstructions in the door's path. Clean door tracks. Ensure the unit is mounted straight and securely.
Remote control not working.	Out of range; remote battery low; interference.	Move closer to the unit. Ensure line of sight. Check remote battery. Reduce potential interference sources.

Problem	Possible Cause	Solution
Battery not charging.	Solar panel dirty or not receiving enough sunlight; DC charging cable faulty.	Clean solar panel. Relocate unit to a sunnier spot. Try a different DC charging cable or power source.
LCD display is blank or flickering.	Low battery; extreme temperatures.	Charge the battery. Ensure the unit is operating within its specified temperature range (-26°C to 60°C).

8. Specifications

Feature	Detail
Model Number	M1-FT-FR
Brand	Cozion
Recommended Species	Chicken
Unit Dimensions (H x W)	35.6 cm x 27 cm (approx. 14.4 in x 10.7 in)
Door Opening Dimensions (H x W)	27 cm x 23.4 cm (approx. 10 in x 9.2 in)
Weight	1.53 Kilograms
Main Battery	5000 mAh (Built-in, rechargeable)
Remote Control Battery	1 AA (included)
Power Supply	Solar Powered, DC Charging
Material	Aluminum, AES
Waterproof Rating	IPX7
Operating Temperature	-26°C to 60°C
Special Features	Durable, Waterproof, Anti-Pinch Sensor, LCD Display, Remote Control
Control Modes	Light Sensor, Timer, Manual, Remote

9. Warranty and Support

Cozion offers a **90-day worry-free refund** and a **1-year free warranty** for this product. If you encounter any issues or have questions regarding your Automatic Solar Chicken Coop Door, please do not hesitate to contact our customer support team.

For support, please visit our official website or contact us via the details provided on your purchase receipt.