#### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- ARMYJY /
- > ARMYJY SCO2 Digital Oscilloscope User Manual

#### ARMYJY 2074834766

# **ARMYJY SCO2 Digital Oscilloscope User Manual**

Model: 2074834766

# 1. PRODUCT OVERVIEW

The ARMYJY SCO2 is a portable dual-channel digital oscilloscope designed for a wide range of applications, including appliance repair, mobile phone repair, automotive repair, and electronic DIY projects. It features a 50M sampling rate, 10MHz analog bandwidth, and a 3.2-inch LCD display for clear waveform visualization.

# **Key Features:**

- High Sampling Rate: 50M samples per second (1 channel) for detailed signal capture.
- Dual Channel: Allows simultaneous measurement and comparison of two signals.
- Wide Bandwidth: 10MHz analog bandwidth and 2MHz effective bandwidth.
- Comprehensive Trigger Functions: Single, Normal, and Automatic modes for stable waveform display.
- One-Key AUTO Function: Simplifies waveform display without complex adjustments.
- Deep Storage: 20KB storage depth with waveform compression and expansion support.
- Current Measurement: Integrated 0-6A current measurement with 2mA precision.
- **High Voltage Protection:** Supports anti-burn high-pressure function.
- **Expandability:** Designed for future module expansion (e.g., audio, function generator, transistor tester modules).
- PC Software Support: Enables system updates and future features like FTT and computer communication.



Figure 1.1: Front view of the ARMYJY SCO2 Digital Oscilloscope, showing the display screen, control buttons, and input/output ports.

# 2. SETUP

# 2.1 Unpacking and Inspection

Carefully unpack the oscilloscope and all accessories. Verify that all components listed in your specific set are present and undamaged. The available sets are:

- Set 1: 1 Standard Oscilloscope, 2 Alligator Clips.
- Set 2: 1 High-End Oscilloscope, 1 Alligator Clip, 1 High Voltage Probe.
- Set 3: 1 High-End Oscilloscope, 1 Alligator Clip, 2 High Voltage Probes.

# 2.2 Charging the Device

Before first use, ensure the oscilloscope is fully charged. Connect the device to a 5V power source using a compatible USB cable. The battery capacity is 2500mA, providing approximately 4.5-6 hours of continuous operation on a full charge.

# 2.3 Connecting Probes

Connect the appropriate probes (alligator clips or high voltage probes) to the CH1 and CH2 input BNC connectors on the top of the oscilloscope. Ensure connections are secure. For high voltage measurements, always use the provided high voltage probes and observe safety precautions.



Figure 2.1: Angled view of the oscilloscope, highlighting the BNC input connectors for CH1 and CH2, and the power button.

# 3. OPERATING INSTRUCTIONS

#### 3.1 Power On/Off

Press and hold the 'OFF/ON' button located on the top right of the device to power on or power off the oscilloscope.

#### 3.2 Basic Controls

The device features several control buttons on the right side of the display:

- Menu: Accesses the main menu for settings and configurations.
- Flexo: (Function not explicitly detailed in source, likely a flexible function button or mode switch).
- Auto: Activates the one-key AUTO function for automatic waveform display adjustment.
- **Ok/Hold:** Confirms selections or pauses the waveform display.
- Left / Right Arrows: Navigate through menus or adjust parameters.
- + / Buttons: Adjust values or zoom levels.



Figure 3.1: Close-up view of the oscilloscope's control panel, showing the arrangement of buttons for menu navigation, auto-adjustment, and parameter control.


# 3.3 Waveform Measurement


The SCO2 supports various waveform measurements and displays. Use the 'Auto' button for quick setup. The display shows parameters such as Max, Min, Vpp, Rms, and Frequency. The device can display dual-channel oscilloscope waveforms, Lissajous patterns, and current waveforms.



Figure 3.2: The oscilloscope displaying a typical waveform with measurement parameters visible on the screen.


# Pattern interface Waveform measurement display





Dual channel oscilloscope

Lissayu model



# **Current waveform display**

Figure 3.3: Examples of different waveform displays, including dual-channel, Lissajous, and current waveforms, demonstrating the device's versatility.

#### 3.4 Current Measurement

The oscilloscope includes a current measurement function, capable of measuring 0-6A with a minimum precision of 2mA and a sampling rate of 2.4KSa/s. Refer to the on-screen interface for current waveform display and parameters.

#### 4. MAINTENANCE

# 4.1 Cleaning

To clean the device, use a soft, dry cloth. For stubborn dirt, a slightly damp cloth with mild detergent can be used, ensuring no liquid enters the device. Avoid abrasive cleaners or solvents.

# 4.2 Storage

Store the oscilloscope in a cool, dry place away from direct sunlight and extreme temperatures. When not in

use for extended periods, ensure the battery is partially charged (around 50%) to prolong its lifespan.

# 4.3 Battery Care

To maintain battery health, avoid fully discharging the battery frequently. Recharge the device when the battery indicator is low. If the device will not be used for a long time, charge it every few months.

#### 5. TROUBLESHOOTING

#### 5.1 No Power

- Ensure the device is fully charged. Connect it to a 5V power source and check the charging indicator.
- Verify the power button is pressed and held correctly.

# 5.2 Unstable Waveform Display

- Press the 'Auto' button to automatically adjust the display settings.
- Check the trigger settings (Single, Normal, Auto) and adjust them according to the signal type.
- Ensure probes are securely connected and making good contact with the circuit.

# **5.3 Incorrect Measurement Readings**

- Verify the probe attenuation setting (X1, X10) matches the physical probe in use.
- Ensure the input impedance is correctly set  $(1M\Omega)$ .
- Check for proper grounding of the oscilloscope and the circuit under test.

# 5.4 Device Not Responding

- Perform a soft reset by holding down the power button for an extended period (e.g., 10-15 seconds) until the device restarts.
- If the issue persists, contact customer support.

# 6. SPECIFICATIONS

The following table details the technical specifications of the ARMYJY SCO2 Digital Oscilloscope:

Model number	SCO_2_10M	SCO_1_500K
Sampling rate	50MSa/S/Channels	2.5MSa/S
Channels	2	1
Analog bandwidth	10MHz	500KHz
Actual bandwidth	2MHz	200KHz
Measured voltage	X1/±40V	X10/±400V
Input impedance	1ΜΩ	
Storage depth	20Kb	1Kb
Parameter display	12Type	
Current measurement	0~6A	
Precision	2mA	
I sampling rate	2.5KSa/S	\

Figure 6.1: Detailed technical specifications for the SCO2 model, including sampling rate, channels, bandwidth, and measurement capabilities.

Parameter	Specification
Maximum Measurable Voltage	±400V
Sampling Rate	50MSa/s (1 channel)
Number of Channels	2
Analog Bandwidth	10MHz (1CH)
Effective Bandwidth	2MHz (1CH)
Measurement Voltage	X1 (±40V), X10 (±400V)
Input Impedance	1ΜΩ
Storage Depth	20KB
Parameter Display Types	12 types

Parameter	Specification
Current Measurement Range	0-6A
Minimum Current Precision	2mA
Current Sampling Rate	2.4KSa/s
Display	3.2-inch LCD, 320x240 resolution
Charging Voltage	5V
Battery Capacity	2500mA
Continuous Working Time	4.5-6 hours
Shell Dimensions	120mm x 66mm x 18.5mm

# 7. WARRANTY AND SUPPORT

# 7.1 Warranty Information

Please refer to your purchase documentation or contact the seller for specific warranty terms and conditions. General return policies may apply as per the retailer's guidelines.

# 7.2 Customer Support

For technical assistance, troubleshooting beyond this manual, or inquiries regarding future software updates and module expansions, please contact ARMYJY customer service. Firmware updates, including features like FTT and advanced computer communication, are planned for future releases. Users can update the system via PC software. Contact customer service for the latest firmware after September 1, 2023. The oscilloscope is designed with rich scalability, supporting the use of different modules to expand more functions. Currently, these modules are under development and will include audio modules, bidirectional function generator modules, and transistor tester modules in the future.


# Field of use

# Diversified uses A wider range of applications











Electronics interest DIY research and development



**☑** Power supply maintenance

Figure 7.1: Illustration of the diverse applications for the SCO2 oscilloscope, including appliance, mobile phone, and automotive repair, as well as electronics DIY and power supply maintenance.