

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [WilTec](#) /

› [WilTec Wall Mount Bicycle Rack \(Model 65353\) Instruction Manual](#)

WilTec 65353

WilTec Wall Mount Bicycle Rack Instruction Manual

Model: 65353

1. INTRODUCTION

Thank you for choosing the WilTec Wall Mount Bicycle Rack. This manual provides essential information for the safe installation, operation, and maintenance of your bicycle rack. Please read these instructions carefully before installation and retain them for future reference. This rack is designed to securely store one bicycle, optimizing space in your garage or home.

2. SAFETY INSTRUCTIONS

- Ensure the mounting surface (wall) is structurally sound and capable of supporting the rack's weight plus the maximum bicycle weight (up to 35 kg). Consult a professional if unsure about wall integrity.
- Use appropriate mounting hardware for your specific wall type (e.g., concrete, brick, wood studs). Hardware is typically not included and must be purchased separately.
- Do not exceed the maximum load capacity of 35 kg (77 lbs). Overloading can cause damage to the rack, wall, and bicycle, and may result in injury.
- Install the rack at a height that allows for safe and easy loading/unloading of the bicycle without strain.
- Regularly check all fasteners to ensure they remain tight and secure.
- Keep children and pets away from the installation area during setup and ensure the bicycle is securely mounted to prevent accidental falls.
- Avoid hanging items other than bicycles on the rack.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- 1x WilTec Wall Mount Bicycle Rack main unit
- 1x Lower wheel support bracket
- Instruction Manual (this document)

Note: Mounting hardware (screws, anchors) is not included and must be selected based on your wall type.

4. SETUP AND INSTALLATION

Proper installation is crucial for the safety and stability of the bicycle rack. Follow these steps carefully:

4.1. Choose a Location

Select a sturdy wall in your garage, shed, or home. Ensure there is enough clear space around the chosen area for the bicycle to be mounted and swiveled without obstruction.

4.2. Mark Drilling Points

Hold the main rack unit against the wall at the desired height. Use a pencil to mark the drilling points for the mounting screws. Ensure the rack is level before marking. The rack measures approximately 11.8 x 63.8 x 58.3 cm (width x height x depth when extended).




Figure 1: Product Dimensions and Swivel Range

4.3. Drill Holes and Install Anchors

Drill holes at the marked points using a drill bit appropriate for your chosen mounting hardware and wall type. Insert wall

anchors if necessary (e.g., for drywall or hollow walls).

4.4. Mount the Main Rack Unit

Align the rack with the drilled holes and secure it to the wall using appropriate screws. Tighten all screws firmly, but do not overtighten.

4.5. Install the Lower Wheel Support

Position the lower wheel support bracket directly below the main rack unit, ensuring it aligns with where the bicycle's rear wheel will rest. Mark drilling points, drill holes, and secure the bracket to the wall.

4.6. Adjust Height (5-Stage Adjustment)

The main rack unit features a 5-stage height adjustment mechanism. This allows you to customize the rack's height to accommodate different bicycle sizes and wheel diameters (508mm-737mm) and tire widths (53mm-71mm). Adjust the height by releasing the locking mechanism, sliding the arm to the desired position, and re-engaging the lock.

Detalles del producto



Figure 2: Foldable Design, 5-Step Height Adjustment, and Tire Stop

Adecuado para varios tamaños

Diámetro de neumático

508mm-737mm

Ancho del neumático

53mm-71mm



Figure 3: Tire Compatibility

5. OPERATING INSTRUCTIONS

5.1. Mounting a Bicycle

1. Ensure the rack arms are extended and locked into position.
2. Lift the bicycle by its front wheel and guide it into the main rack unit. The front wheel should rest securely in the upper hook.
3. Lower the rear wheel until it rests on the lower support bracket. The tire retainers on both the upper and lower supports help protect the bicycle and the wall from scratches.
4. Verify that the bicycle is stable and securely held by both the upper and lower supports. The rack is designed for easy loading without heavy lifting, supporting bikes up to 35 kg.

Sin levantar peso

Basta con deslizar la bicicleta en el soporte



35kg

Capacidad de carga

Figure 4: Easy Bicycle Mounting and 35kg Capacity

5.2. Swiveling the Bicycle for Space Optimization

The rack features swivel arms that allow the mounted bicycle to be rotated up to 60 degrees to either side. This helps optimize space, especially in narrow areas.

1. With the bicycle securely mounted, gently push or pull the bicycle to rotate it along the rack's pivot point.
2. Rotate the bicycle until it is in the desired position, closer to the wall.

Diseño compacto

Portabicicletas giratorio para almacenamiento eficaz



Figure 5: Compact Design with Swivel Function

5.3. Folding the Rack

When not in use, the rack can be folded against the wall to save space.

1. Remove the bicycle from the rack.
2. Release the locking mechanism on the rack arms and fold them upwards against the wall.



Figure 6: WilTec Wall Mount Bicycle Rack in Use

Ideal para una amplia gama de bicicletas



Bicicletas de montaña



Bicicletas infantiles



Bicicletas de carretera



Bicicletas eléctricas

Figure 7: Versatility for Various Bicycle Types

6. MAINTENANCE

- **Cleaning:** Wipe the rack with a damp cloth to remove dust and dirt. Avoid abrasive cleaners that could damage the finish.
- **Fastener Check:** Periodically inspect all mounting screws and connections to ensure they are tight. Retighten if necessary.
- **Damage Inspection:** Check the rack for any signs of wear, damage, or deformation. If any damage is found, discontinue use and replace the affected parts or the entire unit.

7. TROUBLESHOOTING

- **Rack feels unstable:** Ensure all mounting screws are securely tightened. Verify that the wall structure is adequate for the load. If the issue persists, consult a professional for wall assessment.
- **Bicycle does not fit:** Check the tire diameter and width against the specifications (508mm-737mm diameter, 53mm-71mm width). Adjust the 5-stage height setting to accommodate your bicycle's size.

- **Rack arms do not fold/extend smoothly:** Check for any obstructions or debris in the hinge mechanism. Apply a small amount of silicone lubricant if needed.

8. SPECIFICATIONS

Feature	Specification
Model Number	65353
Dimensions (Extended)	11.8 x 63.8 x 58.3 cm (Width x Height x Depth)
Weight	2.48 kg
Maximum Load Capacity	35 kg
Bicycle Capacity	1 Bicycle
Height Adjustment	5-stage
Swivel Angle	±60°
Compatible Tire Diameter	508mm - 737mm
Compatible Tire Width	53mm - 71mm
Material	High-quality steel (implied from image)
Country of Origin	China

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the purchase documentation or contact WilTec customer service directly. Keep your proof of purchase for any warranty claims.

Wiltec Wildanger Technik GmbH

For contact details, please visit the official WilTec website or refer to your product packaging.