

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SUNLU](#) /

› [SUNLU Filament Dryer Box E2 User Manual](#)

## SUNLU E2

# SUNLU Filament Dryer Box E2 User Manual

Model: E2

## INTRODUCTION

The SUNLU Filament Dryer Box E2 is an advanced solution designed for optimal 3D printing filament care. It integrates drying, annealing, and storage functionalities, specifically engineered for high-performance and engineering-grade 3D printing materials. This manual provides essential information for setting up, operating, and maintaining your FilaDryer E2 to ensure consistent and high-quality 3D prints.




Figure 1: The SUNLU Filament Dryer Box E2, designed for efficient filament drying and annealing.

## WHAT'S IN THE Box

Upon opening your SUNLU Filament Dryer Box E2 package, please verify that all the following components are included:

- SUNLU FilaDryer E2 Unit
- Annealing Tray
- Heat-Resistant Gloves
- PTFE Tube 1m\*2
- PTFE Tube 8cm\*2
- Power Cable
- User Manual




Figure 2: All components included in the SUNLU Filament Dryer Box E2 package.

## Unboxing Guide Video

For a visual guide on unboxing and identifying the components, please watch the official unboxing video:

Your browser does not support the video tag.

Video 1: Official SUNLU E2 Filament Dryer Box Unboxing Guide. This video demonstrates the unboxing process and shows all included accessories.

## PRODUCT OVERVIEW AND FEATURES

The SUNLU Filament Dryer Box E2 is engineered to provide comprehensive care for your 3D printing filaments, ensuring optimal print quality and material longevity. Key features include:

- **All-in-One Solution:** Integrates drying, annealing, and storage for engineering-grade 3D printing materials.
- **High Temperature Capability:** Achieves a maximum temperature of 110°C for effective drying and annealing.
- **Efficient Annealing:** Designed for 99.99% effective annealing, enhancing material properties like impact resistance.
- **Rapid Drying:** Features 500W PTC heating, reducing drying time significantly (e.g., 50°C in 20 mins, 70°C in 30 mins from room temperature).
- **Professional Sealing & Insulation:** Triple protection against moisture with silicone-sealed ports, magnetic suction lid, and dual-chamber insulation. Maintains stable internal temperatures while keeping the exterior surface below 60°C for safety.
- **Broad Compatibility:** Supports a wide range of engineering and conventional filaments (PLA, PETG, ABS, ASA, PC, PA, etc.) and accommodates spools up to  $\Phi 250 \times 153\text{mm}$  (2x1KG/2x2KG or 1x3KG).
- **Intelligent Safety:** Dual-layer safety system with alarm for over-temperature and fireproof grade materials.

# Advanced PTC Heating

70°C Safe, 90°C Stable, 110°C Reliable




Figure 3: Overview of the SUNLU Filament Dryer E2's core functionalities.

## Protection for Your Machine

Multiple details for your machine, extending its lifespan



Figure 4: The large capacity of the FilaDryer E2, accommodating various spool sizes.

## SETUP

Setting up your SUNLU Filament Dryer Box E2 is straightforward:

1. Unpack all components from the box as detailed in the "What's in the Box" section.
2. Place the FilaDryer E2 on a stable, flat, and heat-resistant surface.
3. Ensure the power switch on the back of the unit is in the 'Off' position.
4. Connect the provided power cable to the unit's power input and then to a suitable power outlet.
5. Press the power switch to the 'On' position. The display will illuminate.
6. Familiarize yourself with the control panel on the front of the unit.

## OPERATING INSTRUCTIONS

### Drying Filaments

Drying removes excess moisture from filaments, preventing common print defects like bubbling, stringing, and poor layer adhesion. The FilaDryer E2 offers precise temperature control for efficient drying.

1. Open the lid of the FilaDryer E2.
2. Place your filament spool(s) inside the chamber. Ensure the spool fits within the maximum dimensions ( $\Phi 250 \times 153\text{mm}$ ).
3. Close the lid securely.
4. On the control panel, select the appropriate drying temperature and time based on your filament type. The unit heats rapidly, reaching 50°C in 20 minutes and 70°C in 30 minutes from room temperature.
5. Start the drying process. Monitor the display for current temperature and humidity readings.
6. Once drying is complete, the unit will notify you. Carefully remove the filament spool(s) using the provided heat-resistant gloves if the unit is still warm.

## What is Annealing & Why is it Necessary



- Plastic products are placed in a heated liquid medium or hot air circulation box at a constant temperature for a period of time, and then slowly cooled to room temperature, using heat to accelerate the relaxation of macromolecules in the plastic, thus eliminating or reducing the residual stresses in the products after molding.
- Eliminate the local stress concentration phenomenon produced by different cooling speeds during the cooling and curing process of plastic products.
- That's what the SUNLU FilaDryer E2 delivers -a professionalgrade 2-in-1 annealing and drying solution specifically designed for Engineering Materials.

Figure 5: Illustrates the importance of drying and its effect on filament moisture.

### Annealing Filaments and Printed Models

Annealing is a heat treatment process that relieves internal stress in materials, improving their mechanical properties such as impact resistance, durability, and dimensional stability. This is particularly beneficial for engineering-grade filaments and printed parts.




Figure 6: Explanation of the annealing process and its benefits.

To anneal a filament or printed model:

1. Place the filament spool or printed model on the annealing tray inside the FilaDryer E2.
2. Close the lid.
3. Select the annealing mode and set the temperature and duration according to the specific material's requirements. Refer to

the filament manufacturer's recommendations or common annealing profiles for your material (e.g., PA, PC).

4. Start the annealing process. The FilaDryer E2 will heat the chamber to the set temperature and maintain it for the specified duration.
5. After the heating phase, allow the material to cool gradually inside the closed chamber. This controlled cooling is crucial for effective stress relief and property enhancement.
6. Once cooled, carefully remove the annealed material.




Figure 7: Recommended temperatures for various filament spool types.



Figure 8: Data demonstrating the enhanced mechanical properties of SUNLU PA and Easy PA after annealing.

## Filament Storage

The FilaDryer E2 also serves as an excellent storage solution, protecting your filaments from moisture re-absorption. Its dual-chamber insulated design and silicone seals ensure a dry environment.

- After drying or annealing, you can leave the filament inside the FilaDryer E2 with the lid closed to maintain its dry state.
- For printing directly from the dryer, utilize the silicone-sealed filament ports and PTFE tubing to feed the filament to your 3D printer, minimizing exposure to ambient humidity.

Figure 9: The sealed insulation design for effective moisture protection.

## FILAMENT COMPATIBILITY

---

The SUNLU Filament Dryer Box E2 is highly compatible with a wide range of 3D printing filaments, including both standard and engineering materials. It supports wire diameters of  $\Phi 1.75\text{mm}$  and  $\Phi 2.85\text{mm}$ .

### Engineering Filaments Compatible:

- ASA
- PVB
- PA (Nylon)
- PC (Polycarbonate)
- PA6-GF (Glass Fiber Reinforced PA6)
- PA12
- PA-CF (Carbon Fiber Reinforced PA)
- PA-GF (Glass Fiber Reinforced PA)
- Flame retardant PC
- PC-ABS
- PC-PBT
- CoPA
- PA6-CF
- PA12-CF
- PA612-CF

### Standard Filaments Compatible:

- PLA
- PLA+
- PETG
- PVA
- PCL
- ABS
- TPU
- EASY-PA

*Note: Always pay attention to the temperature resistance of your filament spool to avoid deformation during high-temperature drying or annealing.*

## What's in the Box



Figure 10: Detailed compatibility information for various filament types and sizes.

## MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your SUNLU Filament Dryer Box E2.

- **Cleaning:** Regularly wipe the interior and exterior surfaces with a soft, dry cloth. Ensure the unit is unplugged and completely cooled before cleaning. Do not use abrasive cleaners or solvents.
- **Air Vents:** Keep the air vents clear of dust and debris to ensure proper airflow and prevent overheating.
- **Seals:** Periodically inspect the silicone seals around the lid and filament ports for any signs of wear or damage. Intact seals are crucial for maintaining a dry environment.
- **Storage:** When not in use for extended periods, store the unit in a cool, dry place away from direct sunlight.



Figure 11: Internal design features contributing to the durability and ease of maintenance.

## TROUBLESHOOTING

If you encounter issues with your SUNLU Filament Dryer Box E2, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Unit does not power on.	Power cable not connected; Power switch off; Power outlet issue.	Ensure power cable is securely plugged in. Turn power switch to 'On'. Test power outlet with another device.
Temperature not reaching set value.	Lid not properly closed; Ambient temperature too low; Faulty heating element.	Ensure lid is fully closed and sealed. Allow more time for heating in cold environments. Contact support if issue persists.
Filament still moist after drying.	Insufficient drying time/temperature; Filament heavily saturated; Seals compromised.	Increase drying time or temperature. Pre-dry heavily saturated filaments for longer. Check lid and port seals for integrity.
Unusual noises during operation.	Fan obstruction; Loose component.	Ensure air vents are clear. If noise persists, discontinue use and contact support.

If these steps do not resolve your issue, please contact SUNLU customer support for further assistance.

## SPECIFICATIONS

Detailed specifications for the SUNLU Filament Dryer Box E2:

Attribute	Value
Brand	SUNLU
Model Number	E2
Item Weight	15.4 pounds
Package Dimensions	18 x 14.4 x 11 inches
Color	Black
Material Type	SUNLU Official Filament Dryer Box E2
Number of Items	1
Size	Extra Large
UPC	850074112006
Max Drying Temperature	110°C
Heating Power	500W PTC
Max Spool Size	Φ250mm x 153mm
Filament Diameter Compatibility	Φ1.75mm, Φ2.85mm

## WARRANTY AND SUPPORT

SUNLU offers a one-year free replacement service for the Filament Dryer Box E2. If the product you received has quality issues or is damaged during use, please contact SUNLU customer support for a free replacement.

For further assistance, technical support, or warranty claims, please visit the official SUNLU website or contact their customer service team directly. Keep your purchase receipt as proof of purchase for warranty purposes.

© 2025 SUNLU. All rights reserved.