

QLT BEDI 23C18/23110

QLT Bathroom Heater with Wall Mount and Towel Rack - Model BEDI 23C18/23110 User Manual

Your guide to safe and efficient operation

1. INTRODUCTION

Thank you for choosing the QLT Bathroom Heater with Wall Mount and Towel Rack. This manual provides essential information for the safe installation, operation, and maintenance of your new heater. Please read this manual thoroughly before using the appliance and keep it for future reference.

2. SAFETY INSTRUCTIONS

To prevent injury or damage, always observe basic safety precautions when using electrical appliances. This heater is designed for bathroom use and includes specific safety features.

- **Electrical Safety:** Ensure the power supply matches the heater's requirements (220-240V / 50Hz). Do not operate with a damaged cord or plug.
- **Water Resistance:** The heater has an IP22 rating, making it safe for use in damp environments like bathrooms. However, do not immerse the unit in water or expose it to direct water spray.
- **Overheating Protection:** The unit is equipped with an automatic shut-off feature to prevent overheating. If activated, disconnect power and allow the unit to cool before restarting.
- **Open Window Detection:** This feature automatically turns off the heater if a sudden drop in temperature is detected, saving energy.
- **Placement:** Mount the heater securely on a wall, away from flammable materials. Do not cover the air inlets or outlets.
- **Children and Vulnerable Persons:** This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- **Maintenance:** Always unplug the heater before cleaning or performing any maintenance.

3. PACKAGE CONTENTS

Please check that all items are present and undamaged:

- QLT Bathroom Heater Unit
- Remote Control
- Wall Mounting Hardware (screws, anchors)
- User Manual (this document)

4. PRODUCT OVERVIEW

Familiarize yourself with the components of your QLT Bathroom Heater.



Figure 1: Front view of the QLT Bathroom Heater. It is a white, rectangular unit with rounded corners. A circular black control panel with a digital display (showing '21') and various icons (power, mode, timer, fan, temperature up/down) is located at the top center. The 'QLT' logo is visible on the bottom left. A silver-colored metal bar, serving as a towel rack, extends from the bottom of the unit.

Control Panel Features:

- **Power Button:** Turns the heater on or off.
- **Mode Button:** Selects between different heating power levels (e.g., 1000W, 2000W).
- **Timer Button:** Activates and sets the weekly timer function.
- **Temperature Up/Down Buttons:** Adjusts the desired temperature setting.
- **Digital Display:** Shows current temperature, timer settings, or power mode.

5. SETUP AND INSTALLATION

The QLT Bathroom Heater is designed for wall mounting to save space and ensure optimal performance.

1. **Choose Location:** Select a suitable wall location in your bathroom, ensuring it is away from direct water spray and at a safe distance from other objects. The IP22 rating allows for bathroom installation, but avoid areas directly above a bath or shower.
2. **Mark Drilling Points:** Use the provided mounting template (if included, otherwise measure carefully) to mark the drilling points on the wall.
3. **Drill Holes:** Drill holes at the marked points and insert the wall anchors.
4. **Mount Heater:** Secure the heater to the wall using the provided screws. Ensure it is firmly attached.
5. **Connect Power:** Plug the 1.5-meter electrical cable into a grounded 220-240V / 50Hz power outlet. Ensure the cable is not stretched or pinched.
6. **Towel Rack:** The integrated towel rack is ready for use once the heater is mounted.

6. OPERATING INSTRUCTIONS

Your QLT Bathroom Heater can be operated via the control panel on the unit or the included remote control.

6.1 Basic Operation

1. **Power On/Off:** Press the **Power** button (*symbol: circle with vertical line*) on the control panel or remote control to turn the heater on or off.
2. **Adjust Power Level:** Press the **Mode** button (*symbol: fan icon or similar*) to cycle through the available power selections (e.g., 1000W, 2000W). The digital display will indicate the selected power.
3. **Set Temperature:** Use the **Temperature Up** (*symbol: plus sign*) and **Temperature Down** (*symbol: minus sign*) buttons to set your desired room temperature. The heater will automatically maintain this temperature.

6.2 Weekly Timer Function

The weekly timer allows you to program the heater to turn on and off at specific times throughout the week.

1. **Activate Timer:** Press the **Timer** button (*symbol: clock icon*) on the control panel or remote.
2. **Program Settings:** Follow the on-screen prompts on the digital display to set the desired on/off times and temperature for each day of the week. Refer to the specific instructions in the remote control section for detailed programming steps.
3. **Save Settings:** Ensure you save your timer settings before exiting the timer menu.

6.3 Open Window Detection

This feature is automatically enabled. If the heater detects a rapid drop in room temperature (indicating an open window or door), it will temporarily switch off to conserve energy. The heater will resume operation once the temperature stabilizes or can be manually restarted.

7. MAINTENANCE

Regular cleaning ensures optimal performance and extends the lifespan of your heater.

- **Cleaning:** Always unplug the heater from the power outlet before cleaning. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents.
- **Air Vents:** Periodically check and gently clean the air inlet and outlet vents to ensure they are free from dust and debris. Do not insert any objects into the vents.
- **Storage:** If storing the heater for an extended period, ensure it is clean and dry. Store it in a cool, dry place.

8. TROUBLESHOOTING

If you encounter issues with your heater, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Heater does not turn on.	No power supply; Power button not pressed; Overheating protection activated.	Check power plug and outlet; Press the Power button; Unplug, wait 30 minutes, then plug back in.
Heater stops working unexpectedly.	Overheating protection activated; Open window detection activated.	Check for obstructions around vents, unplug and allow to cool; Close windows/doors, heater should resume or can be restarted.
Heater is on but not heating.	Temperature setting is too low; Mode is set to fan-only (if applicable).	Increase the desired temperature setting; Ensure a heating mode (1000W/2000W) is selected.
Remote control not working.	Batteries are dead or incorrectly inserted; Obstruction between remote and heater.	Replace batteries, ensure correct polarity; Remove any obstructions.

If the problem persists after trying these solutions, please contact customer support.

9. SPECIFICATIONS

Model Number:	BEDI 23C18/23110
Brand:	QLT
Color:	White
Material:	Plastic
Power Output:	1000W - 2000W
Power Selections:	2
Thermostat:	Yes, built-in
Timer:	Weekly timer function
Control:	Remote control / Control panel




Mounting:	Wall-mounted
Overheating Protection:	Yes
Electrical Cable Length:	1.5 meters
IP Rating:	IP22 (safe for damp environments)
Connection Voltage:	220-240V / 50Hz
Special Features:	Open window detection, Automatic shut-off
Product Dimensions (L x W x H):	31D x 11B x 12H centimeters
Weight:	1.7 kilograms

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided at the time of purchase or contact your retailer. Keep your proof of purchase for any warranty claims.

Manufacturer: Concept Online, De Kreek 28, 3871 MM, Hoevelaken, Nederland

Related Documents - BEDI 23C18/23110

	<p>QLT Rechargeable Air Compressor/Bicycle Pump User Manual</p> <p>User manual for the QLT wireless and powerful rechargeable air compressor/bicycle pump. Includes instructions for use, power options, specifications, and safety notes.</p>
	<p>QLT Electric Pruning Shears Instruction Manual</p> <p>Comprehensive user manual for QLT Electric Pruning Shears (models 23H01/23800). Includes detailed safety guidelines, operation instructions, maintenance procedures, and technical specifications for this 21V Li-ion battery-powered tool with a 25mm shear capacity, designed for cutting branches and stems.</p>
	<p>QLT Lithium Electric Chain Saw - User Manual and Safety Guide</p> <p>Comprehensive user manual and safety instructions for the QLT Lithium Electric Chain Saw (Model 22-252). Learn about safe operation, installation, maintenance, and technical specifications.</p>

