

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [EARU](#) /

› [EARU Electric 440V 63A 3-Phase Voltage and Overcurrent Protector Instruction Manual](#)

EARU EARU-1008

EARU Electric 440V 63A 3-Phase Voltage and Overcurrent Protector Instruction Manual

Model: EARU-1008

1. INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of the EARU Electric 3-Phase Voltage and Overcurrent Protector, Model EARU-1008. This device is designed to safeguard 3-phase electrical systems by continuously monitoring voltage and current, offering protection against over-voltage, under-voltage, overcurrent, and phase failure. It is suitable for industrial and commercial applications requiring reliable electrical monitoring and protection.

2. SAFETY INFORMATION

WARNING: Electrical shock hazard. Installation and maintenance should only be performed by qualified personnel.

- Always disconnect power before installing or servicing the device.
- Ensure proper grounding to prevent electrical shock.
- Verify all wiring connections are secure and correct according to the wiring diagram.
- Do not operate the device if it appears damaged.
- Adhere to all local and national electrical codes.

3. PRODUCT OVERVIEW

3.1. Key Features

- Real-time 3-Phase Monitoring:** Displays live voltage (L1, L2, L3) and current (I1, I2, I3) values.
- Comprehensive Protection:** Safeguards against over-voltage, under-voltage, overcurrent, and phase failure.

- **Adjustable Parameters:** User-configurable settings for protection thresholds and recovery delays.
- **Automatic Phase Failure Reset:** Detects and automatically resets after phase anomalies.
- **High-Visibility LED Display:** Bright red LED for clear readings in various lighting conditions.
- **DIN Rail Mount:** Easy integration into standard electrical panels.
- **Clear Terminal Labeling:** Simplified installation with clearly marked input and output terminals.

3.2. Components and Display

The device features a clear LED display and intuitive control buttons for configuration. The display shows real-time voltage and current for each phase, along with indicators for protection status.





Image 3.2.1: Front view of the EARU Electric Voltage Protector, showing the LED display for L1, L2, L3 voltage and current, along with control buttons (SET, Up, Down, Power) and protection indicators. Terminal labels for N, L1, L2, L3 (IN and OUT) are also visible.

► PRODUCT FEATURES

EARU
ELECTRIC



- Over Voltage Protection
- Over Current Protection
- Power On Delay
- Protection Trip Delay
- Three Phase Voltage Imbalance Protection
- Voltage&Current Manual Error Calibration
- Under Voltage Protection
- Phase Sequence Protection
- Phase Sequence Protection
- Recover Delay

Image 3.2.2: A perspective view highlighting the product features and the input/output terminals (N, L1, L2, L3) at the top and bottom of the device. This image emphasizes the physical layout and connection points.

4. SETUP AND INSTALLATION

4.1. Mounting

The EARU-1008 is designed for DIN rail mounting. Securely attach the device to a standard 35mm DIN rail within an electrical enclosure.

4.2. Wiring Connections

Refer to the wiring diagram below for correct connections. Ensure all connections are tight and properly insulated.

1. Connect the incoming neutral (N) and phase lines (L1, L2, L3) to the 'IN' terminals.
2. Connect the outgoing neutral (N) and phase lines (L1, L2, L3) to the 'OUT' terminals.
3. Double-check all connections before applying power.




Image 4.2.1: Detailed wiring diagram for the EARU Electric Voltage Protector, showing connections for N, L1, L2, L3 for both input and output. The diagram illustrates how to integrate the protector into a 3-phase electrical system.

5. OPERATING INSTRUCTIONS

5.1. Initial Power-Up

Once wired, apply power to the device. The LED display will illuminate, showing the real-time voltage and current for each phase.

5.2. Display Indicators

- **V:** Voltage display.
- **A:** Current display.
- **Power:** Output indication.
- **>V:** Over-voltage indication.
- **<V:** Under-voltage indication.
- **>I:** Over-current indication.

5.3. Setting Parameters

Use the 'SET' button to enter the configuration menu and the 'Up' and 'Down' keys to adjust values. Press 'SET' again to confirm and move to the next parameter. Hold 'SET' for 3 seconds to enter settings mode.

③ 

Ovvoltage Protection Setting
Adjustable Range: 230-300V
Default: 275V

▲▼ Adjust value with up/down keys.
Short Press **SET** Switch

④ 

Ovvoltage Protection Setting
Adjustable Range: 225-295V
Default: 265V

▲▼ Adjust value with up/down keys.
Short Press **SET** Switch

⑤ 

Ovvoltage Recovery Delay
Adjustable Range: 1-500s
Default: 30s

▲▼ Adjust value with up/down keys.
Short Press **SET** Switch

⑥ 

Ovvoltage Action Delay
Adjustable Range: 0.1-30s
Default: 1.0s

▲▼ Adjust value with up/down keys.
Short Press **SET** Switch

⑦ 

Undervoltage Protection Setting
Adjustable Range: 140-210V
Default: 170V

▲▼ Adjust value with up/down keys.
Short Press **SET** Switch

⑧ 

The Adjustable Range For The Undervoltage Protection Setting
Adjustable Range: 140-215V
Default: 175V

▲▼ Adjust value with up/down keys.
Short Press **SET** Switch

⑨ 

Ovccurrent Actuation Delay
Adjustable Range: 0.1-30s
Default: 1.0s

▲▼ Adjust value with up/down keys.
Short Press **SET** Switch

⑩ 

Three-phase Current Error Value
Adjustable Range: -9.5%~9.5%
Default: 0%

▲▼ Adjust value with up/down keys.
Short Press **SET** Switch

⑪ 

Undervoltage Recovery Delay
Adjustable Range: 1-500s
Default: 30s

▲▼ Adjust value with up/down keys.
Short Press **SET** Switch

⑫ 

Undervoltage Trip Delay
Adjustable Range: 0.1-30s
Default: 1.0s

▲▼ Adjust value with up/down keys.
Short Press **SET** Switch

Image 5.3.1: A detailed guide to setting various protection parameters on the EARU Electric Voltage Protector. This includes overvoltage, undervoltage, overcurrent, and recovery delay settings, with default values and adjustment ranges.

Key adjustable parameters include:

- Overvoltage Protection Setting:** Range 230-300V (Default 270V).
- Overvoltage Protection Recover Setting:** Range 225-295V (Default 265V).
- Overvoltage Recovery Delay:** Range 1-500s (Default 30s).
- Overvoltage Trip Delay:** Range 0.1-30s (Default 1.0s).
- Undervoltage Protection Setting:** Range 140-210V (Default 170V).
- Undervoltage Protection Recover Setting:** Range 145-215V (Default 175V).
- Undervoltage Trip Delay:** Range 0.1-30s (Default 1.0s).
- Overcurrent Protection Setting:** Range 1-63A (Default 30A).
- Overcurrent Trip Delay:** Range 0.1-30s (Default 1.0s).
- Voltage & Current Manual Error Calibration:** Adjust for accuracy, range -9.5% to +9.5% (Default 0%).
- Power-on Delay Setting:** Adjustable Range: 1-500S (Default: 10s).

5.4. Manual ON/OFF

The power button allows for manual switching of the device output.

6. MAINTENANCE

The EARU-1008 is designed for minimal maintenance. However, periodic checks are recommended:

- Keep the device clean and free from dust and debris.
- Periodically inspect wiring connections for tightness and signs of wear.
- Ensure adequate ventilation around the device to prevent overheating.

7. TROUBLESHOOTING

If the device is not functioning as expected, consider the following:

- **No Display/No Power:** Check the main power supply and all wiring connections.
- **Protection Trip:** Identify the active protection indicator ($>V$, $<V$, $>I$). Check the corresponding voltage or current levels. The device will automatically reset once conditions return to normal, based on configured recovery delays.
- **Phase Failure:** The device automatically detects and responds to phase failures, initiating a cut-off and auto-reset once the phase is restored.
- **Incorrect Readings:** If readings appear inaccurate, consider performing a manual error calibration as described in Section 5.3.

Phase Failure Cut Off
Low Voltage Cut Off
High Voltage Cut Off
Overload Cut Off
Phase sequence cut off
Auto-Reset on Normal



Image 7.1: This image highlights the various protection features of the EARU Electric Voltage Protector, including phase failure cut-off, low voltage cut-off, high voltage cut-off, overload cut-off, phase sequence cut-off, and auto-reset on normal conditions. These are key aspects for troubleshooting protection trips.

8. SPECIFICATIONS

Parameter	Value
Brand	EARU
Model	EARU-1008
Rated Supply Voltage	AC 3*220V (N-L1/L2/L3) / 440V
Rated Frequency	50/60Hz
Over Current Protection Setting Range	1-63A (Default 30A)
Over Voltage Protection Setting Range	230-300V (Default 270V)

Under Voltage Protection Setting Range	140-210V (Default 170V)
Product Dimensions	20 x 10 x 20 cm
Item Weight	450 g
Mounting Type	DIN Rail




Image 8.1: This image provides a visual representation of the EARU Electric Voltage Protector's dimensions and a table of key technical specifications, including voltage, frequency, and protection ranges.

9. WARRANTY AND SUPPORT

9.1. Warranty


The EARU Electric Voltage Protector (Model EARU-1008) comes with a **1-year manufacturer's warranty** from the date of purchase, covering defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.


9.2. Customer Support

For technical assistance, troubleshooting, or warranty inquiries, please contact EARU customer support through your retailer or the official EARU website. Provide your model number (EARU-1008) and a detailed description of the issue for efficient service.

© 2023 EARU Electric. All rights reserved.

Related Documents - EARU-1008

	<p>EARU EAMPDW-TY-63 Series WiFi Smart Energy Protector User Manual Voltage, Current, Leakage Protection</p> <p>Comprehensive user manual for the EARU EAMPDW-TY-63 Series WiFi Smart Energy Protector. Learn about installation, features, technical specifications, app control, and troubleshooting for voltage, current, and leakage protection.</p>
	<p>Earu EAMPDW-TY-63 Series WiFi Smart Energy Protector User Manual</p> <p>User manual and technical specifications for the Earu EAMPDW-TY-63 Series WiFi Smart Energy Protector, detailing installation, app connection, parameter settings, and safety features.</p>
	<p>Zhejiang Earu Electronics Circuit Breaker Product Similarity Declaration</p> <p>Declaration by Zhejiang Earu Electronics Co., Ltd. confirming product similarity across various circuit breaker models, including EAWCBT, EAKCB, RDCBC, EAEMP, and EAMPDW series, based on identical electrical, software, and hardware design.</p>
	<p>EAPDX-40/63 Series Earu Electric Voltage & Current Protector User Manual</p> <p>Detailed specifications and operation guide for the Earu Electric EAPDX-40/63 series adjustable voltage and current protector. Learn how to set over-voltage, under-voltage, and over-current protection parameters.</p>

	<p><u>EARU EAMPDW-TY-63 Series WiFi Smart Energy Protector User Manual Voltage, Current, Leakage Protection</u></p> <p>Comprehensive user manual for the EARU EAMPDW-TY-63 Series WiFi Smart Energy Protector. Learn about installation, features, technical specifications, app control, and troubleshooting for voltage, current, and leakage protection.</p>
	<p><u>EAWCB Series Smart Circuit Breaker User Manual by Zhejiang Earu Electronics</u></p> <p>User manual for the EAWCB Series Smart Circuit Breaker by Zhejiang Earu Electronics, detailing product parameters, functions, wiring, dimensions, and app connection steps for Tuya, Smart Life, and eWeLink platforms.</p>

Documents - EARU – EARU-1008

no relevant documents