Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Cecotec /
- > Cecotec Conga X100 Robot Vacuum Cleaner with Self-Emptying Base and AI User Manual

Cecotec Conga X100

Cecotec Conga X100 Robot Vacuum Cleaner with Self-Emptying Base and Al

User Manual

1. Introduction

This manual provides essential information for the safe and efficient operation of your Cecotec Conga X100 Robot Vacuum Cleaner. Please read it thoroughly before using the device and retain it for future reference.

The Conga X100 is an advanced robot vacuum cleaner designed for comprehensive floor cleaning, featuring a self-emptying base, Al-powered navigation, high suction power, and adaptive mopping capabilities.

2. IMPORTANT SAFETY INSTRUCTIONS

- Ensure the power supply voltage matches the specifications of the charging base.
- Do not operate the robot in wet environments or near water.
- Keep children and pets away from the robot during operation.
- Do not use the robot to pick up large debris, sharp objects, or liquids.
- Regularly inspect the power cord for damage. If damaged, contact customer support.
- Turn off the robot and unplug the charging base before performing any maintenance or cleaning.
- Only use original accessories and replacement parts provided by Cecotec.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x Conga X100 Robot Vacuum Cleaner
- 1 x Self-Emptying and Self-Cleaning Base with 2 Tanks (Clean Water and Dirty Water)
- 1 x Dust Bag (pre-installed or spare)
- 1 x Side Brush
- 2 x Rotating Mops

- 1 x Power Cable
- 1 x Cleaning Brush/Tool
- 1 x Instruction Manual



Image: Conga X100 robot, self-emptying base, and all accessories.

4. PRODUCT COMPONENTS

4.1 Robot Overview

Familiarize yourself with the main parts of your Conga X100 robot:

- Lidar Sensor for navigation
- Front Bumper with object recognition sensors
- Power/Clean Button
- Charging Contacts

- Side Brush
- Main Brush (HairCut Brush)
- Rotating Mopping Pads
- Driving Wheels
- · Omnidirectional Wheel



Image: Underside components of the robot.

4.2 Self-Emptying and Self-Cleaning Base

The base serves as the robot's charging station and handles automatic dust emptying, mop washing, and mop drying.

- Clean Water Tank
- Dirty Water Tank
- Dust Bag Compartment
- Mop Washing Tray



Image: Robot docked at the self-emptying base.

5. SETUP GUIDE

5.1 Charging Base Placement

- 1. Place the self-emptying base against a wall in an open area, ensuring at least 1 meter of clear space on both sides and 1.5 meters in front.
- 2. Connect the power cable to the base and plug it into a power outlet.
- 3. Ensure the clean water tank is filled and the dirty water tank is empty. Install a dust bag in the base.

5.2 Initial Robot Charging

- 1. Place the robot manually onto the charging contacts of the base.
- 2. Allow the robot to fully charge before its first use. The indicator light will change when charging is complete.

5.3 App Installation and Connection

- 1. Download the official Cecotec app from your smartphone's app store.
- 2. Register an account and follow the in-app instructions to add your Conga X100 robot.
- 3. Ensure your Wi-Fi network is 2.4 GHz for optimal connection.

6. OPERATION

6.1 Cleaning Modes

The Conga X100 offers various cleaning modes:

- Vacuum Mode: Utilizes the 20000 Pa suction power to effectively remove dust and debris from floors and carpets.
- Mop Mode (Spin Mopping with Perfect Wash): The rotating mops are continuously moistened with clean water from the base to scrub and remove stains.
- Combined Mode: The robot vacuums and mops simultaneously for a complete clean.



6.2 Adaptive Lifting Technology

The robot features adaptive lifting for optimized cleaning:

- BrushUp Technology: In mop mode, the central brush is elevated to prevent contact with liquids.
- **SpinUp Technology:** In combined mode, the mopping pads are raised or lowered based on the surface detected (e.g., lifted when on carpets).



Image: Robot demonstrating mop lifting on carpet.

6.3 Al Object Recognition and Laser Navigation

The Conga X100 uses advanced AI and laser navigation to map your home, recognize objects, and plan efficient cleaning routes. This allows it to navigate around obstacles and clean effectively even in cluttered environments.



Image: Robot with AI object recognition.

6.4 Using the Mobile App

The Cecotec app provides full control over your robot:

- Start/Stop cleaning
- Select cleaning modes and power levels
- View real-time cleaning maps
- Set virtual walls and restricted zones
- Schedule cleaning tasks
- Monitor battery level and maintenance alerts
- Access the robot's camera feed for remote monitoring (if applicable).




Image: App control interface with camera view.

7. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your robot.

7.1 Self-Emptying and Self-Cleaning Base Maintenance

- Dust Bag: Replace the dust bag in the base when full. The app will notify you.
- Water Tanks: Regularly empty the dirty water tank and refill the clean water tank.
- Mop Washing Tray: Clean the mop washing tray periodically to prevent residue buildup.
- **Mop Drying:** The base automatically dries the mops after cleaning to prevent odors. Ensure the base is connected to power for this function.



Image: Automatic mop cleaning at the base.

7.2 HairCut Brush Cleaning

The innovative HairCut Brush is designed to cut and vacuum hair, minimizing tangles. However, periodic inspection and cleaning are recommended, especially if you have long-haired pets.

- Remove the main brush cover and lift out the HairCut Brush.
- Use the included cleaning tool to remove any tangled hair or debris.
- Reinstall the brush and cover securely.

7.3 Rotating Mops Cleaning

While the base performs automatic mop cleaning, it is advisable to occasionally remove and hand-wash the rotating mops for a deeper clean.

- Detach the rotating mops from the robot.
- · Wash them with mild detergent and water.
- Allow them to air dry completely before reattaching.

7.4 Filter Maintenance

The robot uses a HEPA filter to capture fine dust particles.

- Remove the dustbin from the robot and open it.
- Tap the HEPA filter gently to dislodge dust. Do not wash the HEPA filter with water.
- Replace the HEPA filter every 3-6 months, depending on usage.

8. TROUBLESHOOTING

If you encounter issues with your Conga X100, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Robot does not turn on	Low battery; Power button not pressed correctly	Place robot on charging base; Press and hold power button for 3 seconds

Problem	Possible Cause	Solution
Robot cannot find charging base	Base obstructed; Base unplugged; Robot too far from base	Ensure clear space around base; Plug in base; Manually place robot closer to base
Poor suction performance	Dustbin full; Filter clogged; Main brush tangled	Empty dustbin; Clean/replace filter; Clean main brush
Mops not cleaning effectively	Clean water tank empty; Dirty water tank full; Mops dirty/worn	Refill clean water tank; Empty dirty water tank; Clean/replace mops
App connection issues	Incorrect Wi-Fi password; Router too far; 5GHz Wi-Fi network	Verify password; Move robot closer to router; Ensure 2.4GHz Wi-Fi is used

For other issues or persistent problems, please contact Cecotec customer support.

9. TECHNICAL SPECIFICATIONS

• Brand: Cecotec

• Model Name: Conga X100

• Model Number: A01_EU01_114479

• Color: Black

• Product Dimensions: 42.5 x 34 x 46.5 cm (Robot + Base)

Product Weight: 8 kg Voltage: 220 Volts

• Power Source: Battery

• Special Features: Self-Emptying, Programmable, Al Object Recognition, Laser Navigation, Adaptive Mop Lifting, HairCut Brush, Spin Mopping

• Filter Type: HEPA

• Suction Power: Up to 20000 Pa

• **Included Components:** Robot vacuum, Self-emptying base with 2 tanks, Dust bag, Side brush, 2 rotating mops, Power cable, Cleaning brush, Manual.

10. WARRANTY AND SUPPORT

Your Cecotec Conga X100 Robot Vacuum Cleaner is covered by a manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions, including the warranty period and coverage details.

For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact Cecotec customer support through their official website or the contact information provided in your warranty documentation. Keep your purchase receipt as proof of purchase for warranty purposes.



Cecotec Conga Robot Vacuum Cleaners: Ultra-Powerful & Smart Cleaning Solutions

Explore the advanced range of Cecotec Conga robot vacuum cleaners, featuring ultra-powerful suction, intelligent navigation, and versatile 4-in-1 cleaning capabilities for a spotless home.



Conga 11090 Spin Revolution Home&Wash Robot Vacuum Cleaner User Manual

Comprehensive user manual for the Cecotec Conga 11090 Spin Revolution Home&Wash robot vacuum cleaner, detailing parts, setup, operation modes, cleaning and maintenance procedures, troubleshooting, technical specifications, and disposal guidelines.



Cecotec Conga 11090 Spin Revolution Home&Wash Robot Vacuum Cleaner Manual

This manual provides comprehensive instructions for the Cecotec Conga 11090 Spin Revolution Home&Wash robot vacuum cleaner, covering setup, operation, maintenance, and troubleshooting.



Conga 11090 Spin Revolution Home&Wash: Manual de Instrucciones y Uso

Manual completo para el robot aspirador y fregasuelos Cecotec Conga 11090 Spin Revolution Home&Wash. Incluye guías de seguridad, operación, mantenimiento, solución de problemas y especificaciones técnicas.



Manual de Usuario Cecotec Conga 7490 Eternal Genesis: Guía Completa

Descubre el manual de usuario del robot aspirador Cecotec Conga 7490 Eternal Genesis. Aprende sobre su funcionamiento, mantenimiento, seguridad y características avanzadas para una limpieza eficiente en tu hogar.



Conga 11090 Spin Revolution Home&Wash Manual de Instrucciones

Manual completo para el robot aspirador Cecotec Conga 11090 Spin Revolution Home&Wash. Aprenda sobre seguridad, configuración, modos de limpieza, mantenimiento y solución de problemas para optimizar el rendimiento de su dispositivo.