





## ATLI EON Time-Lapse Camera User Manual

[Home](#) » [ATLI EON](#) » ATLI EON Time-Lapse Camera User Manual 

### ATLI EON Time-Lapse Camera



	<b>Searching for Keywords</b> Search for keywords such as “battery” and “install” to find a topic. If you are using Adobe Acrobat Reader to read this document, press Ctrl+F on Windows or Command+F on Mac to begin a search.
	<b>Navigating to a Topic</b> View a complete list of topics in the table of contents. Click on a topic to navigate to that section.
	<b>Printing this Document</b> This document supports high resolution printing.

## Contents

### 1 Using this Manual

- 1.1 Legends
- 1.2 Recommendation for Use
- 1.3 Downloading the ATLI Cam App

### 2 Product Introduction

- 2.1 Overview
- 2.2 ATLI EON Part Names
- 2.3 Attaching the Battery
- 2.4 Connecting ATLI EON

### 3 Charging ATLI EON

### 4 Operation

- 4.1 Camera Body Features
- 4.2 Storing Photos and Videos
- 4.3 LED Status Light
- 4.4 ATLI Cam App

### 5 Updating Firmware

### 6 Notice

- 6.1 Usage Notes
- 6.2 Clean Notes

### 7 Specification

- 7.1 Basic Specifications
- 7.2 Storage and Connectivity
- 7.3 Photo / Video
- 7.4 Design

### 8 After-Sales Information

### 9 Documents / Resources


- 9.1 References

### 10 Related Posts

## Using this Manual

### Legends

 Important

 Hints and Tips

### Recommendation for Use

Download “ATLI EON Quick User Guide” at [www.atliview.com](http://www.atliview.com) to learn more about ATLI EON.

## Downloading the ATLI Cam App



Please download and install ATLI Cam App before using the camera. Scan the QR code or search for “ATLI Cam” on the App Store or Google Play




The Android version of ATLI Cam is compatible with Android v5.0 and later. The IOS version of ATLI Cam is compatible with iOS v11.0 and latest.


## Product Introduction

### Overview

ATLI EON is a multifunctional smart camera that specializes in time-lapse photography. Operated via its dedicated ATLI Cam App, ATLI EON records time-lapse and regular video in 1080p and captures high-resolution photo. With ATLI EON, you can create unique time slice photos without complicated post-editing, shoot in macro mode with a minimum focus distance of 7cm, set flexible schedules to automate the shoot, and utilize infrared imaging in low light environment. The camera is also packed with comprehensive accessories to make it weatherproof and offers a degree of protection from impact.

### ATLI EON Part Names






- ① Power Button
- ② External Flash Interface
- ③ USB Type C (For Power Only)
- ④ Status LED
- ⑤ Focus Ring
- ⑥ Focus Mark
- ⑦ Micro SD Card Slot
- ⑧ Built-in microphone
- ⑨ Battery Cover Opening Slot
- ⑩ Tripod Mount (Size: 1/4" – 20)


#### **Attaching the Battery**

Please Install the battery before using this product.

- a. Locate the battery compartment cover opening slot, and open the cover by pulling from it.



- b. Insert the battery as shown below.



c. Close the battery compartment cover.

### Connecting ATLI EON

- Press and hold the power button for 4-5 seconds to boost the camera. Wait approximately 30 seconds till the status LED changes from orange to green.
- Open ATLI Cam App, and click on "Add Camera" to scan the camera QR code.




Each ATLI EON camera has its own QR code, you can find it in either the "Quick User Guide" attached in the box or inside the camera battery compartment

### Charging ATLI EON

To charge ATLI EON, connect a USB adapter (not included) to the USB-C port using the power cable (included). Status LED will stay in red while charging and change to green once charging is completed.


Charging time: approx. 5 to 6 hours.

\*Charging time is for reference only




## Operation


### Camera Body Features



**Power Button:** Press and hold the power button for 4-5 seconds to turn on the camera when it's off. Press the power button lightly to awake the camera when it's in power saving state.


**Manual Focus:** Rotate the focus ring to set the camera focus.

Focus Mark: The green arrow mark(  ) on the focus ring is to be called the focus mark.



The camera is set to focus on objects beyond 80cm away when the focus ring is in the preset position(green focus mark aligning with the status LED).

Rotate the focus ring counter-clockwise steadily to set focus on objects ranging in between 7 to 80 cm away until the image is sharp.



**Focus Assist** : Trigger focus assist by pressing on the screen to partially magnify 2.5 times on the image.



This feature is applicable to all shooting modes.



You can adjust the focus manually with focus assist turned on.  
Cancel focus assist by tapping on the screen outside of the magnifier ring.

### **Storing Photos and Videos**


Footage shot by ATLI EON can be stored in the microSD card(included). You can download the footage to your smart device via ATLI Cam App, or access and save the footage on PC via a microSD card reader.









USB cable can only be used for charging, not for data transmission.

### **LED Status Light**

The LED status light indicates camera's current status.



-  Off: Power Off
-  Orange: Not Ready
-  Red: Charging
-  Flashing Orange: Sleep
-  Flashing Red: Ready(Power Low)
-  Green: Ready/Fully Charged



When the camera is in power saving state but there is no ongoing shoot, the LED status light will shut off. It will flash in orange when it enters power saving state during shooting.

## ATLI Cam App

### Home Page



Refresh

Refresh page.



Camera List

Click to check out all connected cameras.



Camera Operation Page:

Click to enter individual camera operation page.



Album

Click to check out local album and camera album.



Tutorial

Click to check out camera operating tutorials and shooting tips.

### Camera Operation Page



Back

Click to go back to home page.



Battery Life

Display battery life.



Time-Lapse Mode

Shoot in time-lapse mode.



Photo Mode

Shoot in photo mode.



Video Mode

Shoot in video mode.



New Updates Notification

New firmware updates notification.



Orientation

Set frame orientation.



Shooting Setting

Select auto, manual or pre-set mode.

### Shooting Setting Menu



Auto

Auto adjustment on exposure and shutter speed.





#### Cloud

Pre-set mode for shooting cloud movement.  
Recommended shooting interval: 3 seconds.



#### Cityscape

Pre-set mode for shooting cityscape at night.  
Exposure compensation: -2.0.  
Recommended shooting interval: 3 seconds.



#### Flower

Pre-set mode for shooting flowers and other plants' growth process.  
Recommended shooting interval: 600 seconds.



#### Star

Pre-set mode for shooting starry night.  
Recommended shooting interval: 600 seconds.



#### Sunrise/Sunset

Pre-set mode for shooting sunrise/sunset.  
Saturation: +5.  
Exposure Compensation: -2.0.  
Recommended shooting interval: 2 seconds.



#### Manual

Use manual mode to adjust shutter speed, ISO, white balance, image and infrared image(advanced).



#### Setting:

Setting Menu.

### General



#### WLAN:

Connect the camera to local Wi-Fi using WLAN.



#### Grid:

Use grid lines for alignment in frame composition.



#### Power Saving:

Activate power saving can significantly improve camera's battery life for long shooting task.

Common: Power saving is activated on battery power.

Mandatory: Power saving is always activated.

**Off:** Power saving is deactivated.



#### Memory Card:

View the memory card status and format the memory card.



#### About:

Check out firmware information, serial number, MAC, up time and reset to factory settings.

File Logging: Save log files to the memory card to help us improve user experience.



Restoring the camera to factory setting will not erase image files stored in the memory card.

### Time-Lapse



#### Output:

Video output in MP4 format only.

Video output in MP4 format plus photo sequence output in JPEG format.



#### Timestamp:

Enable timestamp to display shooting date and time at the lower left corner of the video.



Watermark:

Enable watermark to display ATLI EON watermark at the lower right corner of the video.



Schedule:

Customize shooting days, shooting periods and shooting intervals with our flexible schedule feature for continuously or intermittently long shooting tasks.

Repetition – Once: Set schedule once for shooting continuous task.

Repetition – Daily: Repeat schedule on a daily basis for shooting intermittent task.

## Video



Split:

5 minutes: Generate a video output every 5 minutes.

10 minutes: Generate a video output every 10 minutes.



Mute:

Enable “Mute” to record video without sound.

● Start Recording/Take Photo:

Click to start recording videos or take photos.



Camera Album:

Click to check out camera album.



## Album

Local:

Check out image files downloaded to the local album.

Time Slice:

Compose photo sequence into time slice photo.

1.  Camera album → Photo Sequence folder →  TimeSlice
2. Select Time Range, Number of Slices, Direction and Style, then click start.



- Photo sequence output is required for time slice.

- At least 8 photo sequences are required for composing a time slice.



Display:

Select a sampling display for better viewing experience due to the large number of sequences that may potentially exist.



TimeSlice:

Compose your unique time slice photo by selecting its Time Range, Number of Slices, Direction and Style.

Time Range:

Choose its exact time range to be used for composing the time slice, down to the second.

Number of Slices:

Choose the number of slices for composing the time slice.

View thumbnails of selected photo sequences. View thumbnails of selected photo sequences. Swipe left or right to view all photos. Swipe up to remove photos, swipe down to replace photos.

Direction:

Select the direction of the slices placement.

Forward – Slicing from left to right, or top to bottom.  
Reverse – Slicing from right to left, or bottom to top.

Style:

Choose the style of the time slice. Choose the style of the time slice. Vertical slicing, horizontal slicing, right oblique slicing, or left oblique slicing.

## Updating Firmware

ATLI EON can be upgraded via ATLI Cam App.

When there is firmware update, corresponding prompt will appear after connecting the camera with ATLI Cam App, please follow the prompt to proceed for upgrade.

During the updating process, the status LED light will first flash in orange, then flash in green, and eventually change to flashing in red, which indicates the completion of the update.



- A microSD card must be installed before upgrading the firmware.
- Be sure the camera to have sufficient power left before upgrading the firmware.
- Please DO NOT upgrade the firmware while shooting task is in progress.
- Please DO NOT turn off the camera while upgrading the firmware.

## Notice

### Usage Notes

### Back Up Memory Card

Data may be damaged or lost under the following circumstances. Please back up your data for its safety.

- Remove the memory card, disconnect USB cable or shut off the camera during a read or write operation.
- Use memory card where there is static electricity and electrical noise.

### Please DO NOT Use/Store This Product In the Following Places

- Extremely hot, cold or humid places
- Under direct sunlight or close to a heat source
- Vibrating or shaking places
- Near a strong magnetic field
- Sandy or dusty places
- Places with high humidity

### About Operating Temperature

This product is designed for use in a temperature range of 0°C to 40°C. It is not recommended to use this product in extremely cold or hot places beyond this range.

### About Water Resistance

This product itself is not waterproof, please DO NOT use it under water. If you need to use this product outdoor in wet weather, please be sure to use it with ATLI EON customized silicone case, lens hood and U ATLI EON customized silicone case, lens hood and UV filter.

### Clean Notes

- Please DO NOT use cleaners containing organic solvents (thinner, gasoline, etc.)
- When cleaning the surface of the lens, please use a lens pen, lens blower, lens cloth or a soft cloth or paper towel dipped in lens cleaner to remove or wipe fingerprints, dust, etc.
- Please DO NOT spray lens cleaner directly on the surface of the lens.

## Specification

### Basic Specifications

**Lens:** 4 Glass Elements

**Aperture:** F2.8

**Field of View:** 72°±5%

**Photo Resolution:** 2688 ×1520 Pixels

**Video Resolution:** 1080P

**Pixel Size:** 2μm\*2μm

**IR Cut Filter:** App Control

**Focus Mode:** Manual

**Focus Range:** 7cm to Infinity

**Exposure Metering:** Center-Weighted/Partial-Weighted

**Shutter Speed:** 1/20000 – 1.4s

**Language:** English/

**APP:** iOS/Android

### Storage and Connectivity

**Storage:** 16GB Micro SD Pre-installed (Support Up To 128GB)

**Wi-Fi:** 802.11n (Approx. Range 5 Meters Radius)

### Photo / Video

**Photo Format:** JPEG

**Video Format:** H.264 MP4

**Play Back Frame Rate:** 25fps

**Exposure Compensation:** ±4EV

**ISO:** 100 – 4000

**Shooting Mode:** Time-Lapse/Photo/Video

**Battery Type:** Li-ion

**Capacity:** 2050 mAh

**Voltage:** 3.7V

**Charging Limited Voltage :** 4.2V

**Charging Method:** USB Cable

**Operational Environment:** 0°C – 40°C

### Design

**Weight:** 125g (With Battery) 84g (Without Battery)

**Dimension:** 54\*70\*50 mm


### After-Sales Information

Please go to ATLI website at <http://www.atliview.com/warranty> to get our latest aftersales and warranty information.

❖This content is subject to change.  
Download the latest version from [www.atliview.com/tutorials](http://www.atliview.com/tutorials)



## Documents / Resources

<div>OTU EON Time-Lapse Camera</div> <div>User Manual</div> <div>2019</div> <div></div> <div>©2019</div>	<div><a href="#">ATLi EON Time-Lapse Camera</a> [pdf] User Manual</div> <div>Time-Lapse, Camera, ATLi EON</div>
---	---

## References

- [ATLi EON Time Lapse Camera | REVOLUTION IN TIME-LAPSE](#)
- [ATLi EON Time Lapse Camera | REVOLUTION IN TIME-LAPSE](#)
- [ATLi EON Time Lapse Camera | REVOLUTION IN TIME-LAPSE](#)