




CST TP-48 Customize Labels Printer User Guide

[Home](#) » [CST](#) » CST TP-48 Customize Labels Printer User Guide 

CST TP-48 Customize Labels Printer



Caution:


This is a Class A product. In a domestic environment this product may cause radio interference in which the user may be required to take adequate measures.

Contents


- [1 Packing List](#)
- [2 Appearance and Components](#)
- [3 Power Connection](#)
- [4 Loading the Roll](#)
- [5 Loading the Ribbon](#)
- [6 FCC WARNING](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)
- [8 Related Posts](#)

Packing List


- Printer




- AC Adapter




- Power Cord




- Label Roll



- Ribbon Spindles




- CD



- Quick Start Guide



- USB Cable



- Empty Ribbon Core




- Ribbon




Note: The packing materials are actually based on the order.

Appearance and Components


Front View



Rear View




Inside View



Note: The packing materials are actually based on the order.


Power Connection

1. Connect the AC adapter to power receptacle.
2. Connect the power cord to AC adapter.
3. Connect the other end of power cord to the outlet.




Loading the Roll


1. Press to open the printer cover and mechanism.



2. Pull the roll holders open and place the roll between them. Press down the locking tab.







3. Pass the labels through label guides and adjust label guides to label's width.




Loading the Ribbon


1. Install the ribbon module.




2. Insert the left part of supply spindle and then the right part spindle.




3. Press down the printer mechanism.




4. Insert the left part of rewind spindle and then the right part.



5. Wind the core 2~3 times. Press down the mechanism and close the cover.



6. Press down the mechanism and close the cover.



FCC WARNING

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause unde sired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.

CST



[CST TP-48 Customize Labels Printer](#) [pdf] User Guide
TP-48, TP-48 Customize Labels Printer, Customize Labels Printer, Labels Printer, Printer

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.