



## CYC MOTOR DS103 Display Cymotor User Guide

[Home](#) » [CYC Motor](#) » CYC MOTOR DS103 Display Cymotor User Guide 



### Contents

- [1 Required Tools and Software](#)
- [2 Getting Started – Download TPSERVICE](#)
- [3 Step 1: Connect the programming cable](#)
- [4 Step 2: Select the correct COM port](#)
- [5 Step 3: Choose the update firmware](#)
- [6 Step 4: Plug in the display](#)
- [7 Step 5: Disconnect the display](#)
- [8 Documents / Resources](#)
  - [8.1 References](#)

### Required Tools and Software



Programming cable



Wiring harness with display connector



DS103 display



Battery




TPSERVICE (software)

\*Please note that the above images are for reference only.

## Getting Started – Download TPSERVICE

Click the link below and press the “Download” button:

<https://www.dropbox.com/scl/fi/6npj91n5rlyllaqd3vx/TPSERVICE-with-SW102-DS103-Firmware.zip?rlkey=ccda8bv9xxpph7uhipgs1n9ky&dl=0>.



Extract the downloaded zip file, TPERVICE with SW102&DS103 Firmware.zip. Then extract the zip file TPERVICE.zip, inside the folder TPERVICE with SW102&DS103 Firmware.



Launch the TPERVICE.exe file and follow the setup instructions.




After installing the software successfully, TPERVICE is downloaded to your computer and can now be able to run.

### Step 1: Connect the programming cable

Ensure that you have the TPERVICE software installed, Double click the icon of TPERVICE



Check the UART drop-down, remember the COM port you have at beginning. For example, the image below has COM4 & COM5.



Connect the programming cable to the battery.




Plug the USB to the PC's USB port. The opposite end of the programming cable is connected to the main connector of the wiring harness. Afterwards, connect the DS103 display to the display connector of the wiring harness.




## Step 2: Select the correct COM port

Press the UART drop-down menu and select the appropriate COM port as each programming cable may use a different COM port. For example, COM3 is the port for this programming cable.



Select “DS103” under “Product:” and select “COM” port of your programming cable under the drop-down menu. In this example, we’ve selected COM3 for this programming cable.




### Step 3: Choose the update firmware

Press the “Update File:” button and select the respective file based on the battery voltage of your display from the folder.

For the DS103 52V Display, please select the “DS103A\_Cyc\_KM5S\_V2.1.16.2@20221209(2).zip.

For the DS103 72V Display, please select the “72V\_DS103A\_Cyc\_KM5S\_V2.1.16.9\_20230817.zip

**WARNING:** Uploading the wrong firmware file to your display will cause irreversible damage which will not be warrantied. Ensure that you upload the firmware version that matches your display version by following the provided guidelines carefully.




#### Step 4: Plug in the display


Click the “Connect” button on the dashboard.




Click on the “Update” button to install the selected display firmware version.



Right after, quickly press and hold the orange power button of the DS103 display for 1 second. It will prompt that the display is now connected.





Then wait for 5 seconds, the firmware update procedure will start automatically.




## Step 5: Disconnect the display

After the update has been 100% installed, click the “Disconnect” button and unplug the DS103 display.



For technical assistance, kindly reach out to us at [technical\\_support@cycmotor.com](mailto:technical_support@cycmotor.com). Thanks!

© 2023 CYC MOTOR LTD  
**CYC MOTOR LTD**  
[support@cycmotor.com](mailto:support@cycmotor.com)  
+852 3690 8938



## [CYC MOTOR DS103 Display Cyclopedia](#) [pdf] User Guide DS103 Display Cyclopedia, DS103, Display Cyclopedia, Cyclopedia

## References

- [📱 Get the latest App!](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.