

DYNALINK A 3245 HDMI Extender With USB KVM Instruction Manual

Home » DynaLink » DYNALINK A 3245 HDMI Extender With USB KVM Instruction Manual



Contents

- 1 DYNALINK A 3245 HDMI Extender With USB **KVM**
- **2 Product Information**
- 3 Introduction
- **4 Features**
- **5 Package Contents**
- **6 Specifications**
- **7 Operation Controls and Functions**
- **8 Application Example**
- 9 Documents / Resources
- **10 Related Posts**



DYNALINK A 3245 HDMI Extender With USB KVM



HDMI Extender With USB KVM

Product Information

The A 3245 HDMI Extender With USB KVM is a high-performance product that can extend HDMI HD signals up to 230ft / 70m via a single CAT6/6a cable. It enables zero-delay, uncompressed long-distance transmission between the transmitter and receiver. The video resolution is up to 4K2K@60Hz, and it supports KVM signal pass-through, allowing remote control of the source device at the display device. It also supports EDID copy pass-through function between source and display devices and POC function.

- HDMI2.0b and HDCP 2.2 compliant
- · Support 18Gbps video bandwidth
- Support video resolution up to 4K2K@60Hz RGB/YCbCr 4:4:4
- The transmission distance can be extended up to 230ft / 70m via a single CAT6/6a cable
- Support HDR, HDR10, HDR10+, Dolby Vision, HLG
- Audio formats: LPCM 2.0/2.1/5.1/6.1/7.1, Dolby Digital, Dolby TrueHD, Dolby Digital Plus(DD+)
- Support 3.5mm analog audio de-embedding, audio is output through the L/R OUT port of the receiver
- EDID copy pass-through function between the source device and display device
- Support bi-directional POC (Power over Cable) function
- With USB KVM pass-through function, USB1.1 compliant, support remote control by a keyboard and mouse
- · Compact design for easy and flexible installation

Product Usage Instructions

- 1. Before you start using the A 3245 HDMI Extender With USB KVM, read the manual carefully and keep it for future reference.
- 2. Make sure that your equipment is surge protected to prevent damage from electrical spikes, surges, and lightning strikes.
- 3. Connect the HDMI source device to the HDMI IN port of the transmitter using an HDMI cable.
- 4. Connect the HDMI display device to the HDMI OUT port of the transmitter using an HDMI cable.

- 5. Connect the single Cat6/6a cable between the transmitter and receiver.
- 6. Connect your keyboard and mouse to the USB ports on the transmitter and receiver.
- 7. Connect the power adapter to the transmitter and receiver.
- 8. Turn on your equipment in the following order: HDMI source device, transmitter, receiver, and HDMI display device.
- 9. If you want to use audio, connect the 3.5mm analog audio cable to the transmitter and receiver.
- 10. You can control your source device remotely using your keyboard and mouse connected to the USB ports on the transmitter and receiver.

Thank you for purchasing this product

For optimum performance and safety, please read these instructions carefully before connecting, operating or adjusting this product. Please keep this manual for future reference.

Surge protection device recommended

This product contains sensitive electrical components that may be damaged by electrical spikes, surges, electric shock, lighting strikes, etc. Use of surge protection systems is highly recommended in order to protect and extend the life of your equipment.

Introduction

This 18Gbps HDMI Extender can extend HDMI HD signal to a distance up to 230ft / 70m via a single CAT6/6a cable, which can achieve zero-delay, uncompressed long-distance transmission between the transmitter and receiver. Video resolution is up to 4K2K@60Hz. The Extender supports KVM signal pass-through, which can remote control source device at display device. It supports EDID copy pass-through function between the source device and display device. It supports POC function.

This Extender can be widely used in multi-media conference halls, TV teaching and large-screen displays.

Features

- HDMI2.0b and HDCP 2.2 compliant
- · Support 18Gbps video bandwidth
- Support video resolution up to 4K2K@60Hz RGB/YCBCR 4:4:4
- The transmission distance can be extended up to 230ft / 70m via a single CAT6/6a cable
- Support HDR, HDR10, HDR10+, Dolby Vision, HLG
- Audio formats: LPCM 2.0/2.1/5.1/6.1/7.1, Dolby Digital, Dolby TrueHD, Dolby Digital Plus(DD+)
- Support 3.5mm analog audio de-embedding, audio is output through the L/R OUT port of the receiver
- EDID copy pass-through function between the source device and display device
- Support bi-directional POC (Power over Cable) function
- With USB KVM pass-through function, USB1.1 compliant, support remote-control by keyboard and mouse
- Compact design for easy and flexible installation

Package Contents

- 1. 1 × 18Gbps HDMI Extender (Transmitter)
- 2. 1 x 18Gbps HDMI Extender (Receiver)
- 3. 1 × USB-A to USB-B Cable (1.5 meters)
- 4. 4 × Mounting Ears
- 5. 8 × Machine Screws (KM3*4)

- 6. $1 \times 12V/1A$ Locking Power Adapter
- 7. 1 × User Manual

Specifications


Technical	
HDMI Compliance	HDMI 2.0b
HDCP Compliance	HDCP 2.2
Video Bandwidth	18Gbps
Video Resolution	Up to 4K2K@60Hz RGB/YCBCR 4:4:4
Transmission Distance	4K2K@60Hz 4:4:4–70m, 1080P–70m (CAT6 cable)
Color Space	RGB 4:4:4, YCbCr 4:4:4, YCbCr 4:2:2, YCbCr 4:2:0
Color Depth	8/10/12bit
HDR	HDR, HDR10, HDR10+, Dolby Vision, HLG
Audio Formats	LPCM 2.0/2.1/5.1/6.1/7.1, Dolby Digital, Dolby TrueHD, Dolby Digital Plus(DD+)

Connection	
Transmitter	Input: 1 × HDMI IN [TypeA, 19-pin female] Output: 1 × HDMI OUT [TypeA, 19-pin female] 1 × CAT OUT [RJ45] Control: 1 × SERVICE [Micro-USB jack] 1 × USB port [Type-B jack]
Receiver	Input: 1 × CAT IN [RJ45] Output: 1 × HDMI OUT [TypeA, 19-pin female] 1 × L/R OUT [3.5mm Stereo Mini-jack] Control: 1 × SERVICE [Micro-USB jack] 2 × USB port [Type-A jack]
Mechanical	
Housing	Metal Enclosure
Color	Black
Dimensions	Transmitter / Receiver: 90mm (W)×68mm (D)×22mm (H)

Weight	Transmitter: 170g, Receiver: 169g
Power Supply	DC 12V/1A; Support bi-directional POC function
Power Consumption	4.2 W (max)
Operating Temperature	0°C ~ 40°C / 32°F ~ 104°F
Storage Temperature	-20°C ~ 60°C / -4°F ~ 140°F
Relative Humidity	20~90% RH (non-condensing)


Operation Controls and Functions


Transmitter Panel



No.	Name	Function Description
1	SERVICE	Firmware update port.
2	HDMI OUT	HDMI signal loop output port. Connect to HDMI display devices with HDMI cable.
3	HDMI IN	HDMI signal input port. Connect to HDMI source device with HDMI cable.
4	CAT OUT	RJ45 connector for connecting the CAT IN port of the Receiver with CAT6/6a cable.
5	Data Signal In dicator (Yellow)	 Illuminating: HDMI signal with HDCP. Flashing: HDMI signal without HDCP. Dark: No HDMI signal.

6	Link Signal Ind icator (Green)	 Illuminating: Transmitter and Receiver are in good connection status. Flashing: Transmitter and Receiver are in poor connection status. Dark: Transmitter and Receiver are not connected.
7	PC	Connect to PC. The computer can be accessed and controlled remotely through the USB port of the receiver (KVM function).
8	DC 12V	DC 12V/1A power input port. Note that the extender supports POC function, it means that either Transmitter or Re ceiver is connected to 12V/1A power supply, the other doesn't need power supply.
9	EDID DIP switch	Use the DIP switch to set EDID. (Switching to the upper end indicates 1; switching to the lower end indicates 0.) 11 – EDID information is copied from the display at the RX. 10 – EDID is preset to 4K @60Hz 2.0CH 01 – EDID is preset to 1080p 2.0CH 00 – EDID information is copied from the HDMI OUT at the TX.






No.	Name	Function Description
1	SERVICE	Firmware update port.
2	HDMI OUT	HDMI signal output port. Connect to HDMI display devices with HDMI cable.
3	L/R OUT	Analog audio output port, used for audio de-embedding output.
4	CAT IN	RJ45 connector for connecting the CAT OUT port of the Transmitter with CAT6/6a ca ble.

5	Data Signal Indi cator (Yellow)	 Illuminating: HDMI signal with HDCP. Flashing: HDMI signal without HDCP. Dark: No HDMI signal.
6	Link Signal Indi cator (Green)	 Illuminating: Transmitter and Receiver are in good connection status. Flashing: Transmitter and Receiver are in poor connection status. Dark: Transmitter and Receiver are not connected.
7	Keyboard port	Connect to the keyboard.
8	Mouse port	Connect to the mouse.
9	DC 12V	DC 12V/1A power input port. Note that the extender supports POC function, it means that either Transmitter or R eceiver is connected to 12V/1A power supply, the other doesn't need power supply.

Application Example

Transmitter



The terms HDMI and HDMI High-Definition Multimedia interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries.

Documents / Resources



DYNALINK A 3245 HDMI Extender With USB KVM [pdf] Instruction Manual A 3245 HDMI Extender With USB KVM, A 3245, HDMI Extender With USB KVM, Extender With USB KVM, USB KVM

Manuals+, home privacy