



## EseeCloud ZRE1 Security Camera Wireless User Manual

[Home](#) » [EseeCloud](#) » EseeCloud ZRE1 Security Camera Wireless User Manual 

### EseeCloud ZRE1 Security Camera Wireless User Manual




Before operating this unit, please read these instructions carefully, and save them for future use.

## Contents

- [1 Interface description](#)
- [2 Description](#)
- [3 Software Installation](#)
- [4 Wifi Configuration add process](#)
- [5 Wired add configuration process](#)
- [6 Documents / Resources](#)
  - [6.1 References](#)
- [7 Related Posts](#)

## Interface description



**This manual is suitable for various types of cameras.**

(The appearance may be different due to different batches. The details are subject to the receipt. This manual is only for the installation instructions of this series of equipment.)

## Description

### 1. **Photosensitive**

Collect ambient luminosity value, turn on the infrared light when the current illuminance is less than 3 Lux.

### 2. **Reset button**

The working state of the device, long press 3-5 seconds to restore the factory, the camera will have a voice prompt broadcast.

### 3. **SD card slot**

TF card, storage video and playback video

### 4. **DC power supply**

Power input

### 5. **Network port and indicator light**

Connect the Lan cable and check the current device status indicator light.

## **Account login**

**Account login:** On the login interface, enter the account/ phone number/email, and the corresponding password, and click the “OK” button to log in.

**Third-party login:** APP supports third-party login. Click the third-party social software icon, jump to the APP to complete the authorization and log in.



## **Software Installation**





Users can search “EseeCloud” on APP store or “IP PRO” on Google Play,or scan the QR code below to install the APP.

EseeCloud APP APP download

**Note:** For iOS system, it requires iOS 9.0 version or above.  
For Android,Android 5.0 or above.

## Wifi Configuration add process

### Add WIFI mode (optional)

1. Power on the device, wait for the indicator light to flash slowly, connect to the IPCXXX hotspot in the phone settings, the password is 11111111;



2. Open the APP and click on the “+” in the upper right corner to enter the scan code interface;



3. Scan the QR code on the device ;



4. On the search device interface, click "Add"



5. To view and use via WiFi or other networks, please select Remote View;



If there is no network, if you connect to the camera at close range, please select local Direct Connection;

Remote View adding process

1. Select "Remote View" to add, connect the device to WiFi, select the correct WiFi, enter the password, and click Confirm;



2. Please wait patiently during the device configuration network;



3. The device is successfully added, please set a name and password for the device.



Direct Connection adding process

1. Select “Direct Connection” to add, and set the name and password for the device to add successfully;



Note: The Direct Connection needs to be connected to the device hotspot to preview the device screen normally.

When the QR code of the device cannot be found (or the scan code is unsuccessful)

1. Connect to the IPCXXX hotspot in the phone settings, the password is 11111111;



2. Click “Other ways to add” on the scan code interface;





3. Select the wireless standalone camera, and the subsequent adding process is the same as the process of steps "Remote View " and " Direct Connection ";

## Wired add configuration process

### Adding method 1:

1. Power on the device, connect it to a router with internet access with a network cable, scan the QR code of the device, and click "Add";



2. After setting the name and password for the device, it can be added successfully



#### **Adding method 2:**

1. Select “Add by ID/IP” in “Other ways to add”;



2. Enter the device ID and password, and click Finish in the upper right corner to add successfully



### Warning



In case of fire or lightning, pls don't put product in damp and raining place, operate or maintain according to the user manual.



Be careful when you see attachment with a Dangerous Voltage which might cause serious electric accident.



### Warning

CAUTION RISK OF ELECTRIC SHOCK DO NOT OPEN

### Warning

To reduce electric shock, unprofessional people please don't open product front panel or rear panel

### Warning

In case of electric shock and fire, pls don't use power supply beyond power list in user manual

### Notice:

1. Ensure your equity, pls read the user manual carefully before you use the product
2. Pls contact professional people if you need install and maintain the product
3. Working Environment: temperature of  $-20^{\circ}\text{C} \sim +60^{\circ}\text{C}$ , relative humidity under 85%
4. Pls don't exceed the user manual's standard range of temperature, humidity and voltage.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.


This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.



---

## Documents / Resources

	<a href="#">EseeCloud ZRE1 Security Camera Wireless</a> [pdf] User Manual ZRE1 Security Camera Wireless, ZRE1, Security Camera Wireless, Camera Wireless, Wireless
---	---

## References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.