



GO LABEL GL2120TH Thermal Printer Instruction Manual

[Home](#) » [GO LABEL](#) » GO LABEL GL2120TH Thermal Printer Instruction Manual 



The Smart Way to Manage Your Restaurant Operations Thermal Printer

GoLabel is a wireless label printer designed to work with a tablet running GoOps or SubOps.


GoLabel simplifies your food prepping and labeling procedures. This Quick Start Guide will help you familiarize yourself with GoLabel before you get started.



SKIP THE GUIDE AND WATCH OUR “QUICK START” VIDEO!

Watch our “Quick Start” video by scanning the QR code or visiting

www.zippyum.com/golabelsetup



<http://qrs.ly/am6efz7>



(888) 636-7557

support@zippyum.com

www.zippyum.com

Contents

1 SETUP

2 GETTING TO KNOW YOUR GOLABEL HARDWARE

3 FCC Statement


4 PRINTING LABELS

5 Documents / Resources


6 Related Posts

SETUP


1. Open GoLabel's cover and remove any packaging material and the labels from inside. If the first label has tape on it, remove the tape.




2. Place the roll of labels directly into the printer so the labels feed from the top.




3. Push the roll of labels to the left so the left side of the roll is flush with the left side of the printer.




4. Feed the first label through the label feed guides, making sure the labels are aligned on the left side of the printer.




5. If the label is loose in the feed guides, ensure the label feed guides are adjusted to the width of the label by moving the right guide, keeping the left edge of the labels aligned with the left side of the printer.



6. Feed the first label through so it is slightly sticking out of the printer. Then close, the plugin, and turn on your GoLabel.



7. Download and install the GoOps or SubOps app on a compatible tablet.

	
http://qrs.ly/fy65a8u	http://qrs.ly/pt65a8l

8. Enter your credentials, log into the app, and follow the on-screen Quick Start Guide to pair your GoLabel and set up the app.

If you've registered, sign in using your credentials

Restaurant#


Password

Sign In

GETTING TO KNOW YOUR GOLABEL HARDWARE

1. Cover Release Button
2. Connection Indicator
3. Error Indicator
4. Pause Button
5. Feed Button
6. Power Button
7. Label Roll Bucket
8. Left Feed Guide

9. Right Feed Guide



FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by the manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.

ISED Statement:

- English: This device complies with Industry Canada license-exempt RSS standard (s). Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

The digital apparatus complies with Canadian CAN ICES-3 (B)/NMB-3(B).


This device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS 102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

This equipment complies with Canada's radiation exposure limits set forth for an uncontrolled environment.



HVIN: GL2120TH

Documents / Resources

	<p>GO LABEL GL2120TH Thermal Printer [pdf] Instruction Manual GL2120TH, GU6-GL2120TH, GU6GL2120TH, GL2120TH Thermal Printer, Thermal Printer</p>
---	--

[Manuals+](#)