


# **HAMKOT USB 3.0 to HDMI Adapter User Manual**

**Home** » **HAMKOT** » **HAMKOT** USB 3.0 to **HDMI** Adapter User Manual



USB 3.0 to HDMI Adapter Model: HE009



If you have any issues, please email us at <a href="mailto:support@hamkot.net">support@hamkot.net</a> or visit the website <a href="https://support.frescologic.com/portal/kb">https://support.frescologic.com/portal/kb</a> for more information.

# Contents [ hide

- 1 Overview
- 2 Setup the Adapter
- 3 Install Driver
- 4 Connect the Adapter
- **5 Configure the Display**
- **6 Troubleshooting**
- 7 Documents /


Resources

- 7.1 References
- **8 Related Posts**

# **Overview**

1. Host Interface: USB 3.0 Male Type-A Connector

2. Video Output: HDMI Female Connector



Model	HE009
Built-in chips	1x USB 3.0 1x HDMI Female
Connectors:	Fresco Logic FL2000
Power supply	USB bus-powered Windows 10/8.1/8/7 (32/64 bit)
Driver	Not support Mac/ Linux/ Chrome OS/ Android Not support Windows RT/ Surface RT
OS Compatibility	Built-in driver or download
Video resolutions	Up to 1080P(1920×1080)@60 Hz
Display modes	Extend, Mirror (Duplicate), Primary
Audio	NO Audio Support: Audio must be transmitted separately
Housing	2.0×1.5×0.5 Inches
USB cable tail	8.2-inch
Material	Aluminium alloy (Shell) + ABS + PVC cable
Item weighs	1.30 ounces

### Setup the Adapter

NOTE: Before you can begin connecting an additional display, you must install a driver for the adapter cable. Please follow these instructions:

#### **Install Driver**


- 1. Download the driver from the website hamkot.net/support select the correct driver for your operating system. Once the driver downloaded, right-click the downloaded ZIP-file and then click Extract All Files. You will see the driver file with the name "FL2000-2.1.34054.0.exe".
- 2. Double click on the driver file to start the installation process.
- 3. Follow the steps to complete the installation.
- 4. Once the installation is complete, please reboot your computer.

#### NOTE:


- 1. If you are working on a company computer, contact your IT specialist to log in as an Administrator having the right to install the driver.
- 2. If the driver was not successfully installed, please temporarily turn off real-time antivirus protection, then reinstall it.
- 3. Uninstall other USB graphics drivers (such as SMSC, DisplayLink), they cannot be used on your PC simultaneously.

# **Connect the Adapter**

1. Plug your display's HDMI cable male end into the adapter's HDMI female, then turn on your monitor.



1. Connect the adapter's USB end to your computer's USB 3.0 port. Waiting a few seconds, your PC will automatically detect the second monitor and display your PC's desktop screen.



#### NOTE:

- 1. Avoid video adapter chains or USB Hub. Chaining two video adapters together or use USB Hub can actually cause issues, If possible, remove other adapters or Hub.
- 2. Some laptops don't have enough juice to push the extra pixels of an external display, connect the power adapter to give it additional power.

#### **Configure the Display**


By default, the computer should automatically detect external displays and will automatically adjust the screen resolution. Sometimes, things don't go smoothly, you may still need to select the appropriate mode and adjust your resolution manually.

#### Extend or duplicate the desktop with a second monitor.

Press the Windows logo key + P on your keyboard. Select a display option according to your needs:

**Duplicate (Mirror)** — Show the entire desktop on both displays. The second monitors mirror the primary monitor. The maximum resolution is limited to the lowest resolution monitor attached to the system.

**Extend** — Both monitors combine to offer an extended desktop. The desktop screen of your PC is extended across all the detected monitors and allows you to have a desktop screen that spans across all monitors. The mouse can move between monitors.



Second screen

PC screen only


Duplicate

Extend

Second screen only

Windows 10

Windows 8.1/8



Windows 7

#### **Adjust the Screen Resolution**

If you experience problems, such as having one of the functions of the display at the wrong resolution. Right-click an empty area on the desktop, and then click Display settings (Windows 10) or Screen Resolution (Windows 8/7). From there, you can adjust the screen resolution and orientation, as necessary.


#### In Windows 10

In the Resolution drop-down menu, select a screen resolution (ex: 1920 x 1080) that you want for the selected monitor.

Choose between landscape or portrait to change the selected display orientation.

The Multiple displays option allows you to switch display modes (as described in the section above).

If the selected screen resolution mode is optimal, click Keep Changes.




#### In Windows 8.1/8

Point to Resolution

Select your desired resolution, if the selected screen resolution or display mode suits your requirement, click Keep Changes.

Click OK in the Screen Resolution window to close it.

# Change the appearance of your displays




#### In Windows 7

Click the Resolution drop-down menu, and select a screen resolution by moving the slider arrow right or left; then click OK.

If the new settings are compatible, your computer screen will reappear with the new settings in place. Click Yes if you want to keep the new settings.

Restart your computer to ensure that the changes are saved.



#### **Troubleshooting**

#### Why is the screen resolution only 800×600?

- 1. When it is connected to the PC's USB 2.0 port, the video resolution will only operate at 800×600. Please try a different port and ensure it's connected to USB 3.0
- 2. Out-of-date drivers may cause the USB 3.0 to operate at USB 2.0 speed and cause compatibility issues, please upgrade your PC's USB Controller drivers to the latest version.
  - Why is the second monitor's resolution less than 1920\*1080?
  - The resolution you can use depends on the native resolutions your monitor supports. If your the second monitor with a native resolution lower than 1920\*1080, your display screen can only run at the native resolution or lower- assuming you have a monitor with a native resolution 1440\*900, when you connect to your computer, then the maximum resolution is 1440\*900.

Why does the screen display abnormally or even a blank screen?

#### Please check the following to see if something caused this issue:

- 1. Check if your system display adapter driver is installed properly.
- 2. If you have DisplayLink devices installed in your system, please remove the driver from the Control Panel\

Programs and Features\ since this kind of device may influence the performance.

- 3. If you have the USB to VGA adapter connected to a USB 3.0 hub or docking station, connect it directly to a USB 3.0 port on your computer instead.
- 4. Out of date, USB3.0 xHCl hosts may have some compatibility issues due to the specification. It could cause either a blank/blinking screen or only low resolutions supported. Please connect the device to the latest USB 3.0 xHCl hosts.

#### The second monitor not being detected in Windows 10

Usually, it's a driver problem. If your video driver is out of date, incorrect, or faulty, Windows 10 won't be able to extend or mirror your desktop to your second display. It's also possible that your monitor driver is causing the problem.

#### External display issues? Try these steps

- 1. Avoid video adapter chains or Hub
  - Chaining two video adapters together or use USB Hub can act-ually cause issues, If possible, remove other adapters or Hub.
- 2. Change screen resolution manually
  - In your system's settings, play around with the resolution settings until something looks comfortable for your eyes.
  - Choose the default resolution. If you're using a scaled resolution already, try setting your display to use the default resolution for the display.
- 3. The screen resolution is only 800×600. Please try a different port and ensure it's connected at USB 3.0 speed.
- 4. Attach your laptop's power adapter.
  - Some laptops don't have enough juice to push the extra pixels of an external display, connect the power adapter to give it additional power.
- 5. Re-set your video connections, make sure the cable is firmly connected.
- 6. Use Auto-Adjustment of the monitor.
- 7. Check if your computer's brightness turned all the way down.
- 8. Reinstall or update the graphics driver.
- 9. Check for software updates for your software.

Made in China



Contact Us: <a href="mailto:support@hamkot.net">support@hamkot.net</a>

Website: hamkot.net



# **HAMKOT USB 3.0 to HDMI Adapter** [pdf] User Manual USB 3.0 to HDMI Adapter, HE009

# References

• 🖻 support.frescologic.com/portal/kb

Manuals+, home privacy