



KEESON MC232 Control Box Instructions

[Home](#) » [KEESON](#) » KEESON MC232 Control Box Instructions 




A Phoenix Mecano Company

Product Function instruction MC232 Version 1.1

Contents

- [1 Electrical configuration diagram](#)
- [2 Function Picture](#)
- [3 Process of test](#)
 - [3.1 HEAD port](#)
 - [3.2 FOOT port](#)
 - [3.3 Massage](#)
 - [3.4 MULTIFUNCTION port](#)
 - [3.5 Power LED & PAIRING LED](#)
 - [3.6 Power](#)
 - [3.7 Pair Function](#)
 - [3.8 FLAT function](#)
- [4 ZERO-G position function](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)

Electrical configuration diagram



Function Picture



Process of test

HEAD port

Connect to head actuator, control by a remote single:

Click head-up button on the remote, head actuator moves out, stop when released

Click head down button head actuator moves in, stop when released

This function takes effect only by pressing the corresponding button on the remote.

FOOT port

Connect to foot actuator, control by a remote single:

Click foot up button foot actuator moves out stop when released

Click foot down button foot actuator moves in stop when released

This function takes effect only by pressing the corresponding button on the remote.

Massage

Connect to head massage, control by remote:

Click head massage + button, head massage strengthens by one level;

Click head massage – button, head massage weaken by one level;

This function takes effect only by pressing the corresponding button on the remote.

MULTIFUNCTION port

Connect with the same other Control box or Other accessories;

Power LED & PAIRING LED

Power supply for control box, PAIRING LED of control box flashes for 4 times, and then turns off, POWER LED turns on

Power

Connect to the 29V DC;

Pair Function

Power up control box, pairing LED will be flash, the control box enters into the mode of code pairing, Press and holds the pairing LED of Remote, the backlight of pairing LED flashes, the backlight of remote flashes, the remote enters into the mode of code pairing; The backlight of pairing LED of remote stops flashing, and the pairing led of control box stop flash, it indicates that

the code pairing is successful;

If fails, repeat all the processes above;

FLAT function

Press and release the FLAT button on the remote, the head and foot actuators moves to a lower position (when the actuator is free, can turn off the vibration motor and turn off the indicator light when press once), stop when pressing any button

This function takes effect only by pressing the corresponding button on the remote.

ZERO-G position function

Press and release ZERO-G button on remote, the head and foot actuator moves to preset memory position, stop when pressing any button

This function takes effect only by pressing the corresponding button on the remote.

FCC Warning

Please take attention that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

ISED RSS Warning:


This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

(1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Documents / Resources

Product Information	Product Name	MC232
Product Information	Product Number	2AK23MC232
Product Information	Product Version	1.0
Product Information	Product Date	2014-01-01

MC232 Function Instructions



[KEESON MC232 Control Box](#) [pdf] Instructions
MC232, 2AK23MC232, MC232 Control Box, Control Box, Box