


LUMASCAPE LS9016 Line Voltage Non-Dimmable Light User Manual

Home » LUMASCAPE » LUMASCAPE LS9016 Line Voltage Non-Dimmable Light User Manual





User Manual




Contents

- 1 Tools Required
- **2 Included Components**
- **3 Assembly Instructions**
- **4 Wiring Designations**
- **5 Dimensions**
- 6 Documents /


Resources

7 Related Posts

Tools Required




Included Components








Assembly Instructions







Wiring Designations

Designation	Color
Active	Brown
Neutral	Blue
Earth	Green / Yellow
Data	Black

Do not Hi-Pot test

Dimensions






Please read and follow all safety instructions carefully.

Failure to do so will void warranty.

WARNING – Product Warranty is void if product is not installed as per installation instructions and in compliance with all local and provincial codes.

- Ensure installation complies with local electrical rules and regulations.
- All electrical work must be performed by a licensed electrician.


- Class II product SELV (symbol 3).
- For LED Options 2,700K, 3,000K, Red, Green, Blue, RGBA, RGBW, Tunable White: This product contains a light source of energy efficiency class G.
- For LED Options 3,500K, 4,000K, 5,000K:
 This product contains a light source of energy efficiency class F.
- All luminaires may become hot. Use discretion on where the luminaire is mounted. Take care when setting luminaire as it may become hot.
- Luminaire should only be used complete with protective shield. If protective shield is cracked, immediately stop using luminaire. Isolate light source, keep it dry and immediately contact Lumascape for replacement of protective shield (symbol 10).
- If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by Lumascape or their service agent in order to avoid a hazard.
- The light source contained in this luminaire shall only be replaced by Lumascape or their service agent.
- Do not stare at the operating light source. The luminaire should be positioned so that prolonged staring into the luminaire at a distance closer than 9.8' (3 m) is not expected (symbol 13).
- To reduce the risk of strangulation the flexible wiring connected to this luminaire shall be effectively fixed to the wall if the wiring is within arm's reach.
- Ensure mains input power is surge protected.
- Never make or break connections while the circuit is energized.
- Do not make modifications or alter the product.
- · Keep luminaire clean and free of debris.
- · Only clean with warm water.
- Do not use chemicals or abrasives to clean luminaire as this may void the product warranty.
- Connections are to be kept clean and dry at all times.
- · Suitable for use indoors or outdoors.
- Functioning earth; functional grounding (symbol 7)



ARCHITECTURAL & FACADE LIGHTING

Learn more. Visit <u>lumascape.com</u>
Find more product resources at <u>lumascape.com</u>

Documents / Resources



<u>LUMASCAPE LS9016 Line Voltage Non-Dimmable Light</u> [pdf] User Manual LS9016 Line Voltage Non-Dimmable Light, LS9016, Line Voltage Non-Dimmable Light, Non-Dimmable Light, Light