

LUTRON LHD0-96W24V-U HomeWorks Digital 3-Wire Voltage LED Controller Installation Guide

Home » Lutron » LUTRON LHD0-96W24V-U HomeWorks Digital 3-Wire Voltage LED Controller Installation Guide ™

Contents

- 1 LUTRON LHD0-96W24V-U HomeWorks Digital 3-Wire Voltage LED Controller
- **2 PRODUCT SPECIFICATION**
- **3 Required Components**
- **4 MOUNTING INSTRUCTION**
- **5 Controller Leads**
- 6 Field Adjustment Knob
- **7 Compatible Controls**
- 8 FCC
- 9 LHD0-96W24V-U Troubleshooting
- 10 Documents / Resources
 - 10.1 References
- 11 Related Posts



LUTRON LHD0-96W24V-U HomeWorks Digital 3-Wire Voltage LED Controller



PRODUCT SPECIFICATION

• Output: 2-96 W 24 V

• Input: 120-277 V~ 50 / 60 Hz,

• Max 110 W


Important Notes: Please read before installing.

- For installation by a qualified electrician in accordance with all local and national electrical codes.
- Use copper conductors only.
- · For indoor use only.
- For 277 V~ applications, a suitable barrier may be required between the non-Class 2 and Class 2 wiring, per local and national electrical wiring codes. For your convenience, the controller includes an optional barrier.
- Check to see that the controller type and rating are suitable for the application.
- DO NOT install if product has any visible damage.
- If moisture or condensation is evident, allow the product to dry completely before installation.
- Operate between 32 °F (0 °C) and 104 °F (40 °C) ambient.
- 0% to 90% humidity, non-condensing.
- Four 8-32 × 3/8 in (9.5 mm), serrated lid screws provided.
- For best practices, please refer to Application Note #591 (P/N 048591) at www.lutron.com

Required Components

For each system, ensure that you have:


• One Compatible Lutron Control 1,2



• At least one HomeWorks Digital 0.1% Controller



• At least one compatible LED Load (light engine) 3



- 1. See list of compatible controls on the reverse side.
- 2. Please refer to the control installation sheet for wiring instructions.
- 3. Refer to LED load manufacturer instructions for proper installation practices. Load ratings must match controller output ratings.

Mounting (mount as shown on the right)

- 1. Remove top cover to access multi-sided mounting key holes.
- 2. Mount controller per the options shown to the right.


Notes

- Minimum of 3 in (76 mm) required between any two LED controllers.
- Install in accordance with all national and local electrical codes.
- Mount controller in a position where it can be easily located and accessed if service or troubleshooting is necessary.
- Any other mounting configuration will require additional mechanical support. Improper installation may result in hazards to personnel or property.


Wiring (wire as shown below)

! **WARNING:** Shock Hazard. May result in serious injury or death. Turn off power at circuit breaker before installing the unit.


- 1. Remove top cover to access the terminal blocks.
- 2. Open necessary knockouts to pass wires into the wiring compartment.
- 3. Connect the necessary wires according to the illustration below. For HD1 / HD2 wiring, please refer to Application Note #142 at www.lutron.com. Terminals accept 12 AWG to 20 AWG (0.50 mm2 to 2.5 mm2).
- 4. Optional An AC line cord may be used for a 120 V~ application. The line cord must include a grounded plug to be a valid installation as shown to the right. 277 V~ applications cannot use a line cord, they must be hard-wired.
- 5. **Optional** Add barrier between non-Class 2 and Class 2 wires (e.g., HomeWorks digital wiring shown below has HD1 / HD2 as Class 2, therefore barrier is placed between input and control terminal block).
- 6. Rotate Field Adjustment Knob to full counter-clockwise position.
- 7. Ensure compatible dimmer and load are installed and restore power to the circuit. See reverse side for Compatible Controls.




3- Wire Controls



A barrier (included) in the wiring compartment separates non-Class 2 and Class 2 wires. Barrier can be placed between control and output terminals (Option 1) or between input and control terminals (Option 2).



HomeWorks Digital Modules



Compatible Controls

- 3-Wire Controls
- HomeWorks Digital Module
 Consult individual component installation guides for more details.

Controller Leads


Maximum wire length between LED controller and start of the light engine:

Wire Gauge*	Maximum Lead Length
24 AWG (0.20 mm2)*	6 ft (1.8 m)
22 AWG (0.75 mm2)*	10 ft (3.0 m)
20 AWG (0.50 mm2)	15 ft (4.5 m)
18 AWG (0.75 mm2)	25 ft (7.62 m)
16 AWG (1.0 mm2)	40 ft (12.2 m)
14 AWG (1.5 mm2)	60 ft (18.3 m)
12 AWG (2.5 mm2)	100 ft (30.5 m)
10 AWG (4.0 mm2)*	150 ft (45.7 m)

^{*} To use wire gauges larger or smaller than terminal blocks' rated gauge of 20 AWG to 12 AWG (0.50 mm2 to 2.5 mm2), connect 12 in (30 cm) or less of rated wire from terminal and connect with larger or smaller wire.

Field Adjustment Knob

Adjusting knob on the outside of the enclosure changes the minimum light level that is reached during normal operation. This feature enables the user to address light output mismatch between two or more controllers at low-end dim level. The controller is initially defaulted to the minimum light output when at low-end. For more information, please refer to Application Note #591 (P/N 048591) at www.lutron.com



- 1. Ensure knobs on all controllers are in the full counter-clockwise position.
- 2. Set control to get lowest light level.
- 3. Turn knob clockwise to adjust light output to match the brightest controller.
- 4. Repeat steps 2-3 for the remaining controllers.

Compatible Controls

For assistance in selecting controls, contact our LED Center of Excellence

FCC

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference
- 2. This device must accept any interference received, including interference that may cause undesired operation.

277 V~ NOTE: This equipment has been tested at 277 V~ and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense.

120 V~ NOTE: This equipment has been tested at 120 V~ and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

LHD0-96W24V-U Troubleshooting

Problem	Possible Solution
LED does not illuminate at high-end	Verify that the system is wired correctly according to wiring diagram and powere d.
	Verify that the LED load is wired correctly; +LED to positive, -LED to negative.
	Verify that the LED load is for "constant-voltage" applications with PWM dimmin g.
	Verify that the LED load is compatible with the specified voltage output of the controller.
	Lutron controllers are not for use with MR16 LED lamps.
LED does not illuminate at low-end	Verify that the low-end trim on the control is set properly.
	Turn Field Adjustment Knob clockwise until desired low-end operation is obtaine d.
LED does not dim	Verify that Switched Hot and Dimmed Hot are connected to the proper terminals for 3-wire control.
	Verify HomeWorks digital control wiring (HD1 and HD2) is wired according to the instructions for digital control.
LED turns on / off abruptly without Soft-on, Fade-to- B lack feature	Turn Field Adjustment Knob counter-clockwise until desired low-end operation is obtained.
	3-wire control does not have Soft-on, Fade-to-Black dimming technology.

LED is flashing, flickering, dropping out, or has poor d imming performance	Verify that a compatible dimmer is being used with the controller.
	Verify that the input voltage is within the rated limits.
	Verify that Switched Hot and Dimmed Hot are connected to the proper terminals .
	Verify that the LED load is for "constant-voltage" with PWM dimming application s.
	Verify that the length of wires between controller and LED does not exceed specification.
	Verify that the rated voltage is present at the controller.
	Certain types of LED loads may be incompatible.* Verify that the LED load is wit hin the specified wattage range of 2 W to 96 W.
	Lutron controllers are not for use with MR16 LED lamps.
LED is flashing slowly (6 to 8 second interval)	Verify that the LED load does not exceed the maximum specified power rating o f the controller (96 W).
	Verify that the LED load matches the specified voltage output of the controller.
	Verify that the length of wire between controller and LED does not exceed specification.
	Certain types of LED loads may be incompatible. *
LED output appears dim at high-end	Verify that rated line voltage is present at the terminal.
	Verify that the controller is operating in an environment within its ambient tempe rature rating.
	Verify that the controller is not located adjacent to other heat producing devices. Verify that space between controllers is greater than 3 in (76 mm).
	Verify that the maximum lead length is not exceeded per Lutron recommendatio n.
	Verify that the LED load is installed per manufacturer's instructions.
	Verify that the LED load is compatible with the specified voltage output of the controller.
Not all LED strips / fixtures illuminate	Verify that multiple LEDs connected to a single controller are properly wired.
	Verify that the LED load is installed per manufacturer's instructions.
Not all LEDs on the same s trip are evenly lit	Verify that the length of wire between the controller and LED does not exceed s pecifications.
	Verify that the LED load is for "constant-voltage" with PWM dimming application s.
	Verify that the LED load is installed per manufacturer's instructions.

LED is brighter / hotter tha
n expected

Verify that the LED load is compatible with the specified voltage output of the controller.

Certain constant-voltage loads may have added capacitance. Contact the Lutron LED Center of Excellence at 1.877.346.5338 or <u>LEDs@lutron.com</u> for more information about these loads.

For a complete list of compatible controls, see www.lutron.com/homeworksdigitalvoltagecontrols

Need Help?

Please visit the HomeWorks Digital 0.1% page at <u>www.lutron.com</u> or call Lutron Customer Assistance at 1.844.LUTRON1 1.844.588.7661)

Documents / Resources



<u>LUTRON LHD0-96W24V-U HomeWorks Digital 3-Wire Voltage LED Controller</u> [pdf] Installat ion Guide

LHD0-96W24V-U, HomeWorks Digital 3-Wire Voltage LED Controller, LHD0-96W24V-U Home Works Digital 3-Wire Voltage LED Controller

References

- Lutron: Beautiful light. Intelligent Shades. Powerful Controls
- <u>Lutron: Beautiful light. Intelligent Shades. Powerful Controls</u>
- <u>lutron.com/DriverWarranty</u>
- lutron.com/homeworksdigitalvoltagecontrols

Manuals+,