CH Tree
Ble&Bemote control



I .Product Parameter:

Category LED Controller

Domination Principle Ble

APP /
Operation Platform / Android 7.0 or IOS12.0 or later

Input Voltage DC5V Supported Driver IC YZ-CW-10

Working Temperature -20~+55°C

Control Distance Visible distance 30M

Certification CF RoHS FCC

Certification CE, RoHS, FCC
Net Weight 630g

Dimension 1M*1M/2M*2M...1000M*1000M



FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment thas been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is

encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help. To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm distance between the radiator and your body: Use only the supplied antenna.

VI. Frequently Asked Questions

- ▶ How to set up your Bluetooth LED curtain light?
- . Enable your Bluetooth on your phone.
- . Then power on the LED curtain light.
- . Open "Surplife" App, the App can directly connect to the device. It can automatically match the light without other steps, and you can experience the smart light simply and guickly.
- How can I do if connecting the Bluetooth device or adding new device failed?

Please power off the led strip light, then turn it on again, if the problem can't solve, please restart the phone.



Scan the "Instruction" QR code to read the electronic manual Or enter the APP FAO to learn more.

