

# UFO High Bay

## INSTRUCTION MANUAL

- Thank you for purchasing our UFO Highbay. Please read the below articles carefully to see how to use this product safely.
- Warning contents and attention contents related to product safety use, please be sure to follow it.

### ⚠ WARNING



Risk of Fire, Electrical Shock, Cuts or other Casualty Hazards- Installation and maintenance of this product must be performed by a qualified electrician. This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and hazards involved.



Risk of Fire and Electric Shock- Make certain power is OFF before starting installation or attempting any maintenance. Disconnect power at fuse or circuit breaker.



Risk of Fire- Minimum 90°C supply conductors.

Risk of Burn- Disconnect power and allow fixture to cool before handling or servicing.

Risk of Personal Injury- Due to sharp edges, handle with care.




Failure to comply with these instructions may result in death, serious bodily injury and property damage.

### Attention

1. This UFO High Bay within the input voltage range: 100-277v, 50/60Hz.
2. If input voltage exceeds this range, it may cause the lamp failure. Please be sure to operate under correct input voltage.
3. Ensure ambient operating temperature of -35°C~50°C.
4. Using this UFO high bay in temperatures outside of this range will reduce the UFO high bay lifespan.
5. Make sure to turn off power before starting the installation process.
6. IP rating of IP65, can work under damp/wet locations.
7. Please keep the UFO High Bay away from any corrosive substance. When you clean it, please use damp or dry cloth.

### Wiring Diagram




### Power adjustable



Model	RMS-HB-100	RMS-HB-150	RMS-HB-200	RMS-HB-240
LOW	60W	90W	120W	150W
MID	80W	120W	150W	200W
HIGH	100W	150W	200W	240W


### Product Dimension :




Model	RMS-HB-100	RMS-HB-150	RMS-HB-200	RMS-HB-240
Φ1	132mm/5.19"	132mm/5.19"	132mm/5.19"	132mm/5.19"
Φ2	280mm/11.02"	280mm/11.02"	340mm/13.39"	340mm/13.39"
H	115mm/4.53"	115mm/4.53"	116.5mm/4.59"	116.5mm/4.59"

### Installation


1. Lock the hook. (Figure 1.)



2. Install and tighten the set screw. (Figure 2.)



3. Hang up the fixture. (Figure 3.)



4. Install the lock screw. (Figure 4.)

