

Register your product and get support at

www.philips.com/welcome

AS351



User manual

PHILIPS

Contents

1	Important	2	5	Other features	17
	Safety	2		Use more features with DockStudio	17
	Important Safety Instructions	2		Listen to Internet radio	17
				Set sleep timer	17
				Set alarm timer	18
2	Your Docking Speaker for Android™	3		Charge your phone through the USB socket	19
	Introduction	3		Play audio from an external device	19
	What's in the box	3			
	Overview of the main unit	4	6	Product information	21
3	Get started	5		Specifications	21
	Power supply	5	7	Troubleshooting	22
	Option 1: AC power	5			
	Option 2: Battery power	5	8	Notice	23
	Turn on	5		RSS	23
	Switch to standby mode	5		Disposal of your old product	23
4	Play and charge	6			
	Compatible with Android™	6			
	Play audio through manual Bluetooth connection	6			
	Play audio through auto Bluetooth connection with Philips DockStudio	7			
	Install DockStudio app onto Android-powered device	8			
	Activate Bluetooth with DockStudio app	10			
	Dock and charge Android-powered phone	13			
	Dock Android-powered device	13			
	Use dock extension	13			
	Charge Android-powered phone	14			
	Play audio with Philips Songbird	14			
	Install Songbird on Android-powered device	14			
	Install Songbird on PC	16			
	Sync with PC through Philips Songbird	16			

1 Important

Safety

Important Safety Instructions

- ① Read these instructions.
- ② Keep these instructions.
- ③ Heed all warnings.
- ④ Follow all instructions.
- ⑤ Do not use this apparatus near water.
- ⑥ Clean only with dry cloth.
- ⑦ Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- ⑧ Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- ⑨ Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- ⑩ Only use attachments/accessories specified by the manufacturer.
- ⑪ Unplug this apparatus during lightning storms or when unused for long periods of time.
- ⑫ Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- ⑬ **Battery usage CAUTION** – To prevent battery leakage which may result in bodily injury, property damage, or damage to the unit:
 - Install all batteries correctly, + and - as marked on the unit.
 - Do not mix batteries (old and new or carbon and alkaline, etc.).
 - Remove batteries when the unit is not used for a long time.
- ⑭ Apparatus shall not be exposed to dripping or splashing.
- ⑮ Do not place any sources of danger on the apparatus (e.g. liquid filled objects, lighted candles).
- ⑯ This product may contain lead and mercury. Disposal of these materials may be regulated due to environmental considerations. For disposal or recycling information, please contact your local authorities or the Electronic Industries Alliance: www.eiae.org.
- ⑰ Where the plug of the Direct Plug-in Adapter is used as the disconnect device, the disconnect device shall remain readily operable.



Warning

- Never remove the casing of this apparatus.
- Never lubricate any part of this apparatus.
- Never place this apparatus on other electrical equipment.

2 Your Docking Speaker for Android™

Congratulations on your purchase, and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

Introduction

With this docking speaker, you can:


- enjoy audio from your Bluetooth-enabled portable device or an external device;
- charge your phone; and
- experience various features brought by Philips **Philips DockStudio** and **Philips Songbird** app.

What's in the box

Check and identify the contents of your package:

- Main unit
- Power adapter
- Dock extension
- Quick start guide
- Safety sheet

Overview of the main unit



① 

- Activate or deactivate Bluetooth function.

② 

- Bluetooth indicator.

③ 

- Charge your phone through USB cable.

④ **AUX IN**

- Connect an external audio device.

⑤ **Dock for Android-powered device**

⑥ **+/-**

- Adjust volume.

⑦ **Power supply socket**

⑧ **Battery compartment**

3 Get started

Always follow the instructions in this chapter in sequence.

Power supply


Either AC power or batteries can be used as power supply of this speaker.

Option 1: AC power

! Caution

- Risk of product damage! Ensure that the power voltage corresponds to the voltage printed on the back or underside of the unit.
- Risk of electric shock! When you unplug the AC adapter; always pull the plug from the socket. Never pull the cord.

Connect the power adapter to the wall outlet.




Option 2: Battery power

! Caution

- Risk of explosion! Keep batteries away from heat, sunshine, or fire. Never discard batteries in fire.

- 1 Open the battery compartment.
- 2 Insert 4 AA batteries with correct polarity (+/-) as indicated.
- 3 Close the battery compartment.



≡ Note

- Batteries contain chemical substances, so they should be disposed of properly.

Turn on

Press Φ .

- ↳ The Bluetooth indicator Φ begins to blink.

Switch to standby mode

Press Φ again to switch the docking speaker to standby mode.

- ↳ The Bluetooth indicator Φ turns off.

4 Play and charge

With this docking speaker, you can enjoy audio in two ways:

- through manual Bluetooth connection;
- through automatic Bluetooth connection with **Philips DockStudio** app.

Compatible with Android™

To make full use of your docking speaker, your Android-powered device should satisfy the following requirements:

- With Android operation system (Version 2.1 or above);
- With Bluetooth software (Version 2.1 or above); and
- With a micro USB connector.

For other devices with micro USB connector and Bluetooth function, you can still use the docking speaker to do the following:

- Charge your device through the USB connector or USB socket;
- Enjoy audio through Bluetooth.



Tip

- For more details, go to www.philips.com/flexidock.


Play audio through manual Bluetooth connection

The docking speaker uses Bluetooth wireless technology to stream music from your portable device to the system.


Note

- Before you connect a Bluetooth device to this docking speaker, familiarize yourself with the Bluetooth capabilities of the device.
- Keep this docking speaker away from other electronic devices that may cause interference.


- 1 On your docking speaker, press **⏻** to activate Bluetooth.
➡ The Bluetooth indicator **⚡** blinks on the display panel.
- 2 Turn on Bluetooth function of your portable device.
 - Different devices may have different way to activate Bluetooth.




- 3 Scan Bluetooth devices that can pair with your portable device.



- 4 When [PHILIPS AS351] is displayed on your device, select it to start connection.
- ↳ If connection is successful, you will hear double beep confirmation and find a different Bluetooth icon on the top of the screen.



- 5 Play audio with the media player of your portable device.



- ↳ The audio comes out through the docking speaker.



Tip

- The effective operation range between the docking speaker and the paired device is approximately 10 meters (30 feet).
- Any obstacle between the speaker and the device can reduce the operational range.

Play audio through auto Bluetooth connection with Philips DockStudio

Philips DockStudio app brings a suite of new features to your docking speaker; including automatic Bluetooth connection, Songbird music player, Internet radio and a multi-function alarm clock. To enjoy more features, you are recommended to download and install the free app.

Install DockStudio app onto Android-powered device


You have two ways to install **Philips DockStudio** on your Android-powered device.

Install DockStudio app through QR code

Note

- Make sure that your Android-powered device is connected to the Internet.
- Make sure that your device has a barcode scanner such as "QR Droid". If not, download one from the Android market.


- 1 Use the barcode scanner to scan the QR code on the package or Quick Start Guide.




- 2 Follow the on-screen instructions to install **Philips DockStudio** app.



- 3 When installation is complete, tap **[Done]** (done).



- The **DockStudio** icon appears on your portable device.



2 Tap the search icon on the screen.


Install DockStudio app through Android Market

You can also search **Philips DockStudio** from Android Market directly, and then install the app.

Note

- Make sure that your Android-powered device is connected to the internet.
- Make sure that Android Market is available on your Android-powered device.


1 Tap the "Android Market" icon on your device.



- 3 In the search bar, type in "Philips DockStudio" to search the app.
- 4 From the search result list, find and tap **Philips DockStudio** to start downloading.
- 5 Follow the on-screen instructions to install the **DockStudio** app.



- 6 When installation is complete, tap **[Done]** (done).



Activate Bluetooth with DockStudio app

Philips DockStudio app helps to connect your Android-powered device and docking speaker through Bluetooth automatically.

Note

- Make sure that your Android-powered device is connected to the Internet.

First-time launch

- 1 On your docking speaker, press **⓪** to activate Bluetooth.
↳ **⓪** blinks on the display panel.
- 2 On the home screen of your device, tap the **DockStudio** icon to launch the app.




- ↳ A prompt message asking you to download **Songbird** appears.



- 3 Tap **[Cancel]** (cancel).



- ↳ The device starts to scan Philips devices that can be paired automatically.




- ↳ After Bluetooth connection, a different Bluetooth icon can be found on the top of the screen.



- 4 When **[PHILIPS AS351]** is displayed on your device, select it to start connection.
↳ It may take a few seconds to complete the connection.

- 5 Play audio with the media player of your portable device.



↳ The audio comes out through the docking speaker.

Next-time launch

Next time you launch the **DockStudio** app, connect to the docking speaker through Bluetooth as below.

- 1 Activate the Bluetooth function of your docking speaker.
- 2 Launch **Philips DockStudio** to access its menu.



- 3 Tap **[Speaker Connection]** (Speaker Connection) to activate automatic Bluetooth connection.



↳ It may take a few seconds to complete the connection.

- 4 Play audio on your portable device.




- ↳ The audio comes out through the docking speaker.

Dock and charge Android-powered phone


Dock Android-powered device

To charge your Android-powered phone, you need to dock it in the docking speaker first.

- 1 Check the orientation of the micro USB connector on your Android-powered phone. If your USB connector has a cover, flip it outwards.
- 2 If necessary, rotate the USB connector on the docking speaker; and then place your Android-powered phone onto the dock.




PHILIPS




PHILIPS

- 3 Adjust the bumpers on both sides of the connector to stabilize the phone.



- 4 Slide the connector to place your phone in the middle of the docking speaker.



Tip


- If the micro USB connector is located at the top, and you are using Android system of version 2.3 or above, screen auto-rotation is available.

Use dock extension

If the USB connector on your phone is close to the edge, the supplied dock extension can balance the docked phone, as illustrated.

- 1 Adjust the slide knobs to make both bumpers at the lowest position.
- 2 Place the dock extension onto the dock.

3 Dock your phone.



Charge Android-powered phone

When the docking speaker is connected to power, the docked phone starts charging automatically.



Tip


- This function is also available for non Android-powered device that has a micro USB connector.

Play audio with Philips Songbird

Philips Songbird is a simple, easy-to-use PC program and Android app. It lets you discover, play and sync your media from PC to your Android-powered devices seamlessly.

Install Songbird on Android-powered device


- 1 Tap the **DockStudio** icon on your Android-powered device.



→ The **DockStudio** menu is displayed.



- 2 Tap **[Songbird]**.




↳ You are requested to download Songbird.


- 3 Follow the on-screen instructions to download the app.



- 4 After installation, tap **[Open]** (Open) to access Songbird menu.



- 5 Select a track, and then tap ► to play music.





Install Songbird on PC

- 1 Go to www.philips.com/songbird.
- 2 Search **Songbird**.

songbird 

- 3 Download the latest **Songbird** application.
- 4 Follow on-screen instructions to install **Philips Songbird** on your PC.

Sync with PC through Philips Songbird

Note

- Make sure that you have turned on the USB storage.

- 1 On your PC, launch **Philips Songbird**.
- 2 Connect your Android-powered device to PC with a USB cable. Wait until the device is recognized by the **Songbird**.
 - ↳ On **Philips Songbird**, the device is displayed when it is recognized by the PC.



- ↳ If it is the first time you connect the device to **Philips Songbird**, a pop-up screen appears. Select auto sync as prompted.



- ↳ The device synchronizes with **Philips Songbird** automatically.

If you didn't select auto sync, you can sync with **Songbird** manually.

- 1 Select the device under **Devices**.



- 2 Select **Manual** or **Auto**.



- 3 Click **Sync**.
 - ↳ If you have selected auto sync, auto sync starts automatically when you connect the device to the PC.



1 Launch the app.



3 Select a time period for the sleep timer, and then tap **[Start]** (Start).



2 Tap the icon ***** to access clock setting menu.



3 Tap **[Alarm settings]** (Alarm settings).

Note

- This function only works with **Philips Songbird**.

Set alarm timer

With **Philips DockStudio**, you can set multiple alarms and know the latest weather. It even alerts you when weather conditions are suitable for your favorite outdoors activity.



- 4 Tap **+** to access alarm setting menu.



- 5 Set the alarm, and tap **[Save]** (Save) on the top right of the screen.
 ↳ The new alarm is saved and displayed on the screen.



Note

- From the **[Lifestyle]** (Lifestyle) tab, you can select your preferred sport and weather (excellent, good, or fair). The alarm will not ring if the weather is not good enough.

Charge your phone through the USB socket

Connect a USB cable (not supplied) to:

- the  socket at the back of the speaker.
- the USB socket on your phone.

Note

- It is not guaranteed that all USB cables work with this speaker.

Play audio from an external device

You can listen to audio from an external device through this speaker.

- 1 Connect an MP3 link cable (not supplied) to:
 - the **AUX IN** socket.
 - the headphone socket of an external device.
- 2 Play audio on the external device (see the device's user manual).

6 Product information

Note

- Product information is subject to change without prior notice.

Specifications

AC Power	OH-1028A0903000U-VDE/-UK/-SAA/-CCC/-IR/-UL (Philips); OH-1028A0903000U (Philips). Input: 100-240V~, 50/60Hz, 800mA; MAX Output: 9V === 3A
Operation Power Consumption	< 35W
Eco Standby Power Consumption	< 1W
Dimensions - Main Unit (W x H x D)	270.5 X 88.5 X 141.5 mm
Weight - Main Unit	0.885 kg
Charging:	
- through micro USB connector	2A
- through  socket	2A
- through micro USB connector and  socket	1A for each

7 Troubleshooting



Warning

- Never remove the casing of this device.

To keep the warranty valid, never try to repair the system yourself.

If you encounter problems when using this device, check the following points before requesting service. If the problem remains unsolved, go to the Philips Web page (www.philips.com/support). When you contact Philips, make sure that the device is nearby and the model number and serial number are available.

No power

- Make sure that the AC power adaptor of the device is connected properly.
- Make sure that there is power at the AC outlet.
- Make sure that the batteries are inserted correctly.
- If the speaker is powered by the batteries, make sure that the adapter is not connected to the device.

No sound or poor sound

- Adjust the volume of the docking system.
- Adjust the volume of your phone.

No response from the unit

- Disconnect and reconnect the AC power plug, then turn on the unit again.

8 Notice

Any changes or modifications made to this device that are not expressly approved by Philips Consumer Lifestyle may void the user's authority to operate the equipment.

Notice for the USA

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Relocate the receiving antenna.
- Increase the separation between equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC's and IC's RF radiation exposure limits set forth for an uncontrolled environment. The antenna(s) used for this transmitter must be installed and operated to provide a separation distance of at least 20 cm from all persons and must not be collocated or operating in conjunction with any other antenna or transmitter. Installers must ensure that 20cm separation distance will be maintained between the device (excluding its handset) and users.

The set complies with the FCC-Rules, Part 15. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

RSS

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Disposal of your old product

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused. Never dispose of your product with other household waste. Please inform yourself about the local rules on the separate collection of electrical and electronic products and batteries. The correct disposal of these products helps prevent potentially negative consequences on the environment and human health.

Your product contains batteries, which cannot be disposed of with normal household waste. Please inform yourself about the local rules on separate collection of batteries. The correct disposal of batteries helps prevent potentially negative consequences on the environment and human health.

Please visit www.recycle.philips.com for additional information on a recycling center in your area.

Environmental information

All unnecessary packaging has been omitted. We have tried to make the packaging easy to separate into three materials: cardboard (box), polystyrene foam (buffer) and polyethylene (bags, protective foam sheet.)

Your system consists of materials which can be recycled and reused if disassembled by a specialized company. Please observe the local regulations regarding the disposal of packaging materials, exhausted batteries and old equipment.



Note

- The type plate is located on the bottom of the apparatus.



Specifications are subject to change without notice
© 2012 Koninklijke Philips Electronics N.V.
All rights reserved.

AS351_37_CCR_V2.0

