

CACTUS KIDOCALL



QUICKSTART GUIDE

- *buy a 4G LTE NANO SIM card (micro sim) with activated data flow, GPRS and caller display functions from any service provider**
- *charge the KidoCall watch fully using the cable provided – insert the cable into a USB wall charger and attach the magnetized end to the gold points on the back of the watch**
- *when the watch is fully charged, remove the charger & please turn the watch off (screen blank) before inserting the SIM card**
- *remove the little cover on the left side of the watch using the provided screwdriver and do not replace the cover until setup is completed**
- *insert the SIM card fully into the cavity, chip up and notch facing in - the SIM must not slide out towards the edge, it must remain firmly in position inside the SIM cavity – you can use a SIM card tool to do this**
- *power the watch on (press the power on/SOS button for 2 seconds)**
- *swipe the screen to the left to go to settings>scroll down to reboot>tap on reboot**
- *download the APP SeTracker2 onto parent's phone or use computer GPRS platform – for APP download, please scan the QR code on the manual or on the watch go to QR Code>App Code and scan with your phone's camera**
- *once App download is completed, register a new account using a valid email address, create a password and register. Note: area for Australia & New Zealand is Asia & Oceania; you will be prompted with a verification code – enter this code and register**

QUICKSTART GUIDE
PAGE 2

***you are now ready to bind the watch with the APP on your phone – switch Bluetooth on in your phone, power the watch on, go to QR code>RegCode – this code should have letters and numbers – in the APP please scan the watch's QR Regcode by hovering over the code with the APP in your phone.**

***complete the details on this page of the APP, such as name/nickname of the child, avatar/photo and your relationship (Mom, Dad etc)**

***if the QR Regcode appears as 0000000000 only, move to an area where the 4G network coverage is good and stable, and wait a few minutes for the SIM to connect to the network**

***SIM card error message occurs when the SIM has not been inserted correctly (sliding out)**

***device offline error message occurs when signal coverage is not good. Move to a position where signal coverage is better. In addition, on the watch, go to settings>more>wifi>switch this on (blue) and allow the watch to connect to your wifi**

***when the binding has been successfully completed, go to Phone Book in the APP and add names & phone numbers of permitted contacts, and save – these will then appear in the contacts list on the watch; calls from numbers not authorized in the phone book (contacts) will be blocked**

***in the APP, go to Switch Settings (terminal functions) where you can disable the dial pad to prevent the watch making calls to random numbers not authorized**

***Two parents can both be linked to one KidoCall watch – see the manual item 5. Authorizing a Secondary Administrator**

***And one parent can have 2 or more KidoCall watches linked to the APP on their phone – same process as above, and bind a second watch to the same APP on your phone**

***the KidoCall is IP67 waterproof, which is splash proof for daily use; can be immersed in stationary water; not for swimming or showering**

www.cactuswatches.com