



VISIT US ONLINE:
Have a question?
Need service or repair?
Want to leave a comment?
PyleUSA.com/ContactUs

PYLE

Questions? Issues?
We are here to help!
Phone: (1) 718-535-1800
Email: support@pyleusa.com

PYLE
PyleUSA.com



PWMA1080IBT

Wireless BT Portable PA Speaker System
Built-in Rechargeable Battery, iPod Dock, 800 Watt

User Manual

We recommend that you read this manual carefully so that you can fully take advantage of the advanced and convenient functions of the Portable PA Speaker and Microphone System. We also recommend that you keep this manual in a safe and handy place for future reference.

⚠ CAUTION

WARNING! DON'T OPEN THE MACHINE TO AVOID ELECTRIC SHOCK, PLEASE ASK HELP FROM PROFESSIONAL TECHNICIANS.




SAFETY INSTRUCTION

1. Read this manual carefully before using. Retain for future reference.
2. All warnings on the speaker and in the operating instructions should be adhered to.
3. Do not use this apparatus near water.
4. Do not block any of the ventilation openings. Install in accordance with the manufacturers instructions. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat. Do not install the speaker in an airtight location.
5. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
6. Switch OFF and unplug then use a soft cloth to clean the exterior of the unit if it becomes dirty. If necessary, use a damp cloth that has been wrung out well to wipe it.
7. Unplug this apparatus during lightning storms or when unused for long periods of time.
8. Keep foreign objects and liquid from entering the unit to avoid a short circuit, fire and electrical accidents.
9. Place the speaker in a dry location.
10. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.


SYSTEM FUNCTION FIGURE

- | | |
|--------------------------------------|-------------------------------|
| 1. Wireless Mic/MIC 1 Volume Control | 16. Guitar Input Jack |
| 2. MIC 2 Volume Control | 17. Mid Speaker |
| 3. Guitar Volume Control | 18. Vent Hole |
| 4. Audio Volume Control | 19. Unit Fixed Stand |
| 5. Ipod Dock | 20. Vent Hole |
| 6. Ipod/MP3 Volume Control | 21. Woofer Speaker |
| 7. Echo Control | 22. Tweeter |
| 8. Treble Control | 23. MIC 2 Input Jack |
| 9. Bass Control | 24. MIC 1 Input Jack |
| 10. Metal Corner | 25. Power Switch |
| 11. Wireless BT ON/OFF switch | 26. Power Indicator |
| 12. Wireless BT indicator light | 27. Low Voltage Indicator |
| 13. Audio Output Jack | 28. Charge Indicator |
| 14. Ipod/MP3 Input Jack | 29. Wireless Mic RF Indicator |
| 15. Audio Input lack | |



SYSTEM FUNCTION FIGURE

- | | |
|-----------------------------|----------------------------------|
| 30. Trailer Handle | 39. Rechargeable Battery Cover |
| 31. Heating Pane | 40. Warning label |
| 32. Handle | 41. 7AH/12V Rechargeable Battery |
| 33. Audio Out | 42. Trailer Truckle |
| 34. Voltage Selector Switch | 43. MicHead |
| 35. AC Fuse/Battery Fuse | 44. Handheld Mic RF Indicator |
| 36. Power line(-115V /230V) | 45. Handheld Mic Power Switch |
| 37. External DC Input Jack | 46. Handheld Mic Battery Housing |
| 38. 2 PIN Power Socket | |



INSTRUCTIONS

1. Confirm the power

AC Power: Before operation, please confirm the voltage is same as the specified marked on the label. If not, the unit will be damaged.

Built-in Rechargeable Battery: Plug-in the AC power when the rechargeable battery voltage is enough but use the battery directly. When the Low Voltage indicator turns yellow, it indicates the low battery, please charge it in time. When the Low Voltage indicator turns OFF, it indicates the voltage is standard now. If the unit will not be used for a long time, please charge the rechargeable battery every 2 months, 8-10 hours for each time.

2. Operation Instructions

- Plug the power cable into the socket and connect it with this amplifier system.
- Switch **ON** the amplifier. the Power Indicator comes red.
- During charging, **RECHARGE** indicator turns red, when the indicator is flashing, that means battery is almost full and turns **OFF** when fully charged.
- During charging, you can play music at the same time, the **RECHARGE** indicator will flash with the current consumption indicating the speed of charge. Charge time is in direct proportion to the volume of music. When the battery is full, **RECHARGE** indicator will stop flashing and turns off.
- Put two AA 1.5V battery into handheld microphone (bodypack transmitter), push the Power Switch to the middle, the Power Indicator will flash once, RF Indicator turns green.
- Push the handheld microphone Power Switch (bodypack transmitter) to ON position, your sound can be heard from amplifier when speaking. Adjust the Volume Control/Echo Control/Treble Control/Bass Control to proper position to avoid feedback.
- If the microphone Power Indicator (bodypack transmitter) turns on at all times, it indicates the low battery, please replace the battery.
- Connect relative guitar cable with Guitar Input Jack on this system to play music.

3. Wired Microphone

- Two way wired microphone input jacks are supplied for two people to use simultaneously.
- Plug Wired microphones into the jacks separately. Adjust Echo Control to get better sound.
- Adjust the volume of each microphone to make sure the sound is satisfactory.

When you turn on the unit, be sure ECHO control is set to low or there will cause sound distortion

4. Wireless BT Playback

You can connect your Wireless BT phone or other device to the PA speaker.

1. Turn **ON** the unit.
2. Press the **ON/OFF** switch on front panel to turn **ON** Wireless BT, indicator light is lit.
4. Use your Wireless BT phone or other device to search for the Wireless BT name **"PYLE SPEAKER"**.
5. Select the **"PYLE SPEAKER"** Wireless BT name and wait for the device to pair automatically.
6. You do not need code and get connected with unit.
7. Once paired you can play music from your Wireless BT device.
8. You can use the **VOLUME/BASS/TREBLE** to adjust the sound level for Wireless BT, also you can adjust the Wireless BT music sound through your own phone or other device.

NOTES:

Check the volume controller both on the unit and on your phone or other device if there is no sound through the PA speaker during Wireless BT.

What's in the Box:

- Portable PA Speaker
- 1/4" to Aux (3.5mm) Audio Cable + Adapter
- Battery Terminal Alligator Clamp Cables
- RCA Connection Cable
- Power Cable

System Features:

- Rugged & Compact Public Address Sound System
- Built-in Rechargeable Battery & 30-Pin iPod Dock Connector
- (2) 1/4" Microphone Inputs + (3) 1/4" Guitar/Instrument Inputs
- Ability to Connect & Stream Audio From External Devices
- Sound System: 10" Subwoofer, 4" Mid-Range + 4" Tweeter
- Connect up to (3) Mics Simultaneously for a Karaoke Party
- Ported Enclosure for Increased Bass Response
- Independent Channel Volume Controls
- Audio Configuration: Echo, Bass and Treble Controls
- Telescoping Handle & Caster Wheels
- 35mm Speaker Stand Mount
- LED Indicator Lights
- External 12V Power DC Input Connector
- Perfect for Karaoke, Public Events, Crowd Control, etc.

Wireless BT Connectivity:

- Built-in Wireless BT Music Streaming
- Works with All of Your Favorite Devices
(iPhone, Android, Smartphone, iPad, Tablet, Computer, etc.)
- Wireless BT Network Name: Pyle Speaker
- Wireless BT Version: 3.0
- Wireless BT Range: 100 Ft.

Technical Specs:

- Max Power Output: 800 Watt
- RMS Power Output: 400 Watt
- VHF Band Signal System Transmission
- System Battery Life: Approx. 8 Hours
- Average Charging Time: 8 - 10 Hours
- SPL: 94dB (1W/M)
- T.H.D.: <1%
- Power Supply: 120/220 Voltage Switchable
- Dimensions (L x W x H): 12.2" x 10.2" x 22.3" -inches